Xperia 5 II User Guide

# Xperia 5 II User Guide Contents

Introduction
About the User Guide3
Getting Started
Parts & Functions6
SIM Card7
SD Card9
Charging Internal Battery12
Power On/Off12
Making Initial Settings13
Setting a Google Account15
Locking Screen
Basic Operations
Basic Operation22
Using Touchscreen22
Silent Mode23
Airplane Mode24
Text Entry25
Updating Software26
Handset Interface
Handset Screens
Status Bar29
Using Notifications Window30
Using Quick Settings31
Phone
Placing/Answering Calls34
Optional Services36
Phone Number
Using Contacts43
Messaging
Sending Messages (+Message)46
Using Gmail
Internet
Using Chrome50
6
Camera
Capturing Still Images/Videos54
Viewing Still Images/Videos (Photos)55
Application Basics
• •
Applications
Adding Applications59
Wi-Fi/Bluetooth
Connecting by Wi-Fi64
Using Bluetooth Function
osing bluetooth i unction
Handset Settings
<b>-</b>

Data Usage Settings	69
Battery Settings	
Display Settings	
Sound Settings	
Security Settings	
System Settings	
Other Settings	
Other Settings	/ 3
Global Services	
Global Roaming	80
Making Calls while Abroad	8′
W	
Warranty/Specifications/Customer Service	
Warranty & After-Sales Service	86
Specifications	86
Customer Service	87
Safety Precautions	
Safety Precautions	90
Important Product Information	
Bluetooth/Wi-Fi (WLAN)	100
Water Resistance/Dustproofing	102
End User License Agreement	
Export Controls and Regulations	
Intellectual Property Rights	
RF Exposure Information/Specific Absorption Rate	
Information	
FCC Statement for the USA	
Operation Radio Frequencies	
- t	

## About the User Guide

Most operation descriptions are based on default settings. Unless noted otherwise, descriptions are for Home Screen. Some operation descriptions may be omitted.

#### Before You Begin

- $\cdot$  Read "Safety Precautions" and this guide thoroughly beforehand for proper usage.
- $\cdot$  Accessible services may be limited by contract conditions.
- · Unauthorized copying of any part of this guide is prohibited.
- $\cdot$  Guide content subject to change without prior notice.

#### Data Communication

- · Handset is designed to be always connected to the Internet. Some functionality, such as data syncing, initiate transmission automatically.
- Large-volume data communication (application downloads, video viewing, etc.) incur expensive transmission fees. Subscription to a flat-rate data plan is strongly recommended.
- Depending on applications and services used, transmission fees may be incurred even while connected by Wi-Fi®.

#### Screenshots & Key Labels

Screenshots and Key labels are provided for reference only.

Actual handset windows, menus, etc. may differ in appearance.

## Other Notations


- $\cdot$  Xperia 5 II is referred to as "handset" in this guide.
- · In this guide, microSD™/microSDHC™/microSDXC™ Card is referred to as "SD Card."
- In this guide and on handset, "abroad" means "outside Japan" with regard to handset/service usage.

# Getting Started

Parts & Functions	O
SIM Card	7
SD Card	9
Charging Internal Battery1	2
Power On/Off1	2
Making Initial Settings1	3
Setting a Google Account1	5
Locking Screen19	9


# Parts & Functions

# Handset (Front)



Part	Description
1 Front Camera	Use to shoot still images, videos of yourself, etc.
2 Earpiece/ Speaker	Hear the other party's voice here.
3 Proximity/ Light Sensor	Detects surrounding brightness to automatically adjust Display or backlight and prevent Touchscreen misoperation during a call.
4 Notification Lamp	Flashes for notifications while Display is off. Lights while charging.
5 Display	Touchscreen-type display, operate with your fingers on Display.
6 Speaker	Listen to music as well as video, etc.

# Handset (Back/Side)




Part	Description
1 Second Mic	Reduces noise for calling.
2 Headphone Port	Connect commercially available headphones. This port supports tetrapolar headset that conforms to the CTIA standard.
<b>3</b> Wi-Fi Antenna Area	Internal Antenna for Wi-Fi.
4 Flash/ Photo Light	Use as camera flash when taking photos, etc.
<b>5</b> RGBC-IR Sensor	Automatically adjusts white balance based for shooting based on the light source.
6 5G/4G Antenna Area	Internal Antenna for calls and data communication.
7 5G/4G Antenna/Wi-Fi Antenna Area	Internal Antennas for calls, data communication, and Wi-Fi.
8 5G/4G Antenna/ Wi-Fi/GPS/ Bluetooth® Antenna Area	Internal Antennas for calls, data communication, and Wi-Fi, GPS, and Bluetooth features.
9 NFC/ Osaifu-Keitai® Detection Area	Hold up to a reader/writer to use NFC/ Osaifu-Keitai®.
10 Main Camera	Capture still images and videos.
11 SIM Card/ SD Card Slot	Insert SIM Card/SD Card.
12 USB Type- C™ Port	Connect USB Type-C cable (commercially available), etc.
13 Mic	Speak here.

## 👸 Using USB Type-C Port

Connect DisplayPort-compatible USB Type-C cable (commercially available) and show handset screen on a TV or computer monitor. Also, use a USB-LAN adapter (commercially available) and connect to the Internet with a wired LAN cable (Ethernet). Your USB Type-C cable, USB-LAN adapter, or access point device might not work in some instances.

#### Handset Keys



Part	Description
1 Volume/ Zoom Up/ Down Key	Adjust Volume. Adjust Zoom while using Camera.
2 Power Key/ Fingerprint Sensor	Long Press for power on/off. Turn Display on/off. Or, use Fingerprint authentication.
3 Google Assistant Key	Launch the Google Assistant.
4 Camera Key	Use as Camera shutter. Long Press to launch Camera.

### FCC ID

To view the regulatory compliance mark

· Find and tap Settings ( About phone )

Regulatory compliance mark such as FCC ID is displayed on the screen.

#### SIM Card

SIM Card is an IC card containing phone number and other customer information.

## Handling SIM Card

For SIM Card handling, see following items.



1 IC chip

For SIM Card handling, see SoftBank Website. https://www.softbank.jp/mobile/support/protect/usim/

(Japanese)

- · Always keep the IC chip clean.
- $\cdot$  Wipe clean with a dry, soft cloth.
- · Avoid applying labels. May damage SIM Card.

#### SIM Card Cautions

Observe the following when using SIM Card.


- Customer is responsible for any damage caused by inserting SIM Card in an other-brand IC card reader, etc.
   SoftBank Corp. is not responsible in such case.
- $\cdot$  SIM Card is the property of SoftBank Corp.
- $\cdot$  SIM is replaceable (at cost) in case of loss/damage.
- $\cdot$  Return SIM Card to SoftBank Corp. when cancelling subscription.
- Returned SIM Cards are recycled for environmental purposes.
- Note that SIM Card specifications and performance may change without notice.
- It is recommended that you keep a separate copy of information that is stored on SIM Card. SoftBank Corp. is not responsible for damages from stored information that is lost.
- · Always follow emergency procedures to suspend service if your SIM Card or handset (SIM Card inserted) is lost/stolen. For details, contact Customer Service.

#### Inserting SIM Card

Always unmount SD Card beforehand. For details, see "Unmounting SD Card."



Pull Tray out from handset



• Pull SIM Card/SD Card Slot Cover out straight using fingernail in groove.




Set SIM Card into Tray with IC chip (metal) facing down



- · Check SIM Card orientation by notch.
- $\cdot$  Make sure SIM Card is in Tray securely.



Holding handset held level, press Tray in straight





SIM Card is inserted.

- $\cdot$  Check Tray orientation.
- Press firmly where circled O, and make sure there is no gap between handset and SIM Card/SD Card Slot Cover.

### Removing SIM Card

Always unmount SD Card beforehand. For details, see "Unmounting SD Card."



Pull Tray out from handset



 $\cdot$  Pull SIM Card/SD Card Slot Cover out straight using fingernail in groove.




Remove SIM Card from Tray





Holding handset held level, press Tray in straight





SIM Card is removed.

- · Check Tray orientation.
- · Press firmly where circled O, and make sure there is no gap between handset and SIM Card/SD Card Slot Cover.

### SIM-Unlocking Handset

Handset can be SIM-unlocked. SIM-unlocking handset allows other-carrier SIM cards to be used with it.

- · Some services, functions, etc. may have restrictions when an other-carrier SIM card is used. SoftBank Corp. does not guarantee operation whatsoever.
- · For details, see SoftBank Website.

## SD Card

Handset supports SD Cards up to 1 TB. Some SD Cards may not operate properly.

When using a new SD Card for the first time, always format it on handset.

### SD Card Cautions

#### Data

Information stored on SD Card can become lost or changed accidentally or as a result of damage. It is recommended that you keep a separate copy of important data. SoftBank Corp. is not responsible for damages from data that is lost or changed.

#### Reading/Writing Data

Never power off while reading or writing data.

#### Battery Level

A low battery charge may prevent reading/writing to SD  $\mbox{\sc Card.}$ 

# Handling SD Card

Use/store SD Cards away from the reach of infants. May cause choking if swallowed.

### Inserting SD Card



Pull Tray out from handset



 $\cdot$  Pull SIM Card/SD Card Slot Cover out straight using fingernail in groove.




Set SD Card into Tray with metal terminals facing down




· Make sure SD Card is in Tray securely.



Holding handset held level, press Tray in straight





- · Check Tray orientation.
- · Press firmly where circled  $\bigcirc$ , and make sure there is no gap between handset and SIM Card/SD Card Slot Cover.

# Formatting SD Card

1

In Home Screen, (Settings)



2

#### [Storage]



3

#### SD card



4

.



5

#### Storage settings



6

## [Format]



7

#### FORMAT SD CARD



8

#### Done

All data on SD Card is erased.

### Cautions when Formatting SD Card

Observe the following when formatting SD Card.

- $\cdot$  Formatting erases all data on SD Card. Carefully check any SD Card that was used on another device before formatting.
- $\cdot$  Charge Internal Battery while formatting, or format with adequate battery charge.

### Unmounting SD Card

Always unmount SD Card before removing.

1

In Home Screen, (Settings)





2

[Storage]



3

for "SD card"




"Ejected" appears. SD Card is unmounted.

### Removing SD Card

Always unmount SD Card beforehand. For details, see "Unmounting SD Card."



Pull Tray out from handset



· Pull SIM Card/SD Card Slot Cover out straight using fingernail in groove.




Remove SD Card from Tray



3

Holding handset held level, press Tray in straight



- SD Card is removed.
- $\cdot$  Check Tray orientation.
- · Press firmly where circled  $\bigcirc$ , and make sure there is no gap between handset and SIM Card/SD Card Slot Cover.

# Charging Internal Battery

## Charging Cautions

Never connect USB Type-C plug while handset or peripheral equipment is wet.


#### Charging with AC Charger

Be sure to use an AC Charger specified by SoftBank. For information on AC Charger and other peripheral devices, see SoftBank Website.

Charging with AC Charger (USB Type-C<sup>™</sup> rapid charging AC Charger with USB PD capability [ZSDBAS] (SB-AC20-TCPD)) is described as an example.



Insert USB Type-C connector of AC Charger straight into USB Type-C Port



2

Unfold power plug of AC Charger and plug into household AC



Charging start sound sounds and Notification Lamp on handset lights up when charging starts.



When charging is complete, unplug AC Charger and remove USB Type-C connector of AC Charger straight from handset




Charging ends.

## Power On/Off

### Powering On



Long Press Power Key until handset vibrates once




- Lock Screen appears.
- · For details on unlocking screen, see "Unlocking Screen."
- Startup wizard appears for the first time handset is powered on. For details on initial settings, see "Making Initial Settings."
- · Battery level is not sufficient if Notification Lamp flashes red or low battery indicator appears when Power Key is Pressed with handset powered off. Charge Internal Battery.

# Powering Off



Long Press Power Key



2

#### Power off



🏁 Handset powers off.

# Making Initial Settings

When powering on the first time, an initial settings wizard appears for optionally making Wi-Fi, Google™ account, and other settings. Follow onscreen instructions to set items.

## Making Initial Settings







2

Set Important information 

Accept



3

Follow onscreen instructions to set Wi-Fi



• To skip Wi-Fi settings, Tap Use mobile network for setup . Continue by following onscreen instructions. 4

Follow onscreen instructions to transfer data



- ' To set up handset new, Tap Don't copy .
- To copy data from another handset on which a Google account is set, Tap Next, then follow onscreen instructions.



Follow onscreen instructions to set a Google account



- For details on Google accounts, see "Setting a Google Account."
- $^{\cdot}$  If not making Google account settings, Tap  $% \left( S_{i}\right) =S_{i}\left( S_{i}\right) =S_{i}\left($



Select items to set 

Accept





Follow onscreen instructions to set screen lock  $\ensuremath{\text{/}}$  unlocking using fingerprint



- · To not set, Tap Skip .
- · A screen lock is required after restarting handset, fingerprint is not recognized, etc. Do not forget to set.



Follow onscreen instructions to set Google Assistant/Voice Match/Google Pay





## [Continue]



· To complete setup later, Tap Leave & get reminder .









Follow onscreen instructions make other settings





#### FINISH)



Settings are complete.

# Setting a Google Account

Use a Google account and get more convenience with Google services. A Google account is required to use some services or fully use some applications.

Google Account Cautions

Be careful not to forget your Google account mail address or password.

## Creating a Google Account

1

In Home Screen, (Settings)



2

#### (Accounts



3

#### Add account



4

#### [Google]



- Window for logging in to a Google account opens.
- · If fingerprints are already saved, screen for fingerprint authentication may appear. Hold finger to sensor to authenticate fingerprint.
- · If method for unlocking screen is "Pattern" / "PIN" / "Password," screen for unlocking screen lock may appear. Enter method for unlocking screen.

5

#### Create account



6

#### For myself



 To create a child's account, Tap For my child then follow onscreen instructions.



Enter First name 

→ Last name 
→ Next



 $\cdot$  If confirmation appears, follow onscreen instructions.



Enter date of birth  $\Rightarrow$  Select gender  $\Rightarrow$  Next



9

Select Gmail™ address 🗦 Next



• To create a Gmail address, Create your own Gmail address → Enter username (mail address) → Next .



Enter password Enter password again (for confirmation)





11

Yes, I'm in



- ' To not add a phone number, Tap Skip .
- To add a phone number only for security protection, Tap

  More options . Continue by following onscreen instructions.



Next



13



A Google account is created.

14

Set Google service (a) (Accept)



Account is created.

# Logging In with a Google Account



In Home Screen, (Settings)



2

## Accounts



3

# Add account





### [Google]



Window for logging in to a Google account opens.

- If fingerprints are already saved, screen for fingerprint authentication may appear. Hold finger to sensor to authenticate fingerprint.
- · If method for unlocking screen is "Pattern" / "PIN" / "Password," screen for unlocking screen lock may appear. Enter method for unlocking screen.



In window for logging in to Google account, enter mail address ( Next)



6

Enter password 
Next





Follow onscreen instructions



You are logged in to your Google account.

# Locking Screen

### Screen Lock

Display goes out after a set period of inactivity to save battery power (screen lock).

This also prevents accidental Touchscreen operation.

While Display is off (screen is locked), Press Power Key for Lock Screen.



 $\cdot$  To activate Screen lock manually, Press Power Key when Display is turned on.


# When Screen Locks during Music Playback

Music playback continues. While Display is off (screen is locked), Press Power Key for music panel in Lock Screen. Use pause, next song, etc. (operation may differ with application).

## **Unlocking Screen**



While Display is off (screen is locked), Press Power Key



- Lock Screen appears.
- Alternatively, if Ambient display is enabled, Double-Tap Ambient screen or Press Power Key. For details on Ambient display, see "Appearance Settings."



Flick screen up



- Screen is unlocked.
- $\cdot$  The method for unlocking the screen can be changed.
- · For fingerprint authentication, Touch Fingerprint Sensor with authentication finger to unlock screen.

# Basic Operations

Basic Operation	22
Using Touchscreen	22
Silent Mode	23
Airplane Mode	24
Text Entry	25
Undating Software	26

# **Basic Operation**

# Selecting Options and Navigating Screens

Tap items, icons, onscreen keys, etc. to open assigned items.

• Tap 🚺 to go back to previous screen.



## Menu Operations

1

Tap **•** for available settings and items.



2

Screens may also have settings and items that are available by Touching & Holding Display.



# Using Touchscreen

Handset uses a touchscreen-type Display. Operate with your fingers on Display.




Contact Display lightly and briefly.




### Touch & Hold

Touch screen lightly and hold it for a while. When the screen changes, release finger.




### Drag

Touch icon or other item lightly, move it where desired, and release finger.




### Swipe/Flick

Contact Display lightly, then brush screen up/down or left/right.



### Pinch/Spread

Contact Display lightly, then close/widen fingers.



# Silent Mode

Set ringtone, operation sounds, etc. not to sound to avoid disturbing others around you.


Silent Mode Cautions

Camera shutter, video start/stop tones, Alarm, etc. sound even in Silent mode.

# Entering Silent Mode (Vibrate)

1

Press Volume Up or Down Key



2

Δ



- Icon changes to  $\ensuremath{\blacksquare}$  , and handset enters Silent mode (vibrate).
- Tap Silent mode icon to toggle between  $\P$ ,  $\c \lambda$ , and  $\c \Delta$ .
- Entering from Quick Settings


Also use Quick Settings to enter Silent mode (vibrate).

Flick Status Bar down 🔵 🙆 ( 💿 )

## Entering Silent Mode (No Vibrate)

1

Press Volume Up or Down Key



2

Δ



lcon changes to  $\blacksquare$ , and handset enters Silent mode (vibrate).

3

While volume adjustment bar is shown,



Icon changes to  $\mbox{\ensuremath{\upoline{\lambda}}}$  , and handset enters Silent mode (no vibrate).

Tap Silent mode icon to toggle between  $\P$ ,  $\mbox{$\stackrel{\searrow}{\bf Q}$}$ , and  $\mbox{$\stackrel{\frown}{\bf Q}$}$ .

## ■ Entering from Quick Settings

Also use Quick Settings to enter Silent mode (no vibrate). Flick Status Bar down  $\bigcirc$   $\bigcirc$   $\bigcirc$   $\bigcirc$   $\bigcirc$   $\bigcirc$   $\bigcirc$   $\bigcirc$ 

# Airplane Mode

Disable all functions that emit signals. Handset stays powered on.

# Using Airplane Mode



Flick Status Bar down



2





🏁 Handset is in Airplane mode.

 $\cdot$  Use same operation again while in Airplane mode to cancel.

# Text Entry


#### Keyboards

Enter text with onscreen QWERTY keyboard by Tapping each character individually, or by using Glide typing feature and sliding finger from character to character (on by default). Touch & Hold each character for extended characters.

- · Tap 🔽 to hide keyboard.
- Keyboard Operations



### QWERTY Keyboard Layout



- 1 Use the keyboard option menu.
- 2 Show the search bar.
- 3 Enter a character. Touch & Hold character to show variant options.
- 4 Switch between all lower case and sentence case. Double-Tap for all upper case.
- 5 Toggle entry modes.
- 6 Use voice input.
- 7 Delete a character before cursor.
- or appears depending on application.
- 9 Enter a comma. Touch & Hold for text entry settings or to set one-handed mode. With several set keyboards, Touch & Hold ; for emoji, emoticons, etc.
- 10 Show emoji / stickers / GIFs / emoticons. With several set keyboards, Touch & Hold 📵 to switch between keyboards.
- 11 Enter a space.

#### Switching Character Types (Entry Modes)

In QWERTY keyboard, Tap 723



- Entry mode is changed to number and symbol mode.
- · To enter more symbols, Tap □ .
- · Tap ABC to back to alphabet mode.

# **Updating Software**

Steps to update software depend on what is being updated in the software.

## Software Update Cautions

#### Signal Reception

Operate handset where signal reception is good and without changing location. Also operate with adequate battery charge. Signal becoming weak or Internal Battery becoming low during an update may cause an update failure. An update failure may disable handset.

#### Saved Data/Settings

Saved data may be lost depending on condition of handset (malfunctioning, damaged, water exposure, etc.). SoftBank Corp. is not responsible for damages from loss of data. Updating software may revert some settings to their defaults.

#### SIM PIN

If SIM PIN is enabled, a SIM PIN entry window appears after software is updated. Enter SIM PIN.

## **Updating Software Automatically**

Update software automatically.

When the update is complete, Tap the notification in the Notifications Window and restart handset.

## Updating Software Manually

Tap the software update notification in the Notifications Window and follow onscreen instructions. Alternatively:



In Home Screen, (Settings) (System (Advanced)











#### System update



#### Follow onscreen instructions



Software update starts.

# Handset Interface

Handset Screens	28
Status Bar	29
Using Notifications Window	30
Using Quick Settings	31

## Handset Screens

### Layout



Item	Description
1 Status Bar	Flick down for Notifications Window. Continue and Flick screen down for Quick Settings.
2 Customize	Place application shortcuts, folders,
Area	widgets freely.
3 Dock	Place shortcuts (applications), folders, etc. Appears even when Home Screen sheets toggled.
4 Navigation	Tap icons to access functions. For
Bar	Navigation Bar, see "Navigation Bar."
5 Side Sense	Open Side Sense menu and Multi Window
Bar	menu, return, etc.
6 Quick	Search for applications or search <b>ⓒ</b>
Search Box	(Google) with entered words and phrases.

## Toggling Home Screen Sheets

Customize each Home Screen sheet with application shortcuts, widgets, etc. to make handset more convenient. Flick Home Screen left/right to toggle sheets.

· In any Home Screen sheet, Tap to return to Home Screen top sheet.



### Navigation Bar

Tap icons on Navigation Bar (Display bottom) for the following functions/operations.

Also use gesture action. For details, see "System Settings."



Item	Description
(Back)	Return to previous screen. Appears as   ✓ for onscreen keyboard; Tap to close keyboard.
(Home)	Tap for Home Screen. Touch & Hold for Google Assistant.
(History)	Show thumbnails of recently used applications to activate/exit them.
□ (To landscape orientation) / □ (to portrait orientation)	Appears when handset and screen orientations are different. Tap the for horizontal orientation, and the for vertical orientation.

# Portrait Orientation & Landscape Orientation

ightharpoonup appears on Navigation Bar when handset is rotated sideways. Tap ightharpoonup to change screen to landscape orientation. To change to portrait orientation, rotate handset vertically and Tap ightharpoonup.

Set "Auto-rotate screen" to on to change screen to landscape orientation automatically when handset is rotated horizontally. For details on Auto-rotate screen, see "Display Settings."

• Depending on the current screen, the orientation may not change even by changing handset orientation.



# Status Bar

Status Bar appears at the top of Display. Notification Indicators for new mail, etc. and Status Indicators for handset appear here.

# Status Bar Layout



- 1 Notification Indicators
- 2 Status Indicators

### Main Notification Indicators

Notification Indicators appearing in Status Bar include the following.

Indicator	Description	
×	Missed Call	
L	Call Arriving/Calling/Dialing	
<u>u</u>	Call on Hold	
<u>o</u>	New Recorded Message	
<u></u>	New Voicemail	
M	New Gmail	
<b>©</b>	New Text Message (SMS) / S! Mail / +Message	
A	Urgent News, Etc.	
₹?	Wi-Fi Open Network Available	
ψ	USB Device Connected/Moisture Detected in USB Type-C Port	
*:	Sharing File via Bluetooth	
1	Data Uploading	
Ū	Data Downloading	
<b>&gt;</b>	Application Update Available	
<u> </u>	Screenshot Saved	
<b>√</b>	Linked to Dynamic Vibration	
<b>!</b>	Playing Back Music	
31	Calendar Event Reminder	
<u></u>	Alarm Sounding/Snoozing/Unchecked Alarm/Next Alarm	
Ō	Stopwatch in Use	
X	Timer in Use	
1	Low Battery Alert (15% or less)	
	SD Card Detected/Mounting/Unmounting	
0	Software Update Notice, Downloading Complete, Stopped	

### Main Status Indicators

Status Indicators appearing in Status Bar include the following.

Indicator	Description
	Battery Full (100%)
3	Battery Charging
	Battery Low
	STAMINA® Mode
	Signal Strength
5 <b>G ∕∕I</b> †	5G Data in Use
4G <b>11</b> †	4G LTE/4G Data in Use¹
3 <b>G ∕∕I<sup>‡</sup></b>	3G Data in Use
.11 <sup>†</sup>	No Signal
<b></b>	Airplane Mode
<b>;</b> ₹	Wi-Fi Connected
a=+	Wi-Fi Connected without Internet Accessibility, or Unstable Wi-Fi Signal
*	Bluetooth Connected
' <b>-</b>	Silent Mode (vibrate)
Ø	Silent Mode (no vibrate)
Θ	Do Not Disturb <sup>2</sup> On
0	Obtaining Current Location

- 1 Handset supports FDD-LTE (SoftBank 4G LTE) and AXGP (SoftBank 4G); indicator appears when handset is connected to either. Handset connects to SoftBank 4G first
- 2 For details on Do Not Disturb, see "Sound Settings."

# Using Notifications Window

Check Notification Indicators and the details in Notifications Window.

# Opening Notifications Window



Flick Status Bar down



- Notifications Window opens.
- Closing Notifications Window

Flick Notifications Window up

· Alternatively, Tap 🚺 to close Notifications Window.

### Notifications Window Layout



- 1 Show portion of Quick Settings
- 2 Show notifications set as alerts (sound and vibration) and active functions
- 3 Use notification details1
- 4 Show silent notifications
- 5 Manage notifications<sup>2</sup>
- 6 Delete all notifications<sup>3</sup>
- 7 Show in Multi-WIndow<sup>4</sup>
- 1 Available applications depend on notification. Example:with call notification, dial/send SMS to phone number that call was from.
- 2 Notification may not be manageable depending on application or function.
- 3 Deletion may not be possible depending on notification details.
- 4 Icon may not appear depending on notification details.


#### Notifications Window Operations

#### Setting Notifications Not to Appear

In Notifications Window, Touch & Hold notification to set









#### Changing Notification Types

Change between alert (sound and vibration) and silent

In Notifications Window, Touch & Hold notification to change 🔷 (Alerting) / (Silent) 🔷 (Done)

# Using Quick Settings

Tap icons to toggle functions on/off, etc.

# Opening Quick Settings



Flick Status Bar down



Flick screen down



- Quick Settings opens.
- · Alternatively, Flick Status Bar down using two fingers.

#### Quick Settings

#### Closing Quick Settings

Flick Quick Settings up

· Alternatively, Tap 


to close Quick Settings.

#### Arranging Quick Settings

Add, delete, and change order of functions in Quick Settings.

In Quick Settings, / 👂 Follow onscreen instructions and Drag icon

# Quick Settings Layout



- 1 Show current alarm setting, Silent mode, etc.
- 2 Adjust brightness
- 3 Wi-Fi on/off
- 4 Bluetooth on/off
- 5 Enter/exit Airplane mode
- 6 Silent mode (vibrate) / Silent mode (no vibrate) / Silent mode (off)
- 7 Flashlight on/off
- 8 STAMINA mode on/off
- 9 Add, delete, and change order of Quick Settings
- 10 Auto-rotate screen on/off
- 11 Location on/off
- 12 Tethering on/off
- 13 Show handset settings
- 14 Dolby Atmos on/off

# Phone

Placing/Answering Calls	34
Optional Services	36
Phone Number	42
Using Contacts	43

# Placing/Answering Calls

#### Phone Function

#### **Emergency Location Report**

Making emergency calls (110, 119 or 118) automatically reports handset location to corresponding agency (police, etc.). This system is referred to as Emergency Location Report, and notifies location based on positioning from base stations.

- · Location Report does not incur registration/transmission fees.
- $\cdot \ Location/signal \ conditions \ affect \ positioning \ accuracy.$ Always provide location and call purpose.
- · Hiding Caller ID (using 184, etc.) cancels Location Report. However, corresponding agency may obtain location information in life threatening situations.
- · Location Report is not sent for calls made while outside Japan.

#### VoLTE/VoLTE (HD+) and HD Voice

Handset supports VoLTE/VoLTE (HD+) and HD Voice for higher voice call quality.

#### Hints

- Q. Difficulty during call
- A. It may not be possible to make a call properly in a noisy location.
- A. When calling using Speaker, check the call volume. Raising the call volume may make calling difficult.
- Q. Sound pops momentarily during a call
- A. Are you changing location while calling? Sound pops when signal is weak and handset switches to a different area.

## **Emergency Call Cautions**

Emergency calls from handset can be made only in SoftBank service areas.

### Placing Calls

In Home Screen,



(Phone)



- Phone opens.





- Dialing screen opens.

Tap dialpad to enter the other party's number



· Enter area code first for calling landline numbers.

4





Handset dials number. Call begins when other party answers.



To end the call,



Call ends.

Calling the Emergency Number When the Phone's Screen is Locked



#### ? Hints

- Q. Call does not connect
- A. Was the number dialed using the area code? Dial the number starting with "O."
- A. Are conditions for calling poor? Call again after moving where signal is good.

## Answering Calls



Swipe (Flick) up when call is arriving



Call begins.



To end the call,



Call ends.

Arriving Call Operations

## Cancelling Ringtone

Press Volume Key or Power Key when call is arriving

#### Rejecting Arriving Calls

Swipe (Flick) odown when call is arriving

## In-Call Screen Layout/In-Call Operations



- 1 Show image registered for contact
- 2 Show name/number registered for other party
- 3 Appears for high-quality sound calls <sup>1</sup>
- 4 Show dialing screen and send push signals during call
- 5 Mute your voice to the other party
- 6 Add call
- 7 Show call time
- 8 Call using Speaker/Bluetooth device
- 9 Place call on hold
- 10 End call
- 1 Appears HD) for calls with HD Voice, and HD+ for calls with VoLTE (HD+).

## **Optional Services**

Use the following optional services.

#### Optional Services

Use the following optional services.

Service	Description
Call Forwarding	Divert calls to a preset number when out of service area or unable to answer.
Voicemail	Divert calls to a Voicemail Center to take messages when out of service area or unable to answer.
Call Waiting <sup>1</sup>	Answer calls during a call.
Group Calling <sup>1</sup>	Merge multiple calls.
Caller ID notification / display	Send or hide your number when placing calls.
Outgoing Call Barring / Incoming Call Barring	Restrict incoming/outgoing calls by conditions.

1 Requires separate subscription.

## Using Call Forwarding

1

In Home Screen, (Phone)



2





3

#### Voice Mail / Call Forwarding



Voice Mail / Call Forwarding settings open.

4





5

Ring Time 🔵 Select ring time



6





7

#### (CONFIRM)



Call Forwarding is activated.

## Using Voicemail

1

In Home Screen, (Phone)



2



3

## Voice Mail / Call Forwarding



Voice Mail / Call Forwarding settings open.

4

Voice Mail / Call Forwarding 🗦 [Voice Mail ON]



5

Ring Time 🔵 Select ring time



6

## (CONFIRM)



- Voicemail is activated.
- ac appears in Status Bar for new message. Flick Status Bar down and Tap Voicemail notification, then follow the voice prompts.

#### Using Call Waiting

This service requires subscription.

1

In Home Screen, (Phone)



2

**⋮ ⇒** Settings **⇒** Calls **⇒** Call service settings



3

for Call Waiting ( )



- Call Waiting is set.
- · Tap icons to toggle set ( )/cancel ( ).
- · If Call Waiting is set and a second call arrives during a call, Call Waiting tone is heard. Swipe (Flick) © up to begin call.

#### Using Group Calling

This service requires subscription.

1

During a call, Add call



Dialing screen opens.



Enter phone number 🔵 🕓



Call is added.

3

When the other party answers, Merge



Group Calling starts.

## Using Caller ID Notification

1

In Home Screen, (Phone)



2

Settings Calls



🔀 Call settings open.

3

Caller ID → Hide number / Show number



Caller ID notification is set.

## Using Outgoing Call Barring

Restrict calling/SMS.

1

In Home Screen, (Phone)



2



3

Outgoing Call Barring



4

Tap outgoing restriction



- Outgoing Call Barring is set.
- · To disable Outgoing Call Barring, Tap Stop Barring of Outgoing Call).

## Using Incoming Call Barring

Restrict incoming calls.

1

In Home Screen, (Phone)





2











3

[Incoming Call Barring]





Tap incoming restriction



- Incoming Call Barring is set.
- · To disable all Incoming Call Barring, Tap Stop Barring of Incoming Call .

## Phone Number

Checking Your Phone Number



In Home Screen, (Settings)





2

# (About phone)



Your phone number appears below Phone number field.

## **Using Contacts**

Save phone numbers, mail addresses, etc. to Contacts.

## Contacts Cautions

Information saved in Contacts may be lost or changed if Internal Battery is left uncharged for a long period. Accident or malfunction may also cause loss or change to information. It is recommended that you keep a separate copy of contacts and other important information. SoftBank Corp. is not responsible for any damages from lost or changed contacts.

#### Adding New Contacts

1

In Home Screen, 🛞 (Google)



2

(Contacts)



Contacts appear.

3





 $\cdot$  If confirmation appears, follow onscreen instructions.



Enter items 
Save



Contact is added.

## ■ Saving Contacts from Dialing Screen

Save a number entered in dialing screen directly to Contacts.

In Home Screen, (Phone) (Phone) Tap dialpad to enter number to save (Create new contact) Enter each item (Save)

Tap More details (More fields) to enter other items for contact.

# Messaging

Sendir	ig Messages	(+Message)	46
Using	Gmail		47

## Sending Messages (+Message)

Sending New Messages

1

In Home Screen, (+Message)













4

New message






Tap destination



- Message window opens.
- $\cdot$  To send to a phone number/email address not saved in contacts, Tap destination entry field at top of Display  $\Rightarrow$  Enter phone number/email address  $\Rightarrow$  Add and create message.



Tap message entry field



Enter message 🗦 🦻



Message is sent.

## Using Gmail

Use Google's webmail service. Use this service to exchange email.

## Creating/Sending Mail



In Home Screen, 💝 (Google)



2

(Gmail)



Mail list opens.

3





Mail composition window opens.




Enter recipient/subject/mail text ♦ ▶



Message is sent.

Operations when Composing Mail



# Internet

Usina	Chrome	50	۱
OJIIIG			

## **Using Chrome**

Use Chrome simply by entering words to search and URLs.

TLS

TLS (Transport Layer Security) is a protocol for encrypting sent/received data. While in a screen connected by TLS, data is encrypted to safely send/receive private information, credit card numbers, corporate secrets, etc., and provide protection against online threats (eavesdropping, falsification, impersonation, etc.).

#### TLS Cautions

When opening a secured page, users must decide as their responsibility whether or not to open the page with use of TLS. SoftBank Corp. and the Certification Authorities Symantec Website Security G.K. and Cybertrust make no guarantees whatsoever to users regarding security of TLS.

## Using Chrome

1

In Home Screen, (Chrome)



- Chrome opens.
- · If confirmation appears, follow onscreen instructions.

2

Tap entry box at top



3

Enter words to search or URL 🔵 🗖





Search results appear or a Website opens.

### Opening New Tabs

Open several tabs to switch between Websites easily.

· To switch between tabs, Tap ② next to entry field at top of Display and Tap tab (number in icon indicates opened tabs).

#### Adding Bookmarks

1

In Home Screen, (Chrome)



Chrome opens.

2

Show Website to add



3

:



4





Current Website is added to Bookmarks.

### ■ Bookmark Operations



# Camera

Capturing S	till Im	ages/Video	S		54
Viewina Sti	ll Imaq	es/Videos	(Photos)	)	55

## Capturing Still Images/Videos

## Capturing Still Images/Videos

#### File Format for Still Images

File format for still images is JPEG.

#### File Format for Videos

File format for videos is MPEG-4.

#### Camera Cautions

#### If Lens Becomes Dirty

Fingerprints/smudges on lens prevent capturing of clear still images/videos. Wipe lens with a soft cloth beforehand.

#### Avoid Exposure to Direct Sunlight

Be careful not to expose lens to direct sunlight for long periods. May discolor color filter and affect color of images.

## Flash/Photo Light Warning

Do not shine Flash/Photo Light close to eyes. Do not look at Flash/Photo Light directly while in use. Do not shine Mobile Light at other people's eyes. May affect eyesight,

#### Capturing Still Images

In Home Screen, 
(Camera)



## 🔀 Viewfinder appears.

- · If confirmation appears, follow onscreen instructions.
- · Alternatively, Long Press Camera Key for one second or more, or Press Power Key twice, or in Lock Screen, Swipe (Flick) upward to the left to quick-activate Camera.
- · If there is no operation on Viewfinder, Camera operation ends.

2

Swipe (Flick) Viewfinder to switch to "PHOTO" Viewfinder



· Swipe (Flick) up or down in a landscape viewfinder, or left or right in a portrait viewfinder.



Aim Camera at subject  $\bigcirc$  Check Viewfinder, then  $\bigcirc$ 









Shutter clicks and still image is saved.

#### Capturing Videos

In Home Screen,





#### Viewfinder appears.

- · If confirmation appears, follow onscreen instructions.
- · Alternatively, Long Press Camera Key for one second or more, or Press Power Key twice, or in Lock Screen, Swipe (Flick) upward to the left to quick-activate Camera.
- $\cdot$  If there is no operation on Viewfinder, Camera operation ends.

2

Swipe (Flick) Viewfinder to switch to "VIDEO" Viewfinder



· Swipe (Flick) up or down in a landscape viewfinder, or left or right in a portrait viewfinder.

3







Video capturing starts.

· To pause, Tap (II) or to resume, Tap ( •).

4

To stop recording,



Video capturing stops and video is saved.

## Viewing Still Images/Videos (Photos)

## Showing Still Images/Videos

Show captured or downloaded still images/videos. Supported file formats with Photos are as follows.

Туре	File Format
Still image	BMP, GIF, HEIC, ICO, JPG, PNG, TIFF, WEBP, some Raw files
Video	3GP, 3G2, ASF, AVI, DIVX, M2T, M2TS, M4V, MKV, MMV, MOD, MOV, MP4, MPG, MTS, TOD, WMV

In Home Screen, (Photos)





🔀 Still image/video list opens.

Tap still image/video



Still image/video window opens.

- · Tap still image/video window to show/hide menu and other icons.
- $\cdot$  Flick still image/video window up to show captured date &
- · To select other files, in still image/video window, select file again or Flick still image/video window left or right.

## Zooming In or Out Still Image

In still image window, Tap Display twice or Pinch

# Application Basics

Applications	58
Adding Applications	59

## **Applications**

# Setting Required Permissions for Applications

Set the operation of applications when activating for the first time.

The type and content of a confirmation differs with the application. Activating (Photo Pro) for the first time is described as an example.

· An application may not function correctly if permission to use it was not set.



In Home Screen, (Photo Pro)





## (ALLOW



- Settings are complete.
- $\cdot$  In permission screen for Location function, appears as "ALLOW ALL THE TIME" / "ALLOW ONLY WHILE USING THE APP."
- $\cdot$  For several functions, continue in the same way.
- Other Ways to Set Required Permissions for Applications

Setting Functions to Use for Each Application

In Home Screen, (a) (Settings) (b) Apps (a)

Notifications (c) SEE ALL XX APPS (c) Tap application

Permissions (c) Tap function (c) Allow / Deny

After Tapping "Location" in a function, Tap (Allow all the time / Allow only while using the app / Deny).

## 

## Adding Applications

Download a variety of applications (free/paid) from Google Play™. Change the setting of downloaded applications to enable manual or automatic updates. Log in to your Google account beforehand.

## Installing Applications

Many different kinds of applications can be installed on handset from Google Play (provided by Google LLC). SoftBank Corp. is not responsible in any way for userinstalled applications (quality, reliability, legality, fitness for a purpose, credibility, accuracy, etc.) or resulting malfunctions (viruses, etc.).

## Installing Free Applications

1





Google Play appears.

 $\cdot$  If confirmation appears, follow onscreen instructions.


2

Tap free application



3

[Install]



Application is downloaded and installed.

 $\cdot$  If confirmation appears, follow onscreen instructions.

## Purchasing Paid Applications



In Home Screen, (Play Store)



- 🔀 Google Play appears.
- · If confirmation appears, follow onscreen instructions.



Tap paid application



3

Tap amount



- · If confirmation appears, follow onscreen instructions.
- · If purchasing for the first time, Tap Continue and follow onscreen instructions to add payment method.



Buy



- $\cdot$  If confirmation appears, follow onscreen instructions.
- 5





Application is downloaded and installed.

## Purchased Applications

#### Payment


Pay only once. Redownloads of uninstalled applications are free of charge.

#### On Other Android Devices

Install an application on any Android device under the same Google account for free.

#### Requesting Refunds

Refund is possible within a limited time. By requesting a refund, the application is deleted and the charge is cancelled. A refund request is valid only once per one application.



## Purchasing Applications

Purchase applications at your own risk. SoftBank Corp. is not responsible for any disadvantage resulting for user or third parties.

#### **Updating Applications**

1

In Home Screen, (Play Store)




- Google Play appears.
- · If confirmation appears, follow onscreen instructions.







- Application is updated.
- $\cdot$  If confirmation appears, follow onscreen instructions.
- Setting Application Updates



# Wi-Fi/Bluetooth

Connecting	by	Wi-Fi	64
Using Bluet	ootl	h Function	65

## Connecting by Wi-Fi

Handset supports Wi-Fi (wireless LAN). Access the Internet via a household Wi-Fi connection environment.

Automatic Updates for Optimizing Wi-Fi Connection

While using Wi-Fi, updates for optimizing connection may be received or applied automatically.

## Selecting a Network Connection

1

In Home Screen, (Settings)



2

### Network & internet



3

#### Wi-Fi



🟁 Wi-Fi open.

4

Use Wi-Fi ( )



Wi-Fi is enabled.

- Wi-Fi networks are scanned. Available networks appear after scanning.
- · Tap Use Wi-Fi to toggle on ( )/off ( ).



#### Tap Wi-Fi network



6

Enter password ( CONNECT )



- Handset is connected.
- · Alternatively, Tap ## at right of box for entering password Center a QR code in screen to scan and connect to a Wi-Fi network.
- The password, for a household wireless LAN router, is sometimes found on a sticker on the router (WEP, WPA, KEY, etc.). Contact the router manufacturer for information.
   For password for a public wireless LAN, check with user's service provider.
- Entering a password is not required if an access point is not security protected.

## Using Bluetooth Function

Connect to a Bluetooth-capable wireless phone, etc. for calls or to a hands-free device such as a headset.

- ? Hints
- Q. Cannot use Bluetooth
- A. Is handset in Airplane mode? Bluetooth turns off in Airplane mode. Turn on Bluetooth enable in Airplane mode.
- Bluetooth Function Cautions

Information may not appear correctly on both devices depending on the transferred data.

#### **Enabling Bluetooth Function**

1

In Home Screen, (Settings)



2

Device connection



Screen for connecting device opens.

3

Connection preferences



4

[Bluetooth]



- Bluetooth settings open.
- 5





- Bluetooth function is enabled.
- · To disable Bluetooth function, Tap On ( ).

# Handset Settings

Handset Settingsb	ρδ
Data Usage Settingsε	59
Battery Settings7	70
Display Settings7	70
Sound Settings7	71
Security Settings7	71
System Settings7	73
Other Settings 7	73

# Handset Settings

Main setting options are described.

Shown items and their arrangement may differ depending on current settings, etc.

## Handset Settings

Customize operation of handset functions. Handset settings include the following items.

Item	Description
Network & internet	Make network and Internet settings for Wi-Fi, mobile networks, etc.
Device connection	Make connection settings to other devices, such as Bluetooth connection and NFC/Osaifu-Keitai® settings.
Appearance	Set wallpaper, ambient display, clock design, etc.
Apps & notifications	Make application and notification settings.
Battery	Check Battery usage and make settings to save battery power.
Display	Set screen brightness, font size, etc.
Sound	Set ringtone, touch sounds, etc.
Storage	Check internal and SD Card storage, mount SD Card, and delete SD Card data.
Privacy	Make privacy settings such as application permissions and showing passwords.
Location	Make Location settings.
Security	Set security functions such as screen lock, PIN, etc.
Accounts	Create accounts as well as add, sync, etc.
Accessibility	Set captions, magnification gestures, and other useful accessibility functions.
Digital Wellbeing & parental controls	Manage time that handset is used, set parental limitations on use, etc.
Google	Make settings for Google services.
System	Check and make settings for languages & input, gestures, date & time, backup, reset, system update, etc.
About phone	Check device name and own phone number, save emergency information, etc.



In Home Screen, **(Settings)** 



🏁 Handset settings open.

2

Select item to set




Settings open.

## Data Usage Settings

Check mobile data traffic and set limit.

Data Usage Operations



## Data Usage Settings

1





2



Mobile network

3



Mobile data usage window opens.

## **Battery Settings**

Check Battery usage and make settings to save battery power.

## Battery Settings

Items that can be checked/set are the following.

Item	Description
Battery level and estimated time until depletion <sup>1</sup>	Check Battery and time remaining based on current usage.
Apps are running normally <sup>1</sup>	Battery usage, etc appear.
STAMINA mode	Save Battery by limiting heavy- consumption functions such as background communication and some visual effects.
Battery Care	Keep Battery better and longer performing. Set handset to learn charging habits (long time periods where connected to charging equipment) and adjust charging speed.
Adaptive Battery	Limit Battery usage of seldom-used applications.
Battery percentage	Enable battery level to be shown in Status Bar.
Last full charge	Check time elapsed since last full charge.
Screen usage since full charge	Check Battery usage by screen since a full charge.

<sup>1</sup> Screen view may differ depending on usage.

# Display Settings

Set screen brightness, font size, etc.

## Display Settings

Settings can be made for the following items.

Item	Description		
Image quality settings	Make settings for color gamut, contrast, and high-quality processing when playing back videos.		
White balance	Set white balance.		
High refresh rate	Enable smooth screen rendering.		
Brightness level	Set brightness of Display.		
Adaptive brightness	Enable adjustment of brightness for surroundings.		
Screen timeout	Set a period of inactivity after which Display turns off automatically.		
Font size	Set size of font for Display.		
Display size	Set the size of images, icons, etc. in Display.		
Dark theme	Enable a dark theme.		
Auto-rotate screen	Enable Display to rotate with handset orientation automatically.		
Lock screen display	Make settings for ambient display, clock design, lock screen message, notifications, etc.		
Side sense <sup>1</sup>	Set Side sense.		
One-handed mode <sup>1</sup>	Double-Tap  then set smaller screen area.		
Smart backlight control <sup>1</sup>	Set backlight to remain on even without any Tap operation while holding handset.		
Night Light <sup>1</sup>	Set a night light.		
Prevent accidental operations with screen off <sup>1</sup>	Enable handset to prevent misoperation (unintended keypress, screen operation) when in a pocket or bag.		

1 Appears after Tapping "Advanced."

## Sound Settings

Set ringtone, touch sounds, etc.

### Sound Settings

Settings can be made for the following items.

Item	Description
Audio settings	Set for sound.
Media volume	Adjust media volume.
Dynamic Vibration	Add vibration when playing back movies, videos, and music for an enhanced experience.  During playback with a supporting application, Press Volume Key for volume adjust bar to adjust vibration. Muting media volume also turns Dynamic Vibration off.
In-call volume	Adjust call volume.
Ring and notification volume	Adjust ring volume and notification sound.
Alarm volume	Adjust alarm volume.
Vibrate for calls	Enable vibration for ringtone.
Do Not	Enable/disable Do Not Disturb. Also make
Disturb	Do Not Disturb settings.
Phone ringtone	Set phone ringtone.
Notification sound	Set notification sound.
Default alarm ringtone	Set alarm ringtone.
Dial pad	Enable confirmation tones when Dialpad
tones <sup>1</sup>	Tapped.
Screen locking sounds <sup>1</sup>	Enable tone when locking or unlocking screen.
Charging sounds and vibration <sup>1</sup>	Enable tone when charging starts.
Touch sounds <sup>1</sup>	Enable tones for Tap operation.
Touch vibration <sup>1</sup>	Enable vibration for (home), keyboard operation, etc.

1 Appears after Tapping "Advanced."

## Security Settings

Set security functions such as screen lock, PIN, etc.

Setting Screen Not to Lock



## Security Settings

Settings can be made for the following items.


Item	Description
Google Play Protect <sup>1</sup>	Enable regular scanning of handset to check for security threats.
Find My Device <sup>1</sup>	Set Find My Device on/off and check method for finding handset.
Security update <sup>1</sup>	Check for system updates.
Google Play system update <sup>1</sup>	Check for Google Play system updates.
Screen lock	Set method for unlocking screen.
Fingerprint Manager	Set fingerprints.
Smart Lock	Set conditions for automatically unlocking screen when method for unlocking screen is "Pattern" / "PIN" / "Password."
Device admin apps	Enable/disable handset management applications.
SIM card lock	Make settings for SIM Card lock.
Encryption & credentials <sup>2</sup>	Make settings for encryption and credentials.
Trust agents <sup>2</sup>	Enable/disable Trust agents.
Screen pinning <sup>2</sup>	Set to keep only screen of specified application in view. When set to ON, pinned screen cannot be moved.

- 1 Screen view may differ depending on usage.
- 2 Appears after Tapping "Advanced."

## Enabling SIM PIN

When PIN is enabled, a window for entering PIN appears to allow handset use each time handset is powered on with SIM Card installed.











PIN is enabled.

#### PIN Cautions

Entering incorrect PIN three consecutive times activates PIN Lock. To cancel, Personal Unblocking Key (PUK) is required; contact Customer Service. Entering incorrect PUK ten consecutive times locks SIM Card, disabling handset. For recovery, SIM Card must be reissued at a SoftBank Shop (fees apply).

### Changing SIM PIN

First enable SIM PIN to change PIN.

1





2






PIN is changed.

## System Settings

Check and make settings for languages & input, gestures, date & time, backup, reset, system update, etc.

### Languages & Input Operations



## System Settings

Settings can be made for the following items.

Item	Description
Languages &	Make settings for handset language and
input	text entry.
Gestures	Make handset operation settings, such as
	Side sense and System navigation.
Date & time	Make settings for date and time.
Backup	Make settings for data backup functions.
Reset options <sup>1</sup>	Reset settings and initialize data.
System	Check for updates. For details, see
update <sup>1</sup>	"Updating Software."
Application	Check if applications provided by Sony
update¹	Mobile are the latest.

1 Appears after Tapping "Advanced."

## Other Settings

### Network & Internet Settings

Make network and Internet settings for Wi-Fi, mobile networks, etc. Settings can be made for the following items.

Item	Description
Wi-Fi	Make Wi-Fi connection settings. For details, see "Connecting by Wi-Fi."
Mobile network	Make mobile network settings.  For details on automatically selecting a network or roaming, see "Global Roaming."
Internet settings	Download settings for internet and MMS.
Data Saver	Stop background data communication for some applications.
Hotspot & tethering	Use handset as Wi-Fi router to access Internet from a PC, game console, etc.
Airplane mode <sup>1</sup>	Disable all functions that emit signals.  Handset stays powered on.
VPN <sup>1</sup>	Add a VPN.
Private DNS <sup>1</sup>	Make private DNS settings.
Smart connectivity <sup>1</sup>	Enable automatic connection to the optimal network when both Wi-Fi and mobile networks are available.

1 Appears after Tapping "Advanced."

## Device Connection Settings

Make connection settings to other devices, such as Bluetooth connection and NFC/Osaifu-Keitai® settings. For details on Bluetooth connection, see "Enabling Bluetooth Function." Settings can be made for the following items.

Item	Description
CURRENTLY	Devices connected by Bluetooth and USB appear. Tap to make Bluetooth device settings and USB connection settings.
Pair new device	Search for and pair nearby Bluetooth devices.
PREVIOUSLY CONNECTED DEVICES	Paired devices appear.  Tap "See all" for all paired Bluetooth devices.
Connection preferences	Bluetooth Make Bluetooth connection settings. Files received via Bluetooth View history of files received by Bluetooth connection. Chromebook Make Chromebook settings. Nearby Share Share files with nearby devices. Cast View handset screen on Google Cast™-capable device. Screen mirroring View handset screen on Screen mirroring-capable device. NFC/Osaifu-Keitai Make settings for NFC/Osaifu-Keitai®. Lock while on lock screen Make settings for NFC/Osaifu-Keitai® lock while screen is locked. USB Connectivity Enable software install wizard to appear when connected to a computer. DUALSHOCK™ 4 Set handset to be controllable by wireless controller (DUALSHOCK™ 4). Printing Set printing from handset to be possible with a printer.

## Appearance Settings

Set wallpaper, ambient display, clock design, etc. Settings can be made for the following items.

Item	Description
Wallpaper	Set wallpaper.
Ambient display (Always-on display)	Make ambient display settings to allow checking of time, notifications, details of playing music, etc. while screen locked.
Clocks	Change type of clock in Lock Screen.

## Apps & notifications Settings

Make application and notification settings. Settings can be made for the following items.

Item	Description
Recently opened apps	Recently opened applications appear.
SEE ALL XX APPS	Check and make settings for installed applications.
Configure notifications	Make notification settings.
Screen time	Check Screen time, Notifications received, and Times opened for handset and each application.
Default apps	Set applications that launch as standard applications.
Permission manager <sup>1</sup>	Check/change application permissions. For details, see "Setting Required Permissions for Applications."
Emergency alerts <sup>1</sup>	Make settings for emergency alerts.
Special app access <sup>1</sup>	Make settings for special application access.

1 Appears after Tapping "Advanced."

## Storage Settings

Check internal and SD Card storage, mount SD Card, and delete SD Card data. Settings can be made for the following items.

Item	Description
DEVICE STORAGE	Check used space/total space on handset.
Internal shared storage	Check used space/total space in internal storage.
PORTABLE STORAGE	Check used space/total space on SD Card/ USB storage.

## Privacy Settings

Make privacy settings such as application permissions and showing passwords. Settings can be made for the following items.

Item	Description
Permission manager	Check/change application permissions. For details, see "Setting Required Permissions for Applications."
Show passwords	Enable entered characters to be visible briefly before changing to "●" in text entry window for SIM PIN / screen lock PIN / password.
Show notifications	Make settings for showing notification details.
Autofill service from Google	Set information saved to your Google account, such as passwords, to be entered by Tapping only once.
Google location history <sup>1</sup>	Enable handset to save locations of visited places.
Activity controls <sup>1</sup>	Select activities and information that are savable to Google.
Ads <sup>1</sup>	Make settings for advertisements that appear.
Usage & diagnostics <sup>1</sup>	Enable diagnostic data as well as data on handset and application usage to be sent to Google for Android improvement purposes.

<sup>1</sup> Appears after Tapping "Advanced."

## Location Settings

Make Location settings. Settings can be made for the following items.

Item	Description
Use location	Enable use of wireless networks and GPS so as to obtain information on current location.
RECENT LOCATION REQUESTS	Show applications recently using location.  Tap See all to show all applications recently using location.
App permission	Permit use of location information per individual application.
Wi-Fi and Bluetooth scanning	Permit Wi-Fi and Bluetooth scanning for improvement of functions and services that use location information.
Emergency Location Service <sup>1</sup>	Enable use of emergency location information.
Google Location Accuracy <sup>1</sup>	Enable improved accuracy of location information, using Wi-Fi, mobile networks, and sensors.
Google Location History <sup>1</sup>	Enable handset to save locations of visited places.
Google Location Sharing <sup>1</sup>	Share current location with other users.

<sup>1</sup> Appears after Tapping "Advanced."

## **Accounts Settings**

Create accounts as well as add, sync, etc. Settings can be made for the following items.

Item	Description
ACCOUNTS FOR OWNER	Added account appears on handset.
Add account	Create and add accounts.
Automatically	Enable automatic updating of data for
sync data	applications.

## **Accessibility Settings**

Set captions, magnification gestures, and other useful accessibility functions. Settings can be made for the following items.

Item	Description
Volume key shortcut	Set accessibility function to activate by Long Pressing Volume Up/Down Key at the same time for three seconds or more.
Smart Security	Enable use of Smart Security.
詐欺ウォール (SagiWall)	Enable Internet SagiWall.
Select to Speak <sup>1</sup>	Enable Tapped items on Display to be read out.
TalkBack <sup>1</sup>	Set accessibility service (TalkBack) to read out screen information.
Text-to- speech output	Set engine for text readout, as well as change readout speed and play sample.
Font size	Set the size of text appearing in Display.
Display size	Set the size of images and icons, etc. appearing in Display.
Dark theme	Enable a dark theme.
Magnification	Set screen to be enlargeable.
Color	Compensate colors when red and green are
correction	hard to distinguish.
Color inversion	Enable inverted screen colors.
Large mouse pointer	Enable a large pointer when using a mouse.
Remove animations	Remove animation effect when Tapping on ( )/off ( ) icon and when screen changes.
Accessibility Menu	Enable use of large menu by Tapping 📅 in Navigation Bar.
Switch Access	Enable handset functions to be assigned to keys.
Click after mouse pointer stops moving	Set handset to click screen where pointer stops moving when using a mouse.
Power button ends call <sup>2</sup>	Enable end of call by Pressing Power Key during call.
Auto-rotate screen	Enable Display to rotate with handset orientation automatically.
Touch & hold delay	Set detection time for Touch & Hold on Display.
Time to take action (Accessibility timeout)	Set how long messages appear that appear only briefly.
Vibration & haptic strength	Set handset to vibrate for ringtone, notifications, and tap operation.
Mono audio	Enable monaural audio playback.
Audio balance	Set audio left-right balance.
	• · · · · · ·

Captions	Enable captions, as well as caption
preferences	language, size, etc.
High contrast	Make text easier to see by adding outline,
text <sup>3</sup>	etc.

- 1 Readout is in "Language" set in "Text-to-speech output."
- When enabled and Display has gone out during a call, first Press Power Key to turn Display on, then Press Power Key to end call.
- 3 Experimental feature; may not work optimally.

## Digital Wellbeing & parental controls Settings

Manage time that handset is used, set parental limitations on use, etc. Settings can be made for the following items.

Item	Description
Dashboard <sup>1</sup>	Check Screen time, Notifications received, and Times opened for handset and each application.
Wind Down <sup>1</sup>	Change Display to monochrome or enable Do Not Disturb at preset time.
Focus mode <sup>1</sup>	Pause applications that might be a distraction.
Manage	Set notifications on/off for apps that
notifications <sup>1</sup>	have recently sent notifications.
Do Not	Facility (disable Da Nat Distanta Alexandra
	Enable/disable Do Not Disturb. Also make
Disturb <sup>1</sup>	Do Not Disturb settings.
Disturb <sup>1</sup> Show icon in	
	Do Not Disturb settings.
Show icon in	Do Not Disturb settings.  Enable (Digital Wellbeing) to be shown
Show icon in the app list <sup>1</sup>	Do Not Disturb settings.  Enable ③ (Digital Wellbeing) to be shown in app list.

1 When setting for the first time, Tap "Show your data" first.

## Google Settings

Make settings for Google services. Settings can be made for the following items.

Item	Description
Manage your Google Account	Make Google account settings.
Account services	Make service settings for your Google account.  Connected apps Make settings for applications already connected to a Google account.  Google Contacts sync Set syncing for Google Contacts.  Google Fit Manage Google Fit application data.  Google Play Instant Make settings for Google Play Instant.  Google Pay Make Google Pay settings.  Search, Assistant & Voice Make settings for searching, Google Assistant, voice search, etc.
Ads	Make settings for advertisements that appear.
Autofill	Set auto-filling of forms and confirmation codes.
Backup	Make backup settings.
Chromebook	Connect handset to Chromebook.
Data & messaging	<ul> <li>Data management</li> <li>Make file update settings for applications compatible with Google Drive.</li> <li>Device phone number</li> <li>Make settings for use of phone number set to be recognized by Google.</li> </ul>
Device connections	· Cast media controls Enable control directly from Cast media control notifications when playing media on TV or speaker with Chromecast on same Wi-Fi network. · Devices Make notification settings for a device near handset. · Nearby Share Share files with nearby devices.
On-device	Let Google applications use on-device data
sharing	shared by these applications.
Parental controls	Use family link for parents and remotely manage handset and limit handset use time.
Security	Make security settings in case of handset loss.

· Restore contacts

Restore backed up contacts.

Set up & restore

· Set up nearby device

Make settings for a device near handset.

 $\cdot$  Set up your work profile Make work profile settings.

## About phone Settings

Check device name and own phone number, save emergency information, etc.

Items that can be checked/set are the following.

Item	Description
Device name	Check/change handset name.
Phone number	Check own phone number.
Emergency	Set information on any medical treatment
information	and emergency contact information.
Legal information	Show legal information.
Certificates	Check credentials.
Detailed	Enable detailed handset diagnostic data to
Diagnostics	be sent for improving Xperia™ quality.
SIM status	Check SIM information.
Model	Check handset's model name, serial
	number, and hardware version.
IMEI	Check IMEI.
Android	Check the Android version.
version	
Battery life	Check Battery performance.
IP address	Check IP address.
Wi-Fi MAC	Check Wi-Fi MAC address.
address	
Bluetooth	Check Bluetooth address.
address	
Up time	Check up time.
Build number	Check build number.

## Global Services

Global	Roaming		80
—— Making	Calls while	Abroad	81

## Global Roaming

Handset is Global Roaming Service eligible. Use the same handset number outside Japan.

Handset connects to an appropriate cellular provider automatically by default. A specific carrier can also be selected manually.

Change communications method and roaming settings as needed.

## Setting the Carrier

1

In Home Screen, ⊚ (Settings) → Network & internet



2





3





· Disable ( ) to search for available networks.

4

Tap network to connect to



The selected carrier is set.

### Changing Roaming Setting

1





2

#### Mobile network



3





- Roaming setting is changed.
- · Tap Roaming to toggle on ( ◯ )/off ( ◯ ).
- · If confirmation appears, follow onscreen instructions.

## Making Calls while Abroad

See SoftBank Website to learn about roaming areas/services,

https://www.softbank.jp/en/mobile/service/global/

International Calls to Japan and Other Countries from Abroad



In Home Screen, 🕓 (Phone)



- Phone opens.
- 2





- Dialing screen opens.
- 3

Touch & Hold



"+" is entered.

### 4

Enter country code then other party number (omit first 0)



 $\cdot$  Do not omit first O from phone numbers when dialing Italy (39).







Handset dials number. Call begins when other party answers.

## Calls to Landline Phones/Cell Phones in Country of Stay

Place calls the same way you would within Japan.

 $\boldsymbol{\cdot}$  Do not enter country code or omit first 0 from phone numbers.



In Home Screen, (Phone)





Phone opens.







Dialing screen opens.



Tap dialpad to enter the other party's number









Handset dials number. Call begins when other party answers.

## Warranty/Specifications/ Customer Service

Warranty	& After-Sales Service	86
Specificat	tions	.86
Customer	Service	87

## Warranty & After-Sales Service

#### Warranty

- The warranty period is 1 year from the date of newly purchase.
- Repairs will be done based on terms of free repair service.
   Terms of free repair service is referred to SoftBank website.

https://cdn.softbank.jp/mobile/set/common/pdf/legal/spguide/common/warranty.pdf (Japanese)

 Warranty covers only handset. Accessories such as cables are not covered by terms of free repair service.

#### Cautions

#### **Damages**

SoftBank Corp. is not responsible for any damages for user or third party resulting from lost opportunities to make a call, etc. due to breakage, malfunction, or trouble of product.

#### Accidents/Repair

Files and settings may be lost or altered due to accidents or repairs. Keep a copy of important files, etc. SoftBank Corp. is not liable for damages resulting from loss or alteration of files (contacts/images/sound etc.) or settings due to accident or repair.

#### Disassembly/Modification

Disassembly/modification of handset is prohibited under the Radio Law. Note that handset cannot be accepted for repairs if modified.

## After-Sales Service

To request repairs, contact Customer Service or a nearby SoftBank Shop. Have details of symptoms ready.

- During the warranty period, repairs are made under the terms of free repair service.
- After the warranty period, if handset can be repaired, repairs will be made at cost. The functional parts necessary to repair the handset will be available for 3 years generally after the manufacture is discontinued. Repair may not be possible because of a shortage of repair parts even during the warranty period.

#### 👸 Further inquiries

For more information on after-sales service, contact a nearby SoftBank Shop or Customer Service.

## Specifications

#### Handset

Item	Description
Dimensions (W x H x D)	Approx. 68 × 158 × 8.0 mm
Weight	Approx. 163 g
Continuous Talk Time <sup>1</sup>	4G (LTE): Approx. 1,620 minutes 5G: Approx. 1,620 minutes
Continuous Standby Time <sup>1</sup>	4G (AXGP): Approx. 530 hours 4G (FDD-LTE): Approx. 555 hours 5G: Approx. 555 hours
Charging Time	Approx. 135 minutes  AC Charger (USB Type-C™ rapid charging  AC Charger with USB PD capability  [ZSDBAS] (SB-AC20-TCPD))²

- 1 May become shorter depending on battery charge, surrounding conditions such as temperature, signal conditions where used, and function settings.
- 2 For details on compatible chargers, see SoftBank Website.

## **Customer Service**

If you encounter any difficulties or are unsure of anything, contact customer service.

### SoftBank Customer Support

- · From a SoftBank handset, dial toll free at 157
- · From a landline/IP phone, dial toll free at 0800-919-0157
- $\cdot$  Business hours : Call 10:00am 7:00pm / Chat 9:00am 8:00pm

## Smartphone Technical Support Center

- $\cdot$  From a SoftBank handset, dial toll free at 151
- · From a landline/IP phone, dial toll free at 0800-1700-151
- · Business hours : Mon. Fri. 9:00am 7:00pm / Sat., Sun., and Holiday 9:00am 5:00pm / 9:00am 8:00pm (for general information)

## Safety Precautions

Safety Precautions	. 90
Important Product Information	98
Bluetooth/Wi-Fi (WLAN)	100
Water Resistance/Dustproofing	102
End User License Agreement	104
Export Controls and Regulations	104
Intellectual Property Rights	105
RF Exposure Information/Specific Absorption Rate (S.	AR)
Information	106
FCC Statement for the USA	108
Operation Radio Frequencies	108

## Safety Precautions

Read safety precautions before using handset. Observe precautions to avoid injury to self or others, or damage to property.

#### Safety Precautions

These labels indicate the degree of risk from improper use. Make sure you thoroughly understand their meanings before reading on.

Mark	Descriptions
<b>⚠</b> DANGER	Great risk of death or serious injury <sup>1</sup> from improper use
<b><u>∧</u> WARNING</b>	Risk of death or serious injury¹ from improper use
<b>⚠</b> CAUTION	Risk of minor injury <sup>2</sup> or damage to property <sup>3</sup> from improper use

- 1 Serious injury includes: Loss of eyesight, physical injury, high temperature burns, low temperature burns, electric shock, fractures, poisoning and other conditions having side effects or requiring hospitalization or long term treatment.
- 2 Minor injury includes: Physical burns (high-temperature and low-temperature), electric shock, and other conditions not requiring hospitalization or long-term treatment.
- 3 Damage to property includes: Incidental damage to structures and household property and/or to pets and livestock.

These symbols indicate prohibited or compulsory actions. Make sure you thoroughly understand their meanings before reading on.

Mark	Descriptions
Prohibited	Prohibited actions
Do Not Disassemble	Disassembly prohibited
Avoid Liquids Or Moisture	Exposure to liquids prohibited
Do Not Use Wet Hands	Use with wet hands prohibited
Compulsory	Compulsory actions
Disconnect Power Source	Unplug AC Charger from outlet

## Handset, AC Charger (Optional Accessory) (Common)

### **⚠** DANGER



Do not use, store, leave in a high temperature or heat accumulating place (e.g. near fire or heater appliances, under kotatsu or bedding, in direct sunlight, inside a sun-heated car, etc.)

May cause fire, burns, injury, electric shock, etc.



Do not put in or place nearby cooking appliances such as a microwave oven, or IH cooking heater, or high-pressure container such as pressure cooker.

May cause fire, burns, injury, electric shock, etc.



Do not allow sand, soil, or mud to contact, or do not place directly on sand, soil, or mud. Do not touch with soiled hands.

May cause fire, burns, injury, electric shock, etc.
For water resistance/dustproofing, see "Water Resistance/
Dustproofing."



Do not charge when handset or related accessory is wet with liquids such as water (drinking water, sweat, sea water, urine of pets, etc.) Do not charge where handset can come in contact with water.

May cause fire, burns, injury, electric shock, etc.
For water resistance, see "Water Resistance/Dustproofing."



Do not subject handset to excessive force or break it. Especially when carrying it in your pocket, do not hit it or press it between other objects.

Internal Battery breakage may cause fire, burns, injury, etc.

- $\ensuremath{^{\star}}$  Take additional care in instances such as the following:
- $\cdot$  Sitting or squatting with the product in your pants or skirt pocket
- $\cdot$  The product becoming caught in a sliding door or vehicle door when in a jacket pocket
- $\cdot$  Stepping on the product when it is on something soft such as a sofa, bed, or futon or on the floor
- $\cdot$  Getting the product caught in the seat on a train or bus



Do not disassemble, modify, or solder.

May cause fire, burns, injury, electric shock, etc.



Do not try to remove Internal Battery.

May cause fire, burns, injury, etc.



Do not try to remove Back Cover from handset.

May cause fire, burns, injury, etc.



Do not allow handset or related accessory to get wet with liquids such as water (drinking water, sweat, sea water, urine of pets, etc.)

May cause fire, burns, injury, electric shock, etc.
For water resistance, see "Water Resistance/Dustproofing."



Do not allow liquids such as water (drinking water, seat, seawater, urine of pets) to come into Charging Terminals or USB Type-C Port/ Headphone Port.

May cause fire, burns, injury, electric shock, etc.
For water resistance, see "Water Resistance/Dustproofing."



Use optional accessories specified by SoftBank.

Using unspecified accessories may cause fire, burns, injury, electric shock, etc.

### **↑** WARNING



Do not drop, stomp, throw, or otherwise subject to strong force, impact, or vibration.

May cause fire, burns, injury, electric shock, etc.



Do not allow Charging Terminals or USB Type-C Port/Headphone Port to contact conductive materials (metal parts, pencil leads, etc.), or do not allow dust to enter inside.

May cause fire, burns, injury, electric shock, etc.



Do not cover or wrap with bedding or other cloths while using or charging.

May cause fire, burns, etc.



Stop charging if not complete when the prescribed charging time has passed.

Overcharge may occur resulting in fire, burns, injury, etc.



Always turn off handset before entering a place where flammable gas may be present, or a place where dusts are generated. Stop charging handset if charging it.

Ignition of flammable gas may cause explosion, fire, etc.



Follow the instructions of a gas station or other such location before using handset there.

Do not charge handset at a gas station, etc.

Take care not to drop handset at a gas station, etc.; in particular, do not use handset while filling.

Ignition of flammable gas may cause explosion, fire, etc.



Take the following actions, exercising caution, in case of abnormal smell, noise, smoke, heat generation, discoloring or deformation while using, charging, or storing.

- -Disconnect the power plug from an outlet
- -Power off handset

Continued use may cause fire, burns, injury, electric shock, etc.

## **⚠** CAUTION



Do not use damaged handsets or related accessories.

May cause fire, burns, injury, etc.



Do not place handset on unstable/uneven surfaces. Be extra careful while the vibrator is

Handset may drop and cause injury.



Do not use or store handset and related accessories in humid, dusty, or high-temperature places.

May cause fire, burns, electric shock, etc. For water resistance, see "Water Resistance/Dustproofing."



Do not allow children to use handset or related accessories in the wrong way. Guardians should supervise use by children.

May cause accidental swallowing, injury, electric shock, etc.



Do not place handset and related accessories within an infant's reach.

In particular, be careful where small parts are stored, such as SIM Card/SD Card Tray.

May cause accidental swallowing, injury, electric shock, etc.



Handset temperature may become high when used continuously or while charging. Avoid continued contact with handset for a long time involuntarily such as by placing handset in clothes pocket, falling asleep, etc.

While using apps, calling, transmitting data, watching TV or videos, or charging Internal Battery, the temperature of handset or AC Charger (optional accessory) may become high. Continued contact with a high-temperature area may cause redness, itching, rash of skin, or low-temperature burns depending on the user's physical condition.

#### Handset

## **⚠** DANGER



Do not throw handset into a fire or apply heat.

May cause fire, burns, injury, etc.



Do not penetrate with a sharp object (nail), hit with a hard objects (hammer), stomp, or otherwise subject handset to strong force.

May cause fire, burns, injury, etc.



If the internal substance of handset gets into your eyes, mouth, etc., immediately rinse with clean water and consult a doctor.

May cause loss of sight, medical problem, etc.

## **⚠ WARNING**



Do not light up or flash the light with the light-emitting part close to other people's eyes.

Keep away from infants.

May harm eyesight. Flash may impair vision or frighten others causing accidents such as injury.



Do not light up or flash the light toward a driver of a car.

May hinder driving and cause accidents, etc.



Do not look at a repeatedly blinking screen for a long time.

May cause twitches, loss of consciousness, etc.



Do not put liquid such as water (drinking water, sweat, sea water, urine of pets, etc.), metal, or flammable object into SIM Card/SD Card Slot.

Do not insert SIM Card or SD Card in the wrong position or orientation.

May cause fire, burns, injury, electric shock, etc.



Do not expose the camera lens to direct sunlight, etc. for a long time.

May cause fire, burns, injury, etc. due to light-condensing of lens.



Power off handset or set to Airplane mode before boarding an aircraft.

Use of handset on board an airline is restricted. Follow the airline's instructions.

Handset radio waves may affect electronic devices of the aircraft.

Prohibited use aboard an aircraft may be subject to penalty by law.



For use in hospitals, follow the medical facility's instructions.

Power off handset in a place where its use is prohibited. Handset radio waves may affect electronic devices or other electronic medical equipment.



Always keep handset away from your ear when calling hands free, ringing loudly for incoming calls, or during standby.

Adjust the sound volume adequately when playing games or playing back videos or music with an earphone/microphone, etc. connected to handset.

Handset sound is loud when calling hands free. Even in standby, the ringtone or alarm may ring suddenly. Listening to loud sound continuously for a long time may cause hearing impairment or other difficulty.

Too loud volume may cause inability to hear ambient sound and may also cause an accident.



Users with heart conditions should adjust vibration and ringtone volume as needed.

Handset suddenly vibrating and ringing for a new call may startle and affect persons with heart conditions.



When using electric medical equipment, etc., check with the equipment vendor or distributor for information about the effects of radio waves.

Handset radio waves may affect electronic medical equipment.



Power off handset near electronic devices that use precision control or faint signals.

Handset radio waves may cause electronic malfunctions, etc.

\* Take additional care near these devices:
Hearing aids, implanted cardiac pacemakers, implanted
cardioverter defibrillators, other electronic medical
equipment, and other automatically controlled devices or
equipment. For users of implanted cardiac pacemakers,
implanted cardioverter defibrillators, other electric medical
equipment, check with the equipment vendor or distributor
for information about the effects of radio waves.



If Display, Back Cover, or Camera lens is broken, do not touch the broken components or exposed inside of handset.

Touching the broken or exposed part may cause burns, injury, electric shock, etc.



If Internal Battery leaks or has an unusual smell, immediately stop using, and keep away from fire.

The leaked fluid may catch on fire causing ignition, explosion, etc.



Do not allow a pet, etc. to bite handset.

Internal Battery may ignite, explode, overheat, or leak causing fire, burns, injury, etc.

## **⚠** CAUTION



When using the motion sensor, ensure the safety of the surroundings and hold handset firmly, not swinging around more than necessary.

Failure to do so may cause accidents such as injury.



If Display is broken, do not allow the leaked internal substance to contact the skin of your face or hands, or clothes.

May cause injury to eyes, skin, etc.

If the internal substance gets into your eyes, mouth, etc., or contacts your skin or clothes, immediately rinse with clean water.

Also, in case it gets into your eyes, mouth, etc., immediately consult a doctor after rinsing.



Do not dispose handset together with ordinary trash.

May cause fire, burns, injury, etc. Also, may cause environmental destruction. Bring unnecessary handset into a sales outlet such as a SoftBank Shop or follow the municipality instructions for recycling.



If the internal fluid is leaked from Internal Battery, do not allow it to contact the skin of your face or hands, or clothes.

May cause injury to eyes, skin, etc.

If the internal substance gets into your eyes, mouth, etc., or contacts your skin or clothes, immediately rinse with clean water.

Also, in case it gets into your eyes, mouth, etc., immediately consult a doctor after rinsing.



Before using handset in a car, check with the car manufacturer or dealer for information about the effects of radio waves.

Handset radio waves may affect the vehicle's electronic equipment in some car models. In that case, stop using handset immediately.



If skin abnormalities develop during use, immediately stop using handset and consult a doctor.

Continuing its use may cause itching, rashes, eczema, or other symptoms depending on the user's physical condition. For the material of each parts, see "Material List."



Make sure that metallic pieces (cutter blade, staples, etc.) are not adhered to Earpiece/
Speaker (top), Speaker (bottom), vibrator area (bottom right, back) since magnetic parts are included.

Adhered objects may cause injury, etc.



Do not leave handset in reach of children or persons requiring supervision.

Handset uses magnets. If swallowed, there is a risk of choking or serious harm to internal organs.

If the magnet has been swallowed, immediately consult a doctor.



Do not bring handset near medical devices.

Handset uses magnets; they may affect pacemakers, variable-pressure hydrocephalus shunts, and other medical devices. Do not bring handset near persons using these devices. If you use such a device, consult your doctor before using the product.



Watch Display in a well-lit place with enough distance kept.

Watching in a dark place or getting too close to Display may reduce visual acuity, etc.

#### AC Charger (Optional Accessory)

## **№ WARNING**



Do not use AC Charger (optional accessory) if the cord is damaged.

May cause fire, burns, electric shock, etc.



If thunder is audible, do not touch AC Charger (optional accessory).

May cause electric shock, etc.



Do not short circuit Charging Terminals when it is connected to a power outlet. Also, do not allow body parts such as your hands or fingers to contact Charging Terminals.

May cause fire, burns, electric shock, etc.



Do not put heavy objects on the cord of AC Charger (optional accessory) or pull it strongly.

May cause fire, burns, electric shock, etc.



When plugging or unplugging AC Charger (optional accessory) into or from a power outlet, do not allow anything metal (metalic strap, etc.) to come in contact.

May cause fire, burns, electric shock, etc.



Do not use a voltage converter (such as a travel converter for overseas use) when charging with AC Charger (optional accessory).

May ignite, overheat, cause electric shock, etc.



Do not apply unnecessary force to the connection part when handset and AC Charger (optional accessory) are connected.

May cause fire, burns, injury, electric shock, etc.



Do not touch the cord of AC Charger (optional accessory), Charging Terminals, Power plug, with wet hands.

May cause fire, burns, electric shock, etc.



Use with specified power supply and voltage.

Also, use AC Charger for global use (optional accessory) when charging overseas.

Using the incorrect power supply and voltage may cause fire, burns, electric shock, etc.

AC Charger:100V AC (Household AC power outlet only)
AC Charger for global use:100V to 240V AC (Household AC power outlet only)



Wipe off dust on the power plug.

Using with dust adhered may cause fire, burns, electric shock, etc.



Firmly insert the power plug of AC Charger (optional accessory) to an outlet.

Failure to do so may cause fire, burns, electric shock, etc.



When unplugging from an outlet, grasp AC Charger (optional accessory) main unit without applying force such as pulling the cord.

The cord of AC Charger may be damaged if it is pulled out and it may cause fire, burns, electric shock, etc.



Insert or remove the connector of AC Charger (optional accessory) straight against the port without applying force such as pulling the cord.

Incorrect insertion or removal may cause fire, burns, injury, electric shock, etc.



Stop using handset immediately if Charging Terminals are deformed or bent.

Or, do not use AC Charger even with the deformation fixed.

Charging Terminals may short-circuit causing fire, burns, injury, electric shock, etc.



Unplug power plug of AC Charger when not using it.

Keeping the power plug connected may cause fire, burns, electric shock, etc.



If liquid such as water (drinking water, sweat, seawater, urine of pets, etc.) gets on equipment, immediately disconnect the power plug from an outlet.

Liquid on equipment may result in short-circuit causing fire, burns, electric shock, etc.



When cleaning, disconnect the power plug from an outlet.

Failure to do so may cause fire, burns, electric shock, etc.

## **⚠** CAUTION



Do not touch AC Charger (optional accessory) that is connected to an outlet continuously.

May cause burns, etc.

#### SIM Card

## **♠** CAUTION



When handling SIM Cards, be careful of the cut surface so as not to hurt your body parts such as fingers.

Cut surface may be sharp and may cause injury, etc.

## Handset Use & Electronic Medical Equipment

### **M** WARNING



Persons with an implanted pacemaker or defibrillator should keep handset at least 15 cm away from the device.

Handset radio waves may affect implanted pacemakers or defibrillators.



When using electronic medical equipment (other than implanted cardiac pacemakers/ defibrillators) outside medical facilities, check with the equipment vendor or distributor for information about the effects of radio waves.

Handset radio waves may affect electronic medical equipment.



Disable handset transmissions (e.g. airplane mode) or power off handset when it is difficult to keep a distance of at least 15 cm away from others such as in a crowd.

There may be someone who is wearing an implanted pacemaker or defibrillator.

Handset radio waves may interfere with implanted pacemakers or defibrillators causing such devices to malfunction.



Observe each medical facility's instruction when using handset.

Handset radio waves may affect electronic medical equipment.

#### Material List

· Xperia 5 II Main Unit

Part	Material/Surface Treatment
Exterior case (top, bottom, side, Volume Keys, Google Assistant Key, Camera Key, SIM Card/ SD Card Slot Cover, Camera ring (around main camera))	Aluminum alloy/Anodized
Exterior case (antenna slit, USB Type-C Port, Headphone Port)	PBT resin (with glass fiber)/-
Transparent plate (Display, Back Cover)	Strengthened glass/AFP processing
Transparent plate (Camera lens)	Strengthened glass/AFP processing + AR processing
Power Key/ Fingerprint Sensor	Epoxy resin/Coating
Earpiece/ Speaker (top) mesh	Polyester resin/dyed
Rubber gasket of SIM Card/ SD Card Slot Cover	Silicone rubber/-
SIM Card/ SD Card Slot Cover inside	PC resin + elastomer resin/-
SIM Card/SD Card Tray	Polyacetal resin/-

## Important Product Information

## Handset, SIM Card, AC Charger (Optional Accessory) (Common)

- Do not get wet. AC Charger (optional accessory) is not water resistant. Avoid using in humid places such as a bathroom and exposing it to rain. Contact to dampness from sweat by wearing on your body may cause corrosion inside resulting in malfunction. If malfunction is determined to be caused by above water exposures, warranty will not apply to repair. In the case that repair is possible, repair charge is incurred.
- External abnormalities such as damage or deformation may degrade the water resistance/dustproof performance.
- Use handset, SIM Card (inserted in handset) within temperatures of 5°C to 35°C and humidity 35% to 85%.
   Avoid extreme temperatures, humidity, direct sunlight (temporary use at 36°C to 40°C and humidity 86% to 90%).
- · Charge Internal Battery within temperatures of 5°C to 35°C.
- $\cdot$  Do not use in a dusty place, where there is much vibration, or near landline phone, TV, radio, etc.
- For using power outlet with drop-off prevention structure, see the user's manual.
- Handset exterior case is not removable. Trying to remove case may cause breakage or malfunction.
- · Battery is built in and is not removable.
- · Internal Battery is a lithium-ion battery.



#### Li-ion 00

- Lithium-ion batteries are precious, recyclable resources.
   Do not discard of old handsets, batteries, or chargers with ordinary waste, and instead bring them to the nearest shop with the Mobile Recycle Network mark.
- Storing handset with full-charged or insufficient battery level deteriorates battery performance. It is recommended to store handset with 40% battery level.
- Turning off by pressing Power Key does not shut off handset from power source completely. Unplug AC Charger power plug to completely turn it off. Use AC Charger (optional accessory) near a power outlet for easy unplugging in case that malfunction is detected.
- Display may become dim when handset temperature rises. It is not abnormal.
- Do not subject handset to excessive shock. Do not deform USB Type-C Port/Headphone Port. May cause malfunction.
- Occasionally clean Charging Terminals with a dry, cotton swab etc. Dirt on Charging Terminals may cause power shut-off or insufficient charging. Take care not to damage Charging Terminals when cleaning.
- · Clean with a dry, soft cloth. Rubbing hard with a dry cloth etc. may scratch them. Wiping off with wet dustcloth may cause malfunction. Using benzine, thinner, alcohol, detergent, etc. may fade color/print.
- $\cdot$  Do not leave Camera in direct sunlight. Concentrated sunlight through Lens may cause handset to malfunction.
- Do not bring magnetic data or magnetic objects close to handset. Magnetic data on cash card, credit card, etc. may be erased or may cause handset malfunction.

#### Charging

- · AC Charger (optional accessory) may become warm while charging. It is not abnormal.
- · If charging is started, although handset is unavailable for operation, screen indicating that handset is charging appears. For this reason, do not charge where handset is required to be powered off.
- · Check battery level with Status Indicator at the top of
- · Operation time of Internal Battery varies by usage environment or the battery condition.
- · Internal Battery is consumable item. Operation time per charge decreases by charging repeatedly. When operation time with full-charged is extremely shortened, it is time to replace. Internal Battery is not customer-replaceable. Bring handset to a SoftBank Shop etc. to replace Internal Battery. Fee is incurred for the replacement. Contact a SoftBank Shop or Customer Service.
- · Using application while charging may shorten Internal Battery life.

#### Display (Touchscreen)

- · Handset uses a touchscreen Display. Operate with your fingers on Display.
- · Touch with your fingers lightly. Do not press forcibly with fingers or push with a sharp-pointed object (nail, ball-point pen, pins, etc.)
- · Touchscreen may not work or malfunction in the following cases:
- Operation with gloves on
- Operation with fingernail
- Foreign object on Display
- Protection sheet or sticker applied on Display
- Waterdrop or dew condensation on Display
- Operation with fingers wet or sweaty
- Operation under water
- · Although Display is made with hardened and shatterproof glass, touching scattered or exposed parts accidentally may cause injuries.
- · Handset uses an OEL display; ghost images may appear. The same image on Display for a long time, a higher-thannecessary brightness setting, or extremely long use may cause brightness to partially dim, color to change, or may burn images into Display. Depending on viewing angle, uneven color or brightness or change in colors may be visible. This is normal for OEL displays.

#### Volume

· Caution: Listening at a loud volume hard on the ears for a long time can affect hearing.



#### Earpiece/Speaker

Handset earpiece is also used as a speaker. Loud sound may be heard from the speaker when playing sound, for arriving incoming calls, etc.

Subjecting your ears to loud sound may affect your hearing ability. Use Earpiece/Speaker with care to prevent your ears from being subject to loud sound. For example, remove Earpiece/Speaker from your ears as soon as a call is ended.

#### **Technical Conformity**

Handset is certified as wireless equipment for low power electric data communication based on the Radio Law. No license is required for using handset as the wireless radio station. However, disassembling/modifying handset may be subject to penalty by law.

- · Disassembling/modifying handset
- · Never use modified handset. Using modified handset is a violation of the Radio Law.

Handset is compliant with the technical standard conformance of specified wireless equipment based on the Radio Law, and as a proof of it, the "Technical Compliance Mark 😩 " appears on the electronic nameplate of handset. Electronic nameplate can be viewed in the following way.

To view: in Home Screen, (Settings) (Settings) About phone





Certificates

The technical standard conformance certification etc. is invalidated by removing the screws and altering the inside of handset. Using handset with invalid technical standard conformance certification etc. is a violation of the Radio Law.

· Do not alter the basic software illegally. May be regarded as software modification and repairs may be refused.

#### Fingerprint Authentication

- Fingerprint authentication uses the characteristics of your fingerprint. If your fingerprint image has few characteristics, fingerprint authentication may not be available.
- Authentication performance (authenticating fingerprint when using Fingerprint Sensor) depends on usage condition. If your finger is under any of the following conditions, registration of fingerprint may be difficult or authentication performance may degrade. Washing/wiping hands, using different finger, etc. may improve capability.
- Wrinkled after taking a bath, etc.
- Wet with water, sweat, etc.
- Dried
- Covered with grease (e.g. hand cream)
- Dirty with mud or grease
- Rough or injured (cut, inflammation, etc.)
- Abraded and faded
- The shape of fingerprint has changed due to weight loss or weight qain
- The surface condition of finger is extremely different from when you registered fingerprint
- Personal authentication and identification are not completely guaranteed by fingerprint authentication technology. Note that SoftBank Corp. is not liable for any damage incurred due to misuse by a third party or due to handset being unable to be used.

## Precautions on Fingerprint Sensor

- Do not hit or apply strong impact. This may cause a malfunction or damage. Also, do not scratch the surface or poke it with a sharp object such as a ballpoint pen or pin tip.
- Do not attach stickers or do not daub with ink, etc.
- If dirt such as dust or sebum is attached to Fingerprint Sensor, reading fingerprints may be difficult or the authentication performance may be degraded. Occasionally clean the surface of Fingerprint Sensor.
- If the time of touching is too short or too long, authentication may fail. Touch the center of Fingerprint Sensor straight with the vortex of your fingerprint.
- Activating Fingerprint Sensor may fail if a finger is placed on it before starting registration or authentication. Release your finger once and try again.

#### Forcibly Powering Off

If screen freezes or power-off operation is not available, forcibly power off by Pressing & Holding Power Key and Volume Up Key at the same time for approximately 9 seconds, then release after handset vibrates three times consecutively.

## Bluetooth/Wi-Fi (WLAN)

#### Frequencies

Frequency band used by handset Bluetooth/Wi-Fi (WLAN) functions are as follows:



2.4:Frequency band is 2400 MHz

4:Estimated range of radio frequency interference is up to 40 m

8:Estimated range of radio frequency interference is up to 80  $\ensuremath{\mathrm{m}}$ 







:Utilizes 2,400 MHz to 2,483.5 MHz band without mobile device bandwidth differentiation

- $\cdot$  Available channels may vary by country.
- · For use in an airplane, contact your airline.

#### Notes on Using Bluetooth Devices

Handset operates on the same frequency band used by home electric appliances such as microwave ovens, industrial, scientific and medical equipment, premises radio stations for identifying mobile units used in the manufacturing lines of plants (radio stations requiring a license), specified low power radio stations (radio stations requiring no license) and amateur radio stations (hereinafter referred to as "another station.")

- Before using handset Bluetooth function, confirm that premises radio stations, specified low power radios and amateur radios are not in use nearby.
- In the event of handset causing harmful radio wave interference with "another station," promptly change the operating frequency or stop radio wave emission by turning off the power, etc.
- For further questions, contact a SoftBank Shop or Customer Service.

## Reception Interference Caused by Wi-Fi (WLAN) Devices

Handset Bluetooth function uses the same frequency band (2.4 GHz) as Wi-Fi (WLAN) devices. Using near Wi-Fi (WLAN) devices may cause radio interference, low-communication speed, noise or connection failure. In that case, take the following measures.

- Provide distance between Bluetooth device and Wi-Fi (WLAN) device. Required distance varies by device.
- · If the problem persists, power off Bluetooth device or Wi-Fi (WLAN) device.

#### Wi-Fi (WLAN)

- Wi-Fi (WLAN) uses radio waves to exchange information and LAN connection is freely established within an area where the radio wave reaches. Meanwhile, if no security is set, Wi-Fi communications may be intercepted or hacked by malicious parties. It is recommended to make necessary security settings on your responsibility.
- $\cdot$  Use handset WLAN function only in Japan.
- Do not use Wi-Fi near magnetic devices such as electrical appliances or AV/OA devices.

Magnetic/radio waves may hinder or disable communication. Avoid microwave ovens especially.

Using near a TV or radio, etc. may cause interference; may affect TV reception.

If there are multiple Wi-Fi access points using the same channel, search may fail.

- Enable Wi-Fi to search available Wi-Fi networks and then establish connection.
- $\cdot$  Connect to Wi-Fi network before accessing Internet via Wi-Fi (WLAN).
- Take care with radio signal strength for Wi-Fi (WLAN). Radio signal strength for Wi-Fi network differs depending on the access point location. Moving close to a Wi-Fi router may improve radio signal strength.
- · To save battery power, disable Wi-Fi (WLAN) when not used.

#### Notes on Using 2.4 GHz Devices

WLAN devices operate on the same frequency band used by home electric appliances such as microwave ovens, industrial, scientific and medical equipment, premises radio stations for identifying mobile units used in the manufacturing lines of plants (radio stations requiring a license), specified low power radio stations (radio stations requiring no license) and amateur radio stations.

- Before using handset, confirm that premises radio stations, specified low power radios, and amateur radio stations are not in use nearby.
- · In the event of handset causing harmful radio wave interference with premises radio stations for identifying mobile units, promptly change the operating frequency or stop radio wave emission by turning off the power, etc. and then contact a SoftBank Shop or Customer Service for measurement against the cross talk (e.g. installing partition.)
- Also, in the event of handset causing radio wave interference with specified low power radios and amateur radio stations, contact a SoftBank Shop or Customer Service.

#### Notes on Using 5 GHz Devices

In 5 GHz frequency bandwidth, handset can use following bands:

- · 5.2 GHz band (W52/36, 40, 44, 48 ch)
- · 5.3 GHz band (W53/52, 56, 60, 64 ch)
- · 5.6 GHz band (W56/100, 104, 108, 112, 116, 120, 124, 128, 132, 136, 140, 144 ch)

Using a 5.2/5.3-GHz-band wireless LAN outdoors is prohibited by law (this does not apply to communication with access points/relay stations of high-output data communications systems operating in the 5.2 GHz band).

## Reception Interference Caused by Bluetooth Devices

Bluetooth and WLAN (IEEE802.11b/g/n/ax) use the same frequency band. Using near Wi-Fi (WLAN) devices may cause radio interference, low-communication speed, noise or connection fault. Or may cause communication interruption or sound distortion when streaming data is played. In that case, take the following measures.

- Provide distance between Wi-Fi (WLAN) device and Bluetooth device. Required distance varies by device.
- · If the problem persists, power off Bluetooth device.

## Water Resistance/Dustproofing

Handset complies with IPX5 $^1$ , IPX8 $^2$  water resistance standards and IP6X $^3$  dustproof standard with SIM Card/SD Card Slot Cover firmly closed.

- 1 Protection against water jet (at 12.5 L/minute from every direction from a distance of approximately 3 m for over 3 minutes through 6.3 mm nozzle)
- 2 Protection against seepage when slowly submerged in still tap water at room temperature to depth of 1.5 m for 30 minutes
- 3 Protection against dust ingress when being placed in an apparatus with grit and dust of diameters of 75  $\mu m$  or less and shaken for 8 hours

#### Handset Water Resistance/Dustproofing

Handset water resistance/dustproofing provides the following:

Calling in the rain without umbrella (approximately 20 mm rainfall per hour)

 Do not open or close SIM Card/SD Card Slot Cover with wet hands or when handset gets wet.

Washing handset when it gets dirty or stained with liquid other than tap water

- · Wash with tap water at normal temperature (5°C 35°C) with weak water flow (less than 6 L/minute) at distance of approximately 10 cm away from the tap or shower.
- When washing handset, make sure to securely close SIM Card/SD Card Slot Cover. Do not use a brush or sponge.
   Drain and the use handset after washing.

Using handset at a poolside

 Do not get water from a pool on handset or soak it in pool water.

#### Maintaining Water Resistance/ Dustproof Performance

Observe the following to avoid water or dust ingress.

- Do not get any liquid other than room temperature tap water on handset, or soak it in such liquid.
- Firmly close SIM Card/SD Card Slot Cover. Even a fine particle (one hair, one grain of sand, tiny fiber, etc.) put between the port contact surfaces may allow water or dust to ingress.
- Do not push Earpiece/Speaker, Mic, Speaker, Second Mic, USB Type-C Port, or Headphone Port with a sharp-pointed object.
- Do not let handset fall. Scratch on handset may degrade water resistance/dustproof performance.
- Rubber gaskets on inner side of SIM Card/SD Card Slot Cover play important roles for water resistance/dustproofing.
   Do not remove or damage them. Also, prevent dust from adhering onto them.

#### Precautions

Do not perform the following actions.

- -Washing with Soap/Detergent/Bath powder
- -Washing using brush/sponge
- -Machine-washing
- -Applying strong water flow
- -Soaking in ocean water
- -Using in hot spring
- -Exposing to sand/mud

Observe the following precautions to use handset properly.

- Do not apply water flow stronger than allowed directly from a tap or shower. Handset provides IPX5 water resistance, but doing so may cause malfunction.
- If handset gets wet with salt water, sea water, beverage, or mud or sand adheres, wash it immediately. If they dry, they become hard to remove and may cause damage or malfunction.
- Do not put in hot water, use in a sauna or apply hot airflow (from a hair dryer etc.).
- Do not move handset in water or slam handset against surface of water.
- Soaking handset in tap water should be no more than 30 minutes.
- · For using handset at a swimming pool, obey rules of the facility.
- · Handset does not float on water.
- Do not let water remain on handset. In cold region, water freezes up and may cause malfunction.
- Do not allow water to remain in the Earpiece/Speaker, Mic, Speaker, Second Mic, USB Type-C Port, or Headphone Port.
   Such water may interfere with calls or get clothes or bag wet.
- If handset gets splashed with water or other liquid while SIM Card/SD Card Slot Cover is opened, seepage may occur resulting in electric shock or malfunction. In that case, stop using and power off handset, then contact a SoftBank Shop or Customer Service.
- If rubber gasket on back of SIM Card/SD Card Slot Cover becomes scratched or deformed, contact a SoftBank Shop or Customer Service for part replacement.
- Do not connect earphones, etc. to handset that is wet with water. May cause malfunction.
- Do not use USB Type-C Port or Headphone Port if wet or dirty/dusty. May lose water resistance, cause electric shock or short circuit, resulting in malfunction, fire, or burns.
- Do not leave handset in a humid place for a long time. Take handset out from bathroom after using.
- Avoid moving handset from cold place to warm place suddenly. Wait until handset temperature gets warm and before bringing it to bathroom etc.
- Complete protection is not guaranteed under all conditions.
   Malfunctions due to improper handling by the user are not covered by Warranty.

### Draining

When handset gets wet, remaining water may flow out after wiping it off. Drain as shown.



Wipe off moisture on handset surface and back side with dry, clean cloth etc.






Shake handset approximately 20 times until there is no more water splattering (Left), then turn upside down and shake it approximately 20 times again (Right)





Wipe off water drained from handset with clean cloth etc.



- Turn Earpiece/Speaker, Mic, Speaker, USB Type-C Port,
   Second Mic, Headphone Port, Power Key/Fingerprint Sensor,
   Volume/Zoom Up/Down Key, Google Assistant Key, Camera
   Key and SIM Card/SD Card Slot Cover, Camera ring (around main camera) face down onto cloth etc. to drain water.
- · Turn upside down and wipe off.



Place handset on dry, clean cloth etc., and dry naturally at room temperature for a couple of hours



Water is drained.

### Charging

Check the following while and after charging.

- While charging, check that handset is not wet. Never charge while handset is wet.
- Never connect USB Type-C connector when handset or AC Charger is wet. Handset provides water resistance, but liquids (tap water, beverages, sea water, pet urine, etc.) adhered to USB Type-C connector may cause electric shock or short circuit, resulting in fire, burns, or malfunctions.
- Do not use AC Charger (optional accessory), USB Type-C cable (commercially available) in a bathroom, shower room, kitchen, lavatory or other highly humid area. Doing so may cause fire or electric shock.
- Do not touch AC Charger (optional accessory) or USB Type-C cable (commercially available) with wet hand. Doing so may cause electric shock.

## End User License Agreement

#### End User License Agreement

Software delivered with this device and its media are owned by Sony Mobile Communications Inc., and/or its affiliated companies and its suppliers and licensers.

Sony Mobile grants you a non-exclusive limited license to use the Software solely in conjunction with the Device on which it is installed or delivered.

Ownership of the Software is not sold, transferred or otherwise conveyed. Do not use any means to discover the source code or any component of the Software, reproduce and distribute the Software, or modify the Software.

You are entitled to transfer rights and obligations of the Software to a third party, solely together with the Device with which you received the Software, provided the third party agrees in writing to be bound by the terms of this license

This license exists throughout the useful life of this Device. It can be terminated by transferring your rights to the Device to a third party in writing. Failure to comply with any of these terms and conditions will terminate the license immediately.

Sony Mobile and its third party suppliers and licensers retain all rights, titles and interest in and to the Software.

To the extent that the Software contains material or code of a third party, such third parties shall be beneficiaries of these terms.

This license is governed by the laws of Japan. When applicable, the foregoing applies to statutory consumer rights. In the event Software accompanying or provided in conjunction with your device is provided with additional terms and conditions, such provisions shall also govern your possession and usage of the Software.

## **Export Controls and Regulations**

#### **Export Controls and Regulations**

The products may be subject to the application of the Foreign Exchange and Foreign Trade Act and other related laws and regulations in Japan.

In addition, the Export Administration Regulations (EAR) of the United States may be applicable.

In cases of exporting or reexporting the products, customers are requested to follow the necessary procedures at their own responsibility and cost. Please contact the Ministry of Economy, Trade and Industry of Japan or the Department of Commerce of the United States for details about procedures.

## Intellectual Property Rights

#### Copyrights and Portrait Rights

Copyrighted contents you recorded or obtained from Websites pages using this product by downloading or other means, such as documents, images, music data, software, are prohibited from reproduction, transformation and transmission over public lines without consent of the copyright holders, unless intended for personal use or any other purpose permitted by law.

Note that some performances, shows, and exhibitions may not permit photography, movie shooting, or sound recording even for personal use.

You should also refrain from taking a picture of other people and disclosing it by such means as posting it on a Website without their consent because of possible infringement of their right of portrait.

#### **Trademarks**

The company names and product names appearing in this manual are trademarks or registered trademarks of their respective holders.

- SOFTBANK, SOFTBANK's equivalent in Japanese and the SOFTBANK logo are registered trademarks or trademarks of SOFTBANK GROUP CORP. in Japan and other countries.
- · Yahoo! and the Yahoo! logomark are registered trademarks or trademarks of Oath Inc. in the United States.
- ・詐欺ウォール/Internet SagiWall name and logo are trademarks or registered trademarks of BB Softservice Corp.
- $\cdot$  McAfee and the McAfee logo are trademarks of McAfee LLC in the United States and other countries.
- ・ハローページ is a registered trademark of Nippon Telegraph and Telephone Corporation.
- · ©JBA ©B.LEAGUE ©W LEAGUE
- Qualcomm Quick Charge is a product of Qualcomm Technologies, Inc.
- Qualcomm is a trademark of Qualcomm Incorporated, registered in the United States and other countries.
   Qualcomm Quick Charge is a trademark of Qualcomm Incorporated. All Qualcomm Incorporated marks are used with permission.
- · Bluetooth® is a registered trademark of Bluetooth SIG, Inc., and Sony Mobile Communications Inc. is licensed to use them.
- Wi-Fi® and Wi-Fi Direct® are trademarks or registered trademarks of Wi-Fi Alliance.
- Sony, FeliCa, Smile Shutter, DSEE Ultimate, STAMINA, the Video & TV SideView logo, Face Detection, Reader, Xperia, and the XPERIA logo are trademarks or registered trademarks of Sony Corporation.
- PlayStation is a trademark or registered trademark of Sony Interactive Entertainment Inc.
- $\cdot$  microSD logo, microSDHC logo and microSDXC logo are trademarks of SD-3C, LLC.
- · USB Type-C<sup>™</sup> is a trademark of USB Implementers Forum.
- DisplayPort is a trademark, or in the United States and/or other countries a registered trademark, of Video Electronics Standards Association.
- $\cdot$  FeliCa is a contactless IC card technology developed by Sony Corporation.
- ∙ ⋦ is a registered trademark of FeliCa Networks, Inc.
- is a trademark or registered trademark of NFC Forum, Inc. in the United States and other countries.
- ・Manufactured based on a license from Dolby Laboratories.

  Dolby, ドルビー, Dolby Atmos, and the double-D symbol are trademarks of Dolby Laboratories.
- $\cdot$  AccuWeather is a trademark or registered trademark of AccuWeather, Inc.
- Google, the Google logo, Android, Google Play, the Google Play logo, Gmail, the Gmail logo, Google Maps, the Google Maps logo, Google Calendar, the Google Calendar logo, YouTube, the YouTube logo, Google Docs, the Google Docs logo, Google Chrome, the Google Chrome logo, Google Sheets, the Google Sheets logo, Google Slides, the Google Slides logo, YouTube Music, the YouTube Music logo, Google Drive, the Google Drive logo, Google Duo, the Google Duo logo, Google Photos, the Google Photos logo, Google News, the Google News logo, Google Pay, the Google Pay logo, Google One, the Google One logo, the Google Podcasts logo, the

Google Assistant logo, Google Lens, and the Google Lens logo are trademarks or registered trademarks of Google LLC.

- Microsoft, Windows, Microsoft Excel and Microsoft PowerPoint are trademarks or registered trademarks of Microsoft Corporation in the United States and other countries.
- Microsoft Word is a product name of Microsoft Corporation in the United States.
- This product contains technology subject to certain intellectual property rights of Microsoft. Use or distribution of this technology outside of this product is prohibited without the appropriate license(s) from Microsoft.
- QR code is a registered trademark of DENSO WAVE INCORPORATED.
- Osaifu-Keitai is a registered trademark of NTT DOCOMO, INC.
- Facebook and the Facebook logo are registered trademarks of Facebook, Inc.
- Amazon, Amazon.co.jp and its logo, and Amazon Prime are trademarks of Amazon.com, Inc. or its affiliates.
- "mora" and its name and logo are registered trademarks of Label Gate Co., Ltd.
- · iPhone is a trademark of Apple Inc. registered in the United States and other countries. The iPhone trademark is used based on a license from Aiphone Co., Ltd.
- This product is licensed under the MPEG-4 visual and AVC patent portfolio license for the personal and non-commercial use of a consumer for (i) encoding video in compliance with the MPEG-4 visual standard ("MPEG-4 video") or the AVC standard ("AVC video") and/or (ii) decoding MPEG-4 or AVC video that was encoded by a consumer engaged in a personal and non-commercial activity and/or was obtained from a video provider licensed by MPEG LA to provide MPEG-4 and/or AVC video. No license is granted or shall be implied for any other use. Additional information including that relating to promotional, internal and commercial uses and licensing may be obtained MPEG LA, LLC (See https://www.mpegla.com). MPEG Layer-3 audio decoding technology licensed from Fraunhofer IIS and Thomson.
- Other product and company names mentioned herein may be the trademarks of their respective owners.
   In context, TM and ® mark are omitted.
- Any rights not expressly granted herein are reserved. All other trademarks are property of their respective owners.

# RF Exposure Information/Specific Absorption Rate (SAR) Information

"A002SO" here refers to this mobile phone "Xperia 5 II."

## Specific Absorption Rate (SAR) for This Product (for Japan)

This mobile phone A002SO is compliant with the Japanese technical regulations\* and international guidelines for exposure to radio waves.

The Japanese technical regulations on human exposure to radio frequency energy have established permitted levels of radio frequency energy, based on the standards developed by independent scientific organizations through periodic and thorough evaluation of scientific studies.

The regulations employ a unit of measurement known as the Specific Absorption Rate, or SAR.

The SAR limit is 2 watts/kilogram (W/kg) averaged over ten grams of tissue.

The limit includes a substantial safety margin designed to assure the safety of all persons regardless of age and health. The value of the limit is equal to the value stipulated in the international guideline recommended by ICNIRP\*\*, which is in collaboration with the World Health Organization (WHO). The highest SAR value for this mobile phone is 1.29 W/kg\*\*\* when tested for use at the ear, and 0.91 W/kg\*\*\* when worn

While there may be differences between the SAR levels of various phones and at various positions, all phones meet the Japanese technical regulations.

on the body in the below manner\*\*\*\*.

Although the SAR is determined at the highest certified power level, the actual SAR of the phone during operation can be well below the maximum value.

- \* The technical regulations are provided in the Article 14-2 of the Ministry Ordinance Regulating Radio Equipment.
- \*\* International Commission on Non-Ionizing Radiation Protection
- \*\*\* The value is under simultaneous transmission use conditions.
- \*\*\*\* Use at positions other than at the ear

This mobile phone may be used at positions other than at the ear. By using an accessory such as a belt clip holster that maintains a 1.5 cm separation with no metal (parts) between it and the body and the mobile phone, this mobile phone will comply with international guidelines for radio wave protection.

The WHO has announced that "A large number of studies have been performed over the last two decades to assess whether mobile phones pose a potential health risk. To date, no adverse health effects have been established as being caused by mobile phone use."

For more information about SAR, see the following websites:

- $\cdot$  Ministry of Internal Affairs and Communications (MIC)
- https://www.tele.soumu.go.jp/e/sys/ele/body/index.htm
- · Association of Radio Industries and Businesses (ARIB) https://www.arib-emf.org/01denpa/denpa02-02.html (Japanese)

· World Health Organization

https://www.who.int/peh-emf/publications/factsheets/en/

 $\cdot$  List of Specific Absorption Rates (SAR) for radio waves by smartphone/3G model

https://www.softbank.jp/mobile/support/sar/ (Japanese)

#### European RF Exposure Information

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves recommended by international guidelines. These guidelines were developed by the independent scientific organization ICNIRP and include safety margins designed to assure the protection of all persons, regardless of age and health. The guidelines use a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit for mobile devices is 2.0 W/kg and the highest SAR value for this device when tested at the ear is 0.21 W/kg\*. As mobile devices offer a range of functions, they can be used in other positions, such as on the body. In this case, the highest tested SAR value is  $0.87~W/kg^*$  at the separation distance of 0.5~cm from the body. For electronic safety, maintain the separation distance with accessories containing no metal, that position handset a minimum of the above distance. Use of other accessories may not ensure compliance with RF exposure guidelines.

\* The tests are carried out in accordance with international guidelines for testing.

#### FCC RF Exposure Information

Your handset is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government. The guidelines are based on standards that were developed by independent scientific organization through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health. The exposure standard for wireless handsets employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg. The tests are performed in positions and locations (e.g. at the ear and worn on the body) as required by the FCC for each model. The highest SAR value as reported to the authorities for this phone model when tested for use by the ear is 0.64 W/kg, when worn on the body is 0.31 W/kg and when WiFi hotspot mode is 0.80 W/kg. For body-worn operation, this phone has been tested and meets the FCC RF exposure guidelines. Please use an accessory designated for this product or an accessory which contains no metal and which positions the handset a minimum of 15 mm from the body. For devices which include "WiFi hotspot" functionality, SAR measurements for the device operating in WiFi hotspot mode were taken using a separation distance of 10 mm.

The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided. The FCC has granted an Equipment Authorization for this model handset with all reported SAR levels evaluated as in compliance with the FCC RF emission guidelines. SAR information on this model handset is on file with the FCC and can be found under the Display Grant section of https://www.fcc.gov/oet/ea/ after searching on FCC ID PY7-23855M.

Additional information on Specific Absorption Rates (SAR) can be found on the FCC website at https://www.fcc.gov/general/radio-frequency-safety-0.

### FCC Statement for the USA

#### FCC Statement for the USA

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation. Any change or modification not expressly approved by Sony may void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## Operation Radio Frequencies

#### Operation Radio Frequencies

GSM/GPRS/EDGE: 850, 900, 1800, 1900 MHz

UMTS: 2100 (Band I), 1900 (Band II), 1700 (Band IV), 900

(Band VIII) MHz

LTE: Bands 1, 2, 3, 4, 8, 11, 12, 17, 28, 38, 39, 40, 41, 42

5GNR: n77

WLAN: 2.4 GHz/5 GHz

NFC

GSM 850/900: 33 dBm

DCS (1800)/PCS (1900): 30 dBm

UMTS: 24 dBm

LTE: 23 dBm (Bands 1, 2, 3, 4, 8, 11, 12, 17, 28, 38, 39, 40,

42), 26 dBm (Band 41)

5GNR: 23 dBm

WLAN: 2.4 GHz < 100 mW, 5.15-5.35 GHz < 200 mW, 5.47-5.725 GHz < 200 mW, 5.735-5.835 GHz < 25 mW

NFC 13.56 MHz



About the User Guide3
Adding Applications59
Airplane Mode24
Applications58
B
Basic Operation22
Battery Settings70
Bluetooth/Wi-Fi (WLAN)100
C
Capturing Still Images/Videos54
Charging Internal Battery12
Connecting by Wi-Fi64
Customer Service87
Data Usage Settings69
Display Settings70
<b>(E)</b>
Full Harristian and American
End User License Agreement104
Export Controls and Regulations104
G
FCC Statement for the USA108
G)
Global Roaming80
Global Roalling 80
Handset Screens28
Handset Settings68
U
Important Product Information98
Intellectual Property Rights105
intenectual Property Rights105
9
Locking Screen19

Making Calls while Abroad......81

## Xperia 5 II User Guide Index

Making Initial Settings13
Operation Radio Frequencies108
Optional Services36
Other Settings73
P
Parts & Functions6
Phone Number42
Photos
Placing/Answering Calls34
+Message46
Power On/Off
R
RF Exposure Information/Specific Absorption Rate (SAR)
Information
<b>S</b>
Safety Precautions90
SAR106
SD Card9
Security Settings71
Sending Messages (+Message)46
Setting a Google Account15
Silent Mode
SIM Card
Sound Settings
Status Bar
System Settings
,
Text Entry25
U
Updating Software26
Using Bluetooth Function
Using Chrome50
Using Contacts43
Using Gmail47
Using Notifications Window30
Using Quick Settings31
Using Touchscreen
V
Viewing Still Images/Videos (Photos)55



Warranty & After-Sales Service	. 86
Water Resistance/Dustproofing	102
WLAN	100

## Xperia 5 II User Guide

November 2020, First Edition SoftBank Corp.

Visit SoftBank Shop for assistance

Model : Xperia 5 II Manufacturer : Sony Mobile Communications Inc.