# AQUOS CRYSTAL 2 User Guide

# AQUOS CRYSTAL 2 User Guide Contents

# Introduction About the User Guide......3 **Getting Started** Package Contents......6 USIM Card Installation......7 Handset Memory & SD Card......9 Charging Handset......12 Power On/Off......14 Touchscreen Operations......15 Handset Initial Settings......16 **Basic Operations** Applications......22 Activating Applications Quickly (Quick Launcher).......23 Handset Phone Number......26 Using Airplane Mode......27 Text Entry......27 Google Play...... 31 Security Codes......33 USIM PIN......35 Turning Off Display (Screen Lock)......36 Updating Software......37 Operating by Gripping Handset (Grip Magic)......38 Handset Interface Welcome Sheet (Lock Screen) Basics......42 Home Screen (Feel Home) Basics......43 Icons at Display Top (Status Bar)......44 Checking Handset Status & Notifications (Notifications Window)......46 Customizing Welcome Sheet (Lock Screen)......47 Customizing Home Screen (Feel Home)......49 Disabling Touch Operation Temporarily (Childlock)......54 Copying Onscreen Text (Copy Anywhere)......55 Writing Notes on Display (KAKU Notepad).....55 Capturing Screenshots (Clip Now)......56 Phone Calling...... 60 Optional Services......64 Making Call Settings......69 Address Book...... 71 Hiding Contacts (Secrecy Settings)......74 Messaging & Internet Messaging...... 78 S! Mail Initial Setup......78 Sending S! Mail/SMS......79 Opening & Replying to S! Mail/SMS......81 Using Gmail...... 83

Using Email86
Using the Internet (Chrome)88
Camera
Capturing Photos94
Recording Videos95
Music & Images
Music Files (Music)100
Viewing & Managing Photos/Videos (Album)101
Connectivity
Wi-Fi
Using Tethering Functions
Bluetooth®
bidetootii
Global Services
Global Roaming
Calling from Outside Japan115
Handset Settings
About Settings120
Sound/Notification Settings 121
Wallpaper & Display Settings124
Energy Saving Settings126
Home Applications Setting130
Useful Settings130
About phone
Accounts Settings135
Call Settings
Mail Settings136
Guide Setting
Data Usage Settings
Storage Settings
Application Settings143
Data Transfer
Other Settings146
For Assistance
File Storage
Backup & Restore
Troubleshooting
Specifications
Warranty & After-Sales Service
Customer Service166
Safety Precautions
Safety Precautions168
Important Product Information176
Handset & Hardware Care
General Notes
Radio Wave Exposure and Specific Absorption Rate (SAR)
Information
Water Resistance

## About the User Guide

Thank-you for purchasing this product.

#### Before You Begin

Read "Safety Precautions" thoroughly beforehand for proper usage.

Accessible services may be limited by contract conditions.

#### **Guide Usage Notes**

In the User Guide, most operation descriptions are based on handset at time of purchase.

Unless noted otherwise, descriptions are for Home Screen (Feel Home).

"Confirmation" refers to a window that appears after operation, such as authentication prompt window, selection window or caution window.

Some operation descriptions may be omitted.

# Screenshots & Key Labels

Screenshots in the User Guide may differ in appearance with actual Display. Key labels in the User Guide are simplified for description purposes and differ with actual Display.

#### Other Notations

In the User Guide, the product is referred to as "handset."
microSD™/microSDHC™/microSDXC™ Card is referred to as "SD Card."

"403SH" here refers to this mobile phone "AQUOS CRYSTAL 2."

# Accessing Instructions on Handset

#### Launching Guide



In app sheet, 🔛 (Basic) 🔵 🕢 (Guide



- Guide top screen opens.
- Guide usage information and confirmation for automatic updates appear at initial startup. Follow onscreen prompts.
- Enable/Disable Automatic Checking for Updates



## Showing Status Bar Indicator

Show indicator to launch Guide from Notifications Window.



In app sheet, 🔣 (Basic) 🔵 🔞 (Guide)









- Guide top screen opens.
- · If confirmation appears, follow onscreen prompts.

2













Indicator is shown.

#### Launching Guide from Notifications Window

Launch the Guide quickly for how to use functions, etc. when indicator is set to appear.



Drag Status Bar down for Notifications Window



- Notifications Window opens.

Guide



Guide top screen opens.

# Using Guide



Item	Description
1 Enter information to search for	Search for items in Guide.
2 Open Guide	Check how to operate handset by category, and use voice searching for operations to check.
3 FAQ	Check frequently asked questions, and quickly access the FAQ mobile site.

# Getting Started

Package Contents	Ю
Parts & Functions	6
JSIM Card Installation	
Handset Memory & SD Card	9
Charging Handset1	2
Power On/Off1	4
Fouchscreen Operations1	5
Handset Initial Settings1	6

# Package Contents

# Package Contents

- · Handset (AQUOS CRYSTAL 2)
  - $\cdot$  Battery is built into handset.
  - $\cdot$  Handset back cover is not removable.
- · TV Antenna Cable (Complimentary sample)
- ・クイックスタート (Japanese)
- ・お願いとご注意 (Japanese)
- $\cdot \ \mathsf{Warranty}$


# Parts & Functions

# Handset Parts



Name	Description
1 Mic	Use when talking to emopa or using Speakerphone for calls.
2 SD/USIM Card Slot	Insert/remove SD Card and USIM Card.
3 Display	Handset uses a touchscreen-type Display. Operate with your fingers on Display.
4 Proximity/ Light Sensor	Light Sensor detects ambient light level. When Sweep ON¹ or Grip Sensor is enabled, also prevents Touchscreen misoperation during calls.
5 Notification Lamp	Illuminates while charging or for notifications (missed calls, new messages, etc.).
6 External Device Port	Connect AC Charger or Micro USB Cable here.
7 Earphones- Microphone Port	Connect TV Antenna Cable or Earphones with Mic (optional accessory) here.
Receiver Area (Direct Wave Receiver) <sup>2</sup>	Hear other party's voice through this.
9 Internal Camera	Use to shoot photos or videos of yourself.
10 Mic/ Recorder Mic	Talk to other party through this. Also use while recording videos.

- 1 For details on Sweep ON, see "On/Off with Motion Settings."
- 2 For details on Direct Wave Receiver, see "Call Window Layout/In-Call Operation."



Name	Description
1 Mic (Recorder Mic)	Use when talking to emopa or while recording videos.
2 External Camera	Shoot photos or videos.
3 Mobile Light	Use as a camera flash, flashlight, etc.
4 FeliCa Mark	Hold up to reader/writer when using NFC/ Osaifu-Keitai®.
<b>5</b> Grip Sensor Area	Turns on Display, etc. when handset is held with both right and left sensor areas touched.
6 Speaker	Listen to music, video sound, One Seg, etc.

#### Handset Keys



2	
Name	

	Ivanic	
1	ψ	

(Power Key)

2 Volume Up Key

3 Volume Down Key

#### Description

Turn Display off/on. Long Press for power on/off, Reboot, Airplane mode, etc.

Increase volume. Long Press for Mobile Light on/off (in Welcome sheet (lock

Decrease volume. Long Press to activate/ cancel Manner mode (in Welcome sheet (lock screen) or Feel Home).

## **USIM Card Installation**

USIM Card is an IC card containing customer and authentication information, including handset number.

# Handling USIM Card

- · See instructions included with USIM Card for handling.
- · Avoid applying labels. May damage USIM Card.
- $\cdot$  USIM is replaceable (at cost) in case of loss/damage.
- · Wipe clean with a dry, soft cloth.
- · Always keep the IC chip (metal) clean.



1 IC chip (metal)

# **USIM Card Usage Notes**

Observe the following when using USIM Card.

- · Always follow emergency procedures to suspend service if your USIM Card or handset (USIM Card inserted) is lost/ stolen. For details, contact Customer Service.
- · Customer is responsible for any damage caused by inserting USIM Card in an other-brand IC card reader, etc. SoftBank Corp. is not responsible in such case.
- · It is recommended that you back up information that is saved on USIM Card. SoftBank Corp. is not responsible for damages from saved information that is lost.
- · Always power off handset before inserting/removing USIM Card.
- $\cdot$  Note that USIM Card specifications and performance may change without notice.
- · Return USIM Card to SoftBank Corp. when canceling subscription.
- · USIM Card is the property of SoftBank Corp.
- · Returned USIM Cards are recycled for environmental purposes.

### Inserting USIM Card

Always power off beforehand.



Open Card Slot Cover



2

Pull out USIM Tray



 $\cdot$  Do not pull USIM Tray forcefully or at an angle; damage may result. Gently pull it out horizontally from the edge.



Place USIM Card in USIM Tray



· Check orientation of USIM Card (see notch), then gently place it with IC chip (metal) facing up.



Insert USIM Tray into USIM Card Slot (bottom opening)



 $\cdot$  Check orientation of USIM Tray, then gently insert it all the way horizontally.



Close Card Slot Cover by pressing 1 then 2



 Press O areas firmly so that there is no gap between handset and Card Slot Cover. Debris trapped between gasket and Card Slot may allow ingress of liquid.

#### Removing USIM Card

Always power off beforehand.



Open Card Slot Cover



2

Pull out USIM Tray



• Do not pull USIM Tray forcefully or at an angle; damage may result. Gently pull it out horizontally from the edge.



Remove USIM Card



4

Insert USIM Tray into USIM Card Slot (bottom opening)



Do not insert USIM Tray at an angle; damage may result.
 Check orientation of USIM Tray, then gently insert it all the way horizontally.



Close Card Slot Cover by pressing 1 then 2



 Press 
 areas firmly so that there is no gap between handset and Card Slot Cover. Debris trapped between gasket and Card Slot may allow ingress of liquid.

#### SIM Unlocking

Handset supports SIM unlocking. After unlocking SIM, other companies' SIM cards can also be used on handset.

- When using another company's SIM card on handset, accessible services/functions, etc. may be limited. SoftBank Corp. makes no guarantees whatsoever regarding the proper operation of handset.
- · For details on SIM unlocking, see SoftBank Website.

# Handset Memory & SD Card

Photos and videos taken with handset, files created with applications, etc. are saved in handset memory. Install and use an SD Card as needed.

# Handset Memory/SD Card Usage Notes

#### Use of SD Cards

Handset supports SD Card up to 128 GB. Some SD Cards may not operate properly. Observe the following when using SD Cards.

- · Do not insert or remove SD Card forcefully.
- · Do not touch terminals or expose them to metal objects.
- · Some files are not savable.
- · Make sure not to erase or overwrite files accidentally.

#### microSDXC Card

Handset supports microSDXC Cards (SDXC-compatible SD Cards). microSDXC Cards are supported by SDXC-compatible devices only.

#### Exchanging Files with Non-SDXC-Compatible Devices

To exchange files between handset and non-SDXCcompatible devices, use SD Cards (microSD/microSDHC Cards) supported by handset and those devices. Inserting a microSDXC Card used on handset in a non-SDXC-compatible device may corrupt card files.

Do not format the microSDXC Card on that device even if prompted to do so. Formatting deletes all microSDXC Card files and changes the file system. The original memory capacity may be unavailable after formatting.

To use a corrupted microSDXC Card, format it on an SDXCcompatible device.

#### Handset Memory/SD Card Files

Handset memory/SD Card files may be lost/altered due to accidents, malfunctions, repairs, handset upgrade/ replacement, mishandling, etc. Back up important files regularly. SoftBank Corp. is not liable for any damages resulting from loss/alteration of files.

· Never power off while files are being accessed.

#### Save Location

By default, files, including videos and photos taken with handset, are saved in handset memory. Even with downloaded commercially-available apps described as saving data on SD Card, files are saved in handset memory.

# SD Card Caution

Keep SD Card away from infants; may cause choking if swallowed.

## Inserting SD Card



Open Card Slot Cover





Insert SD Card into SD Card Slot (top opening)



· Gently insert SD Card all the way horizontally with terminals facing up.



Close Card Slot Cover by pressing 1 then 2





· Press  $\bigcirc$  areas firmly so that there is no gap between handset and Card Slot Cover. Debris trapped between gasket and Card Slot may allow ingress of liquid.

# Formatting SD Card

When using a new SD Card for the first time, always format it on handset.

- $\cdot$  Formatting deletes all SD Card files. Format SD Card with caution.
- $\cdot$  When formatting, keep handset charged or charge it adequately beforehand.



In app sheet, 🌼 (Settings)



2

[Storage]



3

[Erase microSD]



4

ERASE SD CARD



5

Enter Operation Password 

OK



· If Operation Password is unset, follow onscreen prompts.



ERASE EVERYTHING



All SD Card files will be deleted.

# Unmounting SD Card

1

In app sheet, 🌼 (Settings)



2

[Storage]



3

Unmount microSD → OK



Unmount microSD changes to Mount microSD . (SD Card is unmounted.)

To mount SD Card again, Tap Mount microSD.

## Removing SD Card

Always unmount SD Card beforehand.



Open Card Slot Cover



2

Remove SD Card



· Lightly push SD Card in and release finger (SD Card pops out slightly); gently pull it out horizontally.



Close Card Slot Cover by pressing 1 then 2



 $\cdot$  Press  $\bigcirc$  areas firmly so that there is no gap between handset and Card Slot Cover. Debris trapped between gasket and Card Slot may allow ingress of liquid.

# Charging Handset

Battery is built into handset.

## Internal Battery

A lithium-ion battery is built into handset; it is not removable.

# Recycling

This product requires a lithium-ion battery. Lithium-ion batteries are recyclable. To recycle a used lithium-ion battery, take it to any shop displaying the recycling symbol.





## Battery Cautions

#### Battery Care

To help maintain performance and life of Internal Battery, do not store in the following conditions (battery level should be at approximately 40% for optimal storage).

- · Full (immediately after charging is complete)
- · Exhausted (too low to power on handset)

#### Bulges of Internal Battery

Depending on usage, bulges may appear near end of battery life; this does not affect safety.

#### Internal Battery Replacement

Internal Battery is a consumable item; may need to be replaced if operating time shortens noticeably. Internal Battery is not user replaceable; its replacement incurs fees and requires handset submission to a SoftBank Shop or other appropriate servicer. For details, contact a SoftBank Shop or SoftBank Customer Support, General Information.

#### **About Charging**

The following charging options are available.

Charging Option	Description
AC Charger	Connect handset and AC Charger (optional accessory) directly.
USB charging	Connect handset and a PC with Micro USB Cable (optional accessory).
Cigar lighter socket	Charge handset in a car using Micro USB Charging Adapter (optional accessory) and In-Car Charger (optional accessory).

## Notification Lamp

Notification Lamp illuminates red while charging; illuminates green when charge is almost full.

 If Notification Lamp is blinking, charging is not working properly. Make sure that you are using Charger and products specified by SoftBank Corp. If you are using specified products only, contact a SoftBank Shop or SoftBank Customer Support, General Information.

## Charging Cautions

#### Water Resistance

Handset is water resistant; however, if Micro USB plug is inserted while it is wet, liquid (tap water, beverage, sea water, pet urine, etc.) or a foreign object adhered to handset or Micro USB plug may cause overheating, burnout, fire, malfunction, burns, etc. due to electric shock, short-circuiting, etc.

 AC Charger (optional accessory), Micro USB Charging Adapter (optional accessory), Micro USB Cable (optional accessory) and In-Car Charger (optional accessory) are not waterproof. Never connect Micro USB plug while handset or Charger is wet.

#### Handling Cables

Do not pull, bend, or twist cable; may damage the cable.

#### **About Charging Abroad**


SoftBank Corp. is not liable for problems resulting from charging handset abroad.

# AC Charger

AC Charger is an optional accessory. Be sure to use SHCEJ1 or ZTDAC1 (Micro USB, 1.0 A) specified by SoftBank Corp. For information on other peripheral devices, see SoftBank Website.

The following explains how to charge handset using SHCEJ1.

- $\cdot$  See User Guide for corresponding AC Charger.
- $\cdot$  Never connect Micro USB plug while handset or AC Charger is wet.





Insert Micro USB plug of AC Charger into External Device Port



· Insert Micro USB plug in correct orientation; otherwise, External Device Port may be damaged. Check contours and orientation of Micro USB plug, then insert it with tabs (○) facing down.



Extend blades and plug AC Charger into AC outlet

- Charging starts and Notification Lamp illuminates.
- · Notification Lamp goes out when charge is full.



After charging, remove Micro USB plug from External Device Port, then unplug AC Charger and retract blades

## Charging by PC

Connect handset to a PC with Micro USB Cable (SHDDL1; optional accessory).

- · Make sure that PC is turned on.
- Handset may not charge or charge slowly depending on connection/PC status.
- $\cdot$  Never connect Micro USB plug while handset or Micro USB Cable is wet.





Insert Micro USB plug of Micro USB Cable into External Device Port



 Insert Micro USB plug in correct orientation; otherwise, External Device Port may be damaged. Check contours and orientation of Micro USB plug, then insert it with tabs (O) facing down.



Insert USB plug of Micro USB Cable into PC USB port



- Charging starts and Notification Lamp illuminates.
- $\cdot$  Notification Lamp goes out when charge is full.




After charging, remove Micro USB Cable from handset and PC

# Power On/Off

## Power On

1

Long Press U until SHARP logo appears



Handset powers on, and Welcome sheet (lock screen) appears after a while.

- · If confirmation appears, follow onscreen prompts.
- A screen for initial settings may appear the first time handset is powered on. See "Handset Initial Settings" for details.

2

Drag 🗟 up



Home Screen (Feel Home) appears.

- The appearance of icon may differ depending on handset settings.
- · If confirmation appears, follow onscreen prompts.

## Power Off

1

**心** (Long Press)



2

Power off



3

OK)



Handset shuts down.

# **Touchscreen Operations**

Handset uses a touchscreen-type Display. Operate with your fingers on Display.

# Touchscreen Usage Cautions

#### Touchscreen Operation

To prevent malfunctions, observe the following.

- $\cdot$  Do not use with wet fingers or if Display is wet. If Display is wet, wipe it with a soft cloth.
- Do not use with gloves/long fingernails, pens, pencils or sharp objects.
- $\cdot$  Do not use with objects on/against Display.

#### Display Care

Do not place a sticker or shield (commercially-available protective film, privacy protector shield, etc.) on Display.

#### In Case of Unexpected Touchscreen Response

If handset initiates operation without Touchscreen (Display) being operated or does not respond after Touchscreen being operated, try the following.

(Display turns off) (Display turns on) (Display turns on)

#### Tap

Contact Display lightly and briefly.



# Touch & Hold

Contact Display lightly; release finger when screen changes.



### Drag

Touch icon or other item lightly, move it where desired, and release finger.




#### Flick

Contact Display lightly, then brush screen up/down or left/right.



#### Pinch/Spread

Contact Display lightly, then move fingers toward each other (Pinch) or away from each other (Spread).



# Handset Initial Settings

A screen for language selection may appear the first time handset is powered on. Here, make initial settings for Wi-Fi, a Google  $^{\text{TM}}$  Account, etc.

Insert USIM Card before powering on handset.

# Making Initial Settings

Initial setting items and screen content may differ depending on contract conditions and handset settings. Follow onscreen prompts.

• To skip to the next setting, Tap SKIP in each screen.



Tap language 
NEXT



Wi-Fi setup screen appears.



[NEXT]



Select Wi-Fi screen appears.



Tap access point → Enter password → CONNECT →



- ₩ Wi-Fi setup is complete; handset restarts.
- To skip Wi-Fi settings, Tap SKIP, then follow onscreen prompts. Handset restarts after operation.







- Tap & Go screen appears.
- · To change language, Drag it up/down.
- $\cdot$  If Wi-Fi is not set, Select Wi-Fi screen appears. Follow onscreen prompts.







- Add your account appears.
- · To learn about Tap & Go, Tap Learn more .



Or create a new account  $\bigcirc$  Follow onscreen prompts



- My SoftBank setting screen appears.
- To use your existing Google Account, Tap Enter your email , then follow onscreen prompts.
- $\cdot$  See "Google Account" for details on a Google Account.



Follow onscreen prompts



Initial settings are made.

# Basic Operations

Basic Operations	. 20
Applications	.22
Activating Applications Quickly (Quick Launcher)	.23
Handset Phone Number	26
Using Manner Mode	26
Using Airplane Mode	.27
Text Entry	.27
Google Account	. 29
Google Play	31
Security Codes	. 33
USIM PIN	.35
Turning Off Display (Screen Lock)	.36
Updating Software	. 37
On susting the Cuinning Handast (Cuin Mania)	70

# **Basic Operations**

#### Welcome Sheet (Lock Screen)

After a period of inactivity, Display turns off to save battery power (Screen lock active).

Press 0 to open Welcome sheet (lock screen); screen can be unlocked.

· Welcome sheet (lock screen) also appears at power on.



To unlock screen and use handset, Drag up. See "Welcome Sheet (Lock Screen) Basics" for details.



#### Home Screen (Feel Home)

Most operations start from Home Screen. Activate applications, check notifications, change handset settings, etc. Feel Home appears as Home Screen by default.

· Activate most applications from app sheet in Feel Home. See "Home Screen (Feel Home) Basics" for details.



- · To return to Feel Home, Tap O at Display bottom.
- $\cdot$  In the User Guide, most operation descriptions are for Feel Home.

## Navigation Bar

Icons appear on Navigation Bar (Display bottom). See below for icon descriptions.



Name	Description
1 Back key	Return to the previous screen.
2 Home key	Return to Home Screen.¹
3 Recent apps key	Activate/exit Quick Launcher. <sup>2</sup> Touch & Hold to open/close Notifications Window.
4 Back key	Close keyboard. <sup>3</sup>
<b>5</b> Keyboard key	Change keyboard/input method. <sup>3</sup>

- 1 Drag up for Google Search.
- 2 Application usage history can be set to appear instead of Quick Launcher.
- 3 Appears when keyboard is open.

# Selecting Options and Navigating Screens

Tap item, icon, key, etc. to open menu/window or execute corresponding function/operation.



 $^{\cdot}$  To return to the previous screen, Tap  $\bigcirc$  .

## Menu Operations

Tap **i** at Display top or bottom to open menu or settings.



 $\cdot$  In some windows, Touch & Hold for menu or settings.



## Handset Settings and Making Settings

In app sheet, Tap 🌼 (Settings) to customize the operation of handset functions.



· Checkbox ( ✓ / □ ) or switch ( ● / □ ) appears for some options. Tap to enable ( ✓ / ● ) or disable ( □ / □ ) option.



Drag/Flick slider, spinner, etc. to adjust some settings. If available, Tap or for additional settings.



# Portrait Orientation & Landscape Orientation

The screen changes to portrait orientation when handset is rotated sideways.

- $\cdot$  Depending on the current screen, the orientation may not change even by changing handset orientation.
- · Handset can be set so that the screen does not change from vertical to horizontal orientation while handset is held. See "Changing Grip Magic Settings" for details.



## One-Hand Operation (Shrinking Screen)

Shrink screen for easier one-hand operation.

- · Open shrunk screen along the left or right edge of Display.
- $\cdot$  Some screens may not be shrunk.
- Full-screen view is restored when screen orientation is changed to horizontal or when Display turns off.



Drag (to open along the left edge) or (to open along the right edge) up



- Screen shrinks.
- · If confirmation appears, follow onscreen prompts.

## Shrunk Screen Operations

Moving Shrunk Screen

In shrunk screen, 
 at upper right 
 Drag screen up/down/left/right 
 OK

Enlarging/Reducing Shrunk Screen Size

Restoring Full-Screen View

In shrunk screen, Drag O up S Keep finger on Display and Drag left/right

· When Dragging left/right, Drag in the direction of shrunk screen.

## Capturing Screenshots

Long Press o and Volume Down Key at the same time to capture a screenshot of the current screen.

- · May be unavailable for some applications.
- · Open captured screenshots from 📙 (Album), etc.
- Alternatively, use Clip Now and slide your finger along the top edge of Display to capture a screenshot. See "Capturing Screenshots (Clip Now)" for details.

# **Applications**

## Activating Applications



In app sheet, Tap application



- Application activates.
- · If confirmation appears, follow onscreen prompts.

#### Activating Applications in Folders

In Feel Home, some applications may be collected in folders (e.g., ]]). To activate applications in folders:

Tap folder 🔵 Tap application

• To close folder without activating application, Tap

#### **Exiting Applications**





- Feel Home returns and application exits.
- Feel Home also returns when Tapping O on Navigation
  Bar, but application does not exit. In this case, activate
  Quick Launcher, open application from History, then exit it.
  See "Activating Recently Used Applications (History)" for

# Where to Obtain Applications & Updates

Use Google Play™ to obtain new applications or update installed ones. See "Google Play" for details.

# Activating Applications Quickly (Quick Launcher)

Activate recently used applications and favorite applications quickly. In addition, activate mini-applications and miniwidgets to use multiple applications at the same time.

## Quick Launcher

Use the following options to activate applications from Quick Launcher.

Option	Description
History	Activate recently used application.
Favorites	Activate application saved in Favorites.
Mini apps	Activate mini-application or mini-widget while using applications.

## Activating Recently Used Applications (History)







- 🔯 Quick Launcher (History) opens.
- $\cdot$  "History" appears green when selected; if not, Tap



#### Tap application



- Application activates.
- · Flick left/right for hidden applications.

## History Operations

Deleting All Application History Items

In Quick Launcher (History), Clear all



Deleting Application History Items Individually

In Quick Launcher (History), Touch & Hold application to delete 
Clear from list

#### Activating Frequently-Used Applications (Favorites)







Quick Launcher (Favorites) opens.

2

Tap application in Favorites



Application activates.

· Flick left/right in Favorites for hidden applications.

## **Favorites Operations**

#### Adding Applications and Functions to Favorites

In Quick Launcher (Favorites), 🕕 🗦 Tap item type (e.g., Application )  $\Rightarrow$  Tap application, function, etc.

· If confirmation appears, follow onscreen prompts.

#### Deleting Favorites Items

In Quick Launcher (Favorites), Touch & Hold application, function, etc. to delete 
Peel off

#### Activating Multiple Applications (Mini-Applications)

While using applications, activate another application (miniapplication/mini-widget) in a small separate window.

- · Mini-application/mini-widget can be activated in Feel Home
- $\cdot$  Mini-application/mini-widget may not activate depending on current application window.







Quick Launcher (Mini apps) opens.



Tap mini-application or mini-widget in Mini apps



- Mini-application window or mini-widget window opens.
- · Follow onscreen prompts.

#### Use of Mini-Applications/Mini-Widgets

#### Mini-Widgets

There is no mini-widget in Mini apps by default. Add from Mini apps.

#### Operation of Mini-Applications/Mini-Widgets

Operation of each mini-application/mini-widget is different. Most operations are described in "Mini-Application/Mini-Widget Operations" below. If description does not apply, follow onscreen prompts.

# Mini-Application/Mini-Widget Operations

#### Exiting Mini-Application/Mini-Widget

In mini-application/mini-widget window,



#### Moving Mini-Application/Mini-Widget Window

Drag mini-application/mini-widget window by frame to new location

#### Minimizing Mini-Application/Mini-Widget Window

In mini-application/mini-widget window, 🔋 🧇

#### Minimize

- · Alternatively, for some applications, Tap 🔼 .
- · To restore original size, Tap 🛂 .

#### Adding Mini-Applications/Mini-Widgets

In Quick Launcher (Mini apps), 🕂 🔷 Add mini









# mini-widget to add

#### Deleting Mini-Applications/Mini-Widgets

In Quick Launcher (Mini apps), Touch & Hold miniapplication/mini-widget to delete 

Peel off

#### Adding Mini-Widgets in Mini-Widget Window

In mini-widget window, 🔋 🗦 Add widget 🗦 Tap widget to add

· Flick up/down for hidden widgets.

## Deleting Mini-Widget from Mini-Widget Window

In mini-widget window, 🔋 🗦 Remove widget 🗦 Tap widget to delete ( <a> )</a> <a> )</a> <a> DELETE</a>

### Setting Mini-Widget Background Color

In mini-widget window, : 


Background color Black / White / Translucence

#### Using Mini-Application/Mini-Widget Data and Information with Other Application

Touch & Hold mini-application/mini-widget window 🔵 Drag data or information to other application

Showing Data Selection Screen from Mini-Application Window (During Video Playback)

In mini-application window (during video playback),



Mini-application/mini-widget may not work properly depending on application to be used at the same time.

## Handset Phone Number

# Checking Your Phone Number


1

In app sheet, (Settings) (Settings) Profile



- Profile window opens.
- · Handset number appears in Own phone number field.

#### Profile Operations



# Using Manner Mode

Mute ringtones and other handset sounds to avoid disturbing others around you.

## Activating Manner Mode

· Camera shutter sound, video recording tones, music, video/ game sounds, etc. still play even in Manner mode.



In Welcome sheet (lock screen) or Feel Home, Long Press Volume Down Key

Manner mode activates.

#### Manner Mode Operations

#### Canceling Manner Mode

In Welcome sheet (lock screen) or Feel Home, Long Press Volume Down Key

#### Activating Manner Mode by Selecting Option

Drag Status Bar down for Notifications Window 🕤 📓
(Manner mode) 🕤 Standard manner / Silent manner

# Using Airplane Mode

Leaving power on, suspend signal-transmitting functions.

## Activating Airplane Mode

- 1
- **じ** (Long Press)
- 2

Airplane mode



- Airplane mode activates.
- Canceling Airplane Mode



# Airplane Mode Caution

Activating Airplane mode disables Wi-Fi and Bluetooth®, interrupting corresponding transmissions. Wi-Fi/Bluetooth® connections can be used even in Airplane mode by enabling Wi-Fi/Bluetooth® after activating Airplane mode; make sure that such connection/ transmission is allowed in your current location before use.

# Text Entry

## Keyboards

Use onscreen keyboards for text entry. In 12-key Keyboard, multiple characters are assigned to each key. In QWERTY Keyboard, a single letter is assigned to each key.

- · Tap Text entry field for keyboard. To hide it, Tap  $\nabla$  .
- · Text entry descriptions are for S-Shoin (default input method).

## Switching Keyboards

In a text entry window, 🏮 🗦 Input UI










QWERTY keyboard or [12 keyboard]






Keyboard is switched.

## 12-Key Keyboard Layout



- 1 Enter characters.
- 2 Undo conversion; reverse-toggle character options before confirming entry.
- Backspace cursor.
- 4 Move keyboard in the arrow direction.
- 5 Current entry mode
- 6 Delete characters.
- 7 Advance cursor; add space at text end.
- 8 Show text entry options. (During text entry, convert hiragana.)
- 9 Insert line break; confirm current characters.
- 10 Enter pictograms, symbols, or emoticons; switch conversion options.
- 11 Toggle entry modes.
- 12 Enter space; toggle case; add " or ° for hiragana.

## QWERTY Keyboard Layout



- 1 Enter characters.
- 2 Toggle case.
- 3 Toggle entry modes.
- 4 Enter pictograms, symbols, or emoticons; switch conversion options.
- 5 Undo conversion.
- 6 Open text entry options.
- Current entry mode
- 8 Delete characters.
- 9 Insert line break; confirm current characters.
- 10 Advance cursor; add space at text end.
- 11 Backspace cursor.
- 12 Enter space. (During text entry, convert hiragana.)

## Switching Entry Modes

1

In a text entry window,



Keyboard interface changes accordingly. Current entry mode indicator, such as 個 (Half Alphabet) or 鹵 (Hiragana/Kanji), appears.

• Tap 🔤 to toggle Half Numeric, Hiragana/Kanji, and Half Alphabet modes. Flick right to toggle these in reverse order.

# Using Other Entry Modes

In a text entry window, Flick 

■ up 

Tap entry mode

Keyboard interface changes accordingly.

#### **Entering Letters**


In 12-key Keyboard, to enter Phone:

· Entry in Half Alphabet is described.










- $\dot{}$  To toggle case, type a letter and Tap  $_{A\dot{\Leftrightarrow}a}$  . Tap as required to toggle case.
- · Alternatively, for character entry, Touch & Hold key for guide instead of Tapping key repeatedly. See "Flick Input" for details.

## Flick Input

In 12-key Keyboard, Flick key for target character (instead of Tapping key repeatedly).

· Touch & Hold key for guide; Flick toward target character to enter.



Target Character	Operation
р	Tap Pors once.
q	Touch Pors and Flick left.
r	Touch <sup>Pors</sup> and Flick up.
S	Touch <sup>Pors</sup> and Flick right.
7	Touch PQRS and Flick down.

• To enable/disable key preview and Flick input guide, in a text entry window, Tap 

Display / Layout 

Key input guide .

# Google Account

Use a Google Account and get more convenience with Google services. A Google Account is required to use some services or fully use some applications.

## Google Account Cautions

#### Google Account Email Address & Password

Do not forget your Google Account email address and password.

#### Google Account Operations & User Interface

Operations and user interface are subject to change due to automatic application updates or other reasons.

## Creating a Google Account

1

In app sheet, 🏩 (Settings) 🔵 Accounts



2

Add account



3

[Google]



Add your account appears.



Or create a new account



5

Enter first name 

Enter last name 

NEXT



6

Enter username (email address) 
NEXT





 $\cdot$  If confirmation appears, follow onscreen prompts.



Enter password 
Re-enter password 
NEXT



8

Enter phone number for recovery 

NEXT





[VERIFY]



SMS will be sent to entered phone number.



[ AGREE



11



12

Select whether to enable data backup  $\bigcirc$  Select whether to receive news and offers from Google Play 🔵 NEXT









- An account is created.
- · To set payment information, Tap Add credit or debit card / Enable SoftBank billing / Redeem 🗦 NEXT . Follow onscreen prompts.
- · If confirmation appears, follow onscreen prompts.

#### Signing in to a Google Account

If an application requires a Google Account, Add your account appears. Sign in with an existing Google Account to use the application.

1

In Add your account, enter email address 
NEXT





Enter password 
NEXT



3

Follow onscreen prompts

You are signed in to your Google Account.

# Google Play

Download a variety of applications (free/paid) from Google Play. Change the setting of downloaded applications to enable manual or automatic updates. Sign in to a Google Account beforehand.

## Google Play Cautions

#### Application Installation Disclaimer

Many different kinds of applications can be installed on handset from Google Play (provided by Google Inc.). SoftBank Corp. is not responsible in any way for userinstalled applications (quality, reliability, legality, fitness for a purpose, credibility, accuracy, etc.) or resulting malfunctions (viruses, etc.).

#### Google Play Operations & User Interface

Operations and user interface are subject to change due to automatic application updates or other reasons.

#### Installing Free Applications

In app sheet, (Play Store)



- Google Play opens.
- · If confirmation appears, follow onscreen prompts.



Tap free application → INSTALL → ACCEPT



## Purchasing Applications





- Google Play opens.
- · If confirmation appears, follow onscreen prompts.



Tap paid application → Tap price → Follow onscreen prompts

Application downloads and installs.

## Purchased Applications

#### Payment

Pay once. Re-downloads of uninstalled applications are free of charge.

#### Use on Other Android Devices

Install same application on other Android devices under same Google Account at no added cost.

#### Refund Requests

Request refunds within designated period. Returned applications are deleted from handset; no payment is required. One refund request per application.

· See "Getting Help with Google Play" for details.

### Application Purchase Disclaimer

Purchase applications at your own risk. SoftBank Corp. is not responsible for any disadvantage resulting for user or third parties.

## Updating Installed Applications





- Google Play opens.
- · If confirmation appears, follow onscreen prompts.








3

Tap application ( UPDATE)

- Application downloads and installs.
- · If confirmation appears, follow onscreen prompts.

### Making Application Update Settings



## **Uninstalling Applications**

Applications installed via Google Play can be uninstalled.

1





- Google Play opens.
- · If confirmation appears, follow onscreen prompts.









3

Tap application → UNINSTALL → OK





Application uninstalls.

# Getting Help with Google Play







- Google Play Help window opens.
- 2

Follow onscreen prompts

A description for each item appears.

# Security Codes

## Code Types

The following codes are required for handset use.

Code	Description
Center Access Code	Four-digit code you have set in subscription contract; necessary to change subscription details, use optional services from landlines, etc.
Operation Password	A user-defined code necessary to use settings and applications related to security, personal information, etc.; unset by default.

#### Code Cautions

Do not forget Center Access Code; write it down if necessary. If you forget the code, contact us for recovery. For details, contact SoftBank Customer Support, General

Be careful not to reveal security codes to others. If misused by others, SoftBank Corp. is not liable for any resulting damages.

# Setting Operation Password



















Password Setting window opens.



Enter Operation Password 
OK





4

Re-enter Operation Password 🔵 OK 🔵 OK











# Operation Password Usage Notes

#### Changing Operation Password

Refer to the steps for setting Operation Password. (Current Operation Password is required to proceed.)

#### Resetting Operation Password

If prompted for Operation Password, Tap PASSWORD

RESET then Tap OK . Follow onscreen prompts.

· My SoftBank authentication is required to reset Operation Password. Set My SoftBank authentication from 🧕 (My SoftBankプラス).

#### **USIM PIN**

#### USIM PIN and USIM Card Lock

When USIM card lock is enabled, PIN (a code for USIM Card) is required for handset use each time handset is powered on; helps prevent unauthorized use by others.

- $\cdot$  Enable USIM card lock by enabling PIN.
- · PIN is 9999 by default.

#### PIN Entry Cautions


PIN entry is required when changing PIN, when powering handset on with USIM card lock enabled, etc.

- Entering incorrect PIN three consecutive times activates PIN Lock. To cancel, Personal Unblocking Key (PUK) is required; contact SoftBank Customer Support, General Information.
- Entering incorrect PUK ten consecutive times activates PUK Lock, disabling handset. For recovery, USIM Card must be reissued at a SoftBank Shop (fees apply).

#### **Enabling USIM PIN**

When PIN (a code for USIM Card) is enabled, PIN entry is required for handset use each time handset is powered on with USIM Card installed.







Lock & Security menu opens.







PIN is enabled (USIM card lock is enabled).

#### Disabling USIM Card Lock



#### Operation at Power On

When USIM card lock is enabled, PIN entry window appears each time handset is powered on. To use handset:



Tap PIN entry field



2

Enter PIN 🔵 OK



Handset is usable.

#### Changing USIM PIN

Enable USIM card lock first. See "Enabling USIM PIN" for details.



In app sheet, ♠ (Settings) ➡ Other settings ➡ Lock & Security



2



PIN is changed.

#### Turning Off Display (Screen Lock)

#### Screen Lock

After a period of inactivity, Display turns off to save battery power (Screen lock active).

Screen lock prevents accidental Touchscreen operation.

- $\dot{}$  To activate Screen lock manually, Press  $\boxed{\textbf{0}}$  when Display is turned on.
- Set handset to activate Screen lock when handset is placed flat as needed. See "On/Off with Motion Settings" for details.

# If Screen Lock Activates while Playing Music

Music continues to play. For operation, Press 🛈 to open Welcome sheet (lock screen) and use operation panel (operations may vary depending on application).

#### **Unlocking Screen**





Welcome sheet (lock screen) opens.

 $\cdot$  Welcome sheet (lock screen) may not open depending on handset settings; use handset normally.



In Welcome sheet (lock screen), Drag 🔒 up





- · The appearance of icon may differ depending on handset settings.
- · If confirmation appears, follow onscreen prompts.
- · For enhanced security, set handset to require pattern drawing or password/Lock No. passcode entry for unlocking screen as needed. See "Lock & Security Settings" for details.

#### Other Methods for Turning On Display

Set Display to turn on when handset is gripped (Grip Magic) or when Display is Flicked (Sweep ON). See "Operating by Gripping Handset (Grip Magic)" and "On/Off with Motion Settings" for details.

#### **Updating Software**

#### Software Updates

At specified time, handset automatically checks for/downloads firmware updates as required.

- $\cdot$  Software Update cannot be performed if application or function is in use.
- · Alternatively, update firmware manually.

#### Software Update Cautions

#### **Applications**

Applications may be updated or newly added, or names, icons, operations and user interfaces of applications may be changed.

#### **During Update**

Handset cannot be used until Software Update completes; it may take some time to complete.

#### Data Backup

Saved data may be lost depending on condition of handset (malfunctioning, damaged, water seepage, etc.). It is recommended that you back up important data before updating software. SoftBank Corp. is not responsible for damages from loss of data.

#### **Updating Software Manually**

Operate handset where signal reception is good and without changing location. Also operate with adequate battery charge. Signal becoming weak or Battery becoming low during an update may cause an update failure.

- · Remove Micro USB Cable (optional accessory) from handset beforehand; otherwise, Software Update may not complete properly.
- · An update failure may disable handset.



In app sheet, 🌼 (Settings) 🕣 About phone











#### Software update



Software update menu opens.







Software update 🗦 YES 🗦 Follow onscreen prompts



Software Update starts.

#### Software Update Operations

#### Enabling/Disabling Automatic Updates

In Software update menu, Automatic Update Settings









#### Changing Automatic Update Start Time

In Software update menu, Update Schedule Settings 🗦









#### Operating by Gripping Handset (Grip Magic)

Set actions that occur when handset is picked up or set down.

#### Grip Magic

Use Grip Magic to perform preset actions when grasping Grip Sensor Areas or when setting down handset and releasing Grip Sensor Areas.



The following actions are set by default.

#### Item Action Display turns on when handset is picked Turn screen up (Grip Sensor Areas grasped) with on by holding Screen lock active. Screen does not change from vertical to Deterrence horizontal orientation automatically while rotate screen handset is held.

· Change Grip Magic actions as needed. See "Changing Grip Magic Settings" for details.

#### **Grip Magic Cautions**

#### Grasping Grip Sensor

Grip Sensor responds to touch on both the right and left of handset. As Grip Sensor does not respond when touched on only one side, be sure to touch Grip Sensor on both sides.

#### Releasing Grip Sensor

Release Grip Sensor on both sides. If one side remains contacted, Grip Sensor will continue to react.

#### General Use

Grip Magic may not function properly in the following

- · Operation with gloves worn
- $\boldsymbol{\cdot}$  Operation while a metal object is in contact with Grip
- $\cdot$  Operation when handset is wet
- · Attaching or detaching a cover while Grip Magic is enabled

(Disable Grip Magic, then enable it again.)

#### Changing Grip Magic Settings

1

In app sheet, 🌼 (Settings)



2

Useful



Useful window opens.

3

Grip magic



Grip magic window opens.

4

Set each item

Setting is complete.

Grip Magic Operations

Enabling/Disabling Grip Magic

In Grip magic window, On / Off

- · Tap On to disable ( Off ), Off to enable ( On ).
- · If confirmation appears, follow onscreen prompts.

# Setting Whether to Turn On Display when Handset Picked Up

In Grip magic window, Turn screen on by holding

- Tap (Turn screen on by holding) to toggle on (♥)/off(□).
- · If handset is picked up immediately after (about two seconds) Pressing 🐧 to turn Display off, Display may not turn on when handset is picked up.
- If Proximity/Light Sensor is covered by a hand or other object, Display may not turn on even when Grip Sensor Areas are touched, or operation may not be possible. Also, Display may turn off regardless of handset settings.

Setting Whether to Minimize Volume and Use Vibrator when Handset Picked Up for Incoming Call

In Grip magic window, Volume down for incoming calls

· Tap Volume down for incoming calls to toggle on

(✓)/off(□).

Setting Whether to Prevent Vertical to Horizontal Screen Change while Handset Held

In Grip magic window, Deterrence rotate screen

- Tap (Deterrence rotate screen) to toggle on ( ✓ )/off
   ( □ ).
- $\boldsymbol{\cdot}$  The feature may not follow settings with certain applications.

Setting Whether Handset Vibrates for New Notification Indicator when Handset Picked Up with Display Off

In Grip magic window, Notify by vibrating (

Tap to toggle on (
), to toggle off
(
).

Setting Number of Times that Handset Vibrates for New Notification

In Grip magic window, Notify by vibrating (a) Notify times (b) Only once / Every time till notification confirmation

 $\cdot$  Available when Notify by vibrating is enabled.

Specifying Applications for which Handset Vibrates

In Grip magic window, Notify by vibrating 


Notification application setting 

Add apps 

Tap application ( ✓ ) 

Add apps

 $\cdot$  Available when Notify by vibrating is enabled.



# Handset Interface

Welcome Sheet (Lock Screen) Basics	42
Home Screen (Feel Home) Basics	43
Icons at Display Top (Status Bar)	44
Checking Handset Status & Notifications (Notifications	S
Window)	46
Customizing Welcome Sheet (Lock Screen)	47
Customizing Home Screen (Feel Home)	49
Disabling Touch Operation Temporarily (Childlock)5	54
Copying Onscreen Text (Copy Anywhere)	55
Writing Notes on Display (KAKU Notepad)	55
Conturing Screenshots (Clin Now)	E 6

#### Welcome Sheet (Lock Screen) Basics

Welcome sheet (lock screen) appears at power on or when **(**) is Pressed while Display is turned off (Screen lock active).

#### Welcome Sheet (Lock Screen) Layout



- 1 Wallpaper 1
- 2 Notifications of missed calls and new messages or from applications, etc. appear here.
- 3 Tap to show owner information.<sup>2</sup>
- 4 Drag up for applications, settings, etc.
- 5 Drag up to unlock screen.
- 6 Date and time, weather, messages from emopa, etc. appear here (Info area).1
- 7 Drag up to activate SH Camera.
- 1 Flick left/right to toggle view.
- 2 Set owner information beforehand. See "Lock & Security Settings" for details.

#### **Activating Applications**



In Welcome sheet (lock screen), Drag up





Application window opens.



#### Tap application



- Application activates.
- $\cdot$  Change assigned applications as needed. See "Customizing Welcome Sheet (Lock Screen)" for details.
- Viewing Tutorial on Welcome Sheet (Lock Screen)

In application window, 🖪 (Let's Try!) 🔵 Follow onscreen prompts

# Notifications (Missed Calls, New Messages, Etc.)

Notification appears in Welcome sheet (lock screen) for missed calls, new messages and information from applications.



Tap notification twice



- Corresponding window opens.
- · Follow onscreen prompts.

#### Notification Count & Grouping

Notifications may be grouped depending on the number of unread notifications. To show all notifications, Tap the bottom notification twice.

#### Home Screen (Feel Home) Basics

Most operations start from Home Screen. Feel Home appears as Home Screen by default.

In the User Guide, most operation descriptions are for Feel  $\ensuremath{\mathsf{Home}}.$ 

#### Toggling Sheets & Pages

Feel Home consists of two sheets; activate applications in app sheet, and access widgets or save shortcuts to frequentlyused applications in desktop sheet.

Flick left/right to toggle sheets.



App sheet consists of multiple pages. Flick up/down to toggle pages.




· Adding shortcuts to desktop sheet may add pages to it. Flick up/down to toggle pages.

#### App Sheet Layout



- 1 Activate applications.
- 2 Tap to toggle pages; large dot indicates current page position.
- 3 Dock (activate applications)

#### Desktop Sheet Layout



- 1 Use widgets.
- 2 Activate applications from shortcuts.
- 3 Tap to toggle pages; large dot indicates current page position.<sup>1</sup>
- 4 Dock (activate applications)
- 1 Available when application shortcuts and widgets are added. See "Adding Shortcuts" and "Adding Widgets" for details.

#### Icons at Display Top (Status Bar)

Indicators (new message notification, handset status, etc.) appear on Status Bar (at the top of Display).

#### Status Bar Layout



- 1 Notifications, warnings, etc. appear here. (Notification Indicators)
- 2 Handset status and other information appear here. (Status Indicators)

#### Main Notification Indicators

Notification Indicators appear on the left.

 $\cdot$  Notification Indicators do not appear in Welcome sheet (lock screen).

Indicator	Description
<b>@</b>	Guide Available <sup>1</sup>
Ø.	Bright Keep On
<b>(1)</b>	Urgent News
<u>U</u>	Call Arriving/in Progress
U	Call on Hold
×	Missed Call
<u>•</u>	New Answer Phone Message
00	New Voicemail
<b>3</b>	New SMS/S! Mail
abla	New Email
M	New Gmail
<u></u>	Unchecked Alarm
31	Calendar Event
<b>7</b>	One Seg Viewing in Progress
<b>2</b>	One Seg Recording in Progress
Ĵ	Application Update Available
9	Application Installation Complete
Ū	Data Downloading
<b>\$</b> ₁	Bluetooth® File Reception Request
ntát	SD Card Unmounted
nan <b>*</b>	Readying SD Card
Ψ	Connected via USB
	Screenshot Captured
	Screenshot Failed
	Screenshot Captured (Clip Now)
\$	Screenshot Failed (Clip Now)
	More Notifications
T	Mobile Light On

1 Drag Status Bar down and launch Guide from Notifications Window.

#### Main Status Indicators

Status Indicators appear on the right.

Indicator	Description
	Battery Strength
<b>3</b>	Charging
.il	Signal Strength
311	No Signal (4G LTE/4G/3G)
4G	4G LTE/4G Data in Use¹
3G	3G Data in Use
<b>★</b>	Airplane Mode
<u>হ</u>	Wi-Fi Connected
8	Bluetooth® On
*	Bluetooth® Connected
<b>~</b>	Manner (Standard) Mode
∢×	Manner (Silent) Mode
•	Getting Location Information
00	Answer Phone Set
<del>jo</del> o	Answer Phone Set (Message Recorded)
<b>©</b>	Alarm Set
<b>@</b>	NFC/Osaifu-Keitai® Lock Set
<b>-</b> -	NFC/Osaifu-Keitai® Lock Set (USIM Card only)²
あ	Hiragana/Kanji Mode
AB	Half Alphabet Mode
12	Half Numeric Mode
A	Full Alphabet Mode
1	Full Numeric Mode
区	Character Code Mode

- Corresponding indicator appears when handset is connected to FDD-LTE (SoftBank 4G LTE) or AXGP (SoftBank 4G).
   Between these Networks, handset connects to SoftBank 4G whenever possible.
- 2 Appears when a USIM Card with NFC locked on another mobile phone is then installed in handset.

#### Checking Handset Status & Notifications (Notifications Window)

Open notifications, check handset status or change various settings.

#### Opening Notifications Window

Drag Status Bar down



Notifications Window opens.

· To close Notifications Window, Tap

#### Notifications Window Layout



- Setting keys
- 2 Drag down to show second and subsequent lines of Setting keys.
- 3 Notifications and active functions
- 4 Use corresponding functions.
- **5** Open Settings.
- 6 Delete all notifications and close Notifications Window.

#### Notifications Window Operations

#### Selecting and Deleting Notifications

In Notifications Window, Flick notification left/right

 $\cdot$  Some notifications may not be deleted.

#### Blocking Notifications from Specific **Applications**

In Notifications Window, Touch & Hold notification 🗦



- · Tap Block to toggle on ( )/off ( ).
- · May be unavailable depending on application.

#### Showing Notifications from Specific Applications at the Top


In Notifications Window, Touch & Hold notification 🔷



( Priority ( )

- · Tap Priority to toggle on ( )/off ( ).
- · Available when Block is disabled ( ).

#### Setting Keys



- 1 Set Manner mode option.
- 2 Toggle Wi-Fi on/off.
- 3 Toggle Bluetooth® on/off.
- 4 Enable/disable Auto-rotate screen.
- 5 Set Display brightness.
- **6** Drag down to show second and subsequent lines of Setting keys.
- 7 Toggle Energy saving settings on/off.
- 8 Set Bright Keep.
- Manage use of location information.
- 10 Enable/disable account sync.
- 11 Open Wireless output menu.
- 12 Enable/disable Reader/Writer, P2P.
- 13 Enable/disable Airplane mode.
- 14 Turn on/off Mobile Light.
- **15** Drag up to hide second and subsequent lines of Setting keys.
- 16 Toggle Grip Magic on/off.
- 17 Open window for customizing Setting keys.

#### Customizing Setting Keys

#### Rearranging Setting Keys

#### Deleting Setting Keys

In Notifications Window, Customize → Drag icon to unused key area (right above Navigation Bar) → ✓

#### Adding Setting Keys

In Notifications Window, Customize Drag icon from unused key area (right above Navigation Bar) to target location Total

# Customizing Welcome Sheet (Lock Screen)

Set Wallpaper for Welcome sheet (lock screen) and change assigned applications (shortcuts).

#### Setting Wallpaper

1

In Welcome sheet (lock screen), Drag 🔋 up



2

(Welcome sheet)



3

Welcome Sheet wallpaper



Welcome sheet wallpaper menu opens.

4

Tap > in Image field > Tap page (e.g., Page 1)

5

Tap option (e.g., Contents Manager(wallpaper) ) → Follow onscreen prompts

Setting is complete.

• To remove set Wallpaper, Tap To cancel the setting when Tapping an option.

Welcome Sheet (Lock Screen)Operations

Setting Live Wallpaper to Welcome Sheet (Lock Screen)

In Welcome sheet wallpaper menu, > in Live wallpaper field > Tap image > SET WALLPAPER

 $\cdot$  For some Wallpapers, additional settings are available. Follow onscreen prompts.

Applying Feel Home Wallpaper Setting to Welcome Sheet (Lock Screen)

In Welcome sheet wallpaper menu, To reflect the

wallpaper setting

# Changing Assigned Applications (Shortcuts)

Change applications (shortcuts) that appear when Dragging 
up.



In Welcome sheet (lock screen), Drag 📱 up



2

(Welcome sheet)



3

[Shortcut]



4

Tap shortcut to change



5

Tap shortcut type (e.g., Application )



6

Tap application/function to activate with shortcut

Shortcut is set.

 $\cdot$  If confirmation appears, follow onscreen prompts.

# Customizing Home Screen (Feel Home)

Set Wallpaper and theme for Feel Home, rearrange icons, change layout of icons as well as add folders, shortcuts and widgets.

#### Setting Wallpaper



In Feel Home, Touch & Hold open area



Menu opens.

2

[Wallpaper Setting]



3

Tap option (e.g., Album(wallpaper) ) → Follow onscreen prompts

Setting is complete.

#### Setting Theme and View



In Feel Home, Touch & Hold open area



Menu opens.

2

Home settings



Mome settings window opens.

3

Tap theme (Standard, Color pop or Natural)



4


Tap color, pattern, etc. 🗦 🔘



Theme is set.

· For Standard , Tap Visible / Invisible to show/hide icon background as needed.

#### Home Setting Operations



#### Rearranging App Sheet Pages

1

In app sheet, Touch & Hold open area



Menu opens.

2

[Edit pages]



3

Drag page up/down to target location



4

[MOVE]



Page is moved.

#### Moving Icons/Widgets



In Feel Home, Touch & Hold icon/widget



2

Drag to target location



 $\cdot$  To a folder: Drag icon to target folder.

#### Changing Icon Layout

Change layout of icons in app sheet (columns/rows per screen).



In Feel Home, Touch & Hold open area



Menu opens.

2


[Home settings]



Home settings window opens.



In Layout Setting, Simple / 3x4 / 4x5 / 5x6



- · If confirmation appears, follow onscreen prompts.
- · Select Simple for large icons and text.

#### Hiding Applications

In app sheet, Touch & Hold open area Application view setting for application to hide

Tap to show application again. Icon appears at end in app sheet.

#### Layout Setting Caution

When Layout Setting is set to Simple, desktop sheet is hidden.

#### Adding Folders

Add folders to collect icons.

 $\cdot$  Folders can also be created in desktop sheet and dock.



In Feel Home, Touch & Hold icon to place in folder



2

#### Add to new folder



Folder is added, and icon is saved in the folder.



Drag another icon to group into the folder



- 2 icons are saved in the folder.
- $\cdot$  Alternatively, to create a folder, Touch & Hold open area in Feel Home, then Tap  $\mbox{ Create Folder }$  .

#### Folder Operations

#### Changing Folder Names

In Feel Home, Tap folder 
Tap Name entry field at top of window 
Enter folder name 
Next 

O

#### Placing Icons in Folder

In Feel Home, Touch & Hold icon 🔵 Drag to folder

#### Moving Icons Out of Folder

In Feel Home, Tap folder 🔵 Touch & Hold icon 🥥 Drag

#### **Deleting Folders**

In Feel Home, Touch & Hold folder 

Peel off

 $\cdot$  Move icons out of target folder beforehand.

#### **Adding Shortcuts**

Add an application shortcut to desktop sheet.



In desktop sheet, Touch & Hold open area



Menu opens.



#### Add shortcut



Application 🔵 Tap application



Shortcut is added.

· appears for shortcut icons.

#### Shortcut Arrangement Operations

Adding Shortcut from App Sheet to Desktop Sheet

In app sheet, Touch & Hold icon 
Add shortcut

#### **Deleting Shortcuts**

In desktop sheet, Touch & Hold shortcut icon 
Peel off



#### Adding Widgets

Add Album, Calendar, etc. as follows.



Touch & Hold open area of desktop sheet



Menu opens.



Add widget



Tap widget



Widget is added.

#### Removing Widgets

In desktop sheet, Touch & Hold widget 🔵 Peel off



#### Disabling Touch Operation Temporarily (Childlock)

Set Childlock to disable touch operation temporarily and prevent unintended operation. (An incoming call cancels Childlock automatically.)

#### Setting Childlock













Childlock is set.

#### Canceling Childlock

When Display is turned off, ⋃ → Unlock screen  $\cdot$  To cancel Childlock when Display is turned on, Press υ to turn off Display first.

#### Copying Onscreen Text (Copy Anywhere)

Copy text in webpages, images, etc. on Display.

#### Using Copy Anywhere

 $\cdot$  Show content to copy on Display beforehand.











Copy Anywhere window opens.

Trace over area to copy 🥏 Drag frame to specify scan area



Text is scanned (scan result window).

3





Text is copied.

#### Copy Anywhere Operations



#### Writing Notes on Display (KAKU Notepad)

Write notes on Display and save them as images. Attach saved images to email or share them.

#### Using KAKU Notepad

 $\cdot$  Show screen to add notes to beforehand.











■ → Favorites → M (KAKU Notepad)



- Pencil palette opens.
- · If confirmation appears, follow onscreen prompts.
- · Move pencil palette by Dragging toward top or bottom of
- · If pencil palette is minimized, Tap pen or tool with (A) to return to original size.

2


Tap pen ( <a>G</a>, etc.) <a>D</a> Trace on Display to create notes



· Pencil palette is half-transparent while creating notes.




After completing notes,



- Screen with added notes is saved as an image.
- · Open saved image from Photo in Contents Manager, etc.

#### Pencil Palette Layout



- 1 Pens¹
  2 Undo
  3 Eraser
  4 Clip out¹
  5 Enter text
  6 Save
  7 Share/save
  8 Change background
  9 Stamp¹
- 1 Tap again while using to change pen color/thickness, cutout method, stamp type, etc.

#### Capturing Screenshots (Clip Now)

Slide finger along the edge of Display to capture a screenshot. Capture permanent screenshots for saving as image files or temporary screenshot for temporary use.

#### **Enabling Clip Now**



In app sheet, 🌼 (Settings) 🗦 Useful



- Useful window opens.
- 2

#### Clip Now



- Clip Now window opens.
- 3

Clip Now ( 🗸 )



- Clip Now is enabled.
- · Tap Clip Now to toggle on ( ✓ )/off ( ☐ ).

#### Capturing Permanent Screenshots

Capture screenshots for saving as files. Webpages opened from browser (e.g., Chrome) are saved with their URL.

 $\cdot$  Some screens may not be captured, or URL may not be saved.



Touch upper left (upper right) corner of Display



Screen shrinks.

2

Slide finger to the right (left) along the top edge of Display



Permanent screenshot is captured.

#### Opening Permanent Screenshots



In app sheet, 

【 (Tools) → 【 (Clip Now)



- Screenshot list appears.
- · If confirmation appears, follow onscreen prompts.




Tap screenshot



- Screenshot appears (screenshot details).
- · URL appears for webpage screenshots. Tap URL to open corresponding webpage.
- When Auto-rotate screen is enabled, rotating handset
   90 degrees changes screenshot list to screenshot details automatically.

#### Screenshot Operations



# Capturing and Opening Temporary Screenshot

Capture screenshot of webpage, etc. for saving it temporarily. Captured screenshot can be opened while using other applications as well.

· Only one temporary screenshot can be captured. It cannot be saved as a file.



Touch upper right (upper left) corner of Display  $\bigcirc$  Slide finger down along the edge of Display



Temporary screenshot is captured; portion of screenshot appears at the right (left) of Display.

2

Drag portion of screenshot at the right (left) of Display to the left (right)



- Temporary screenshot appears.
- $\cdot$  To move screenshot aside, Drag it to the right (left) of Display.
- Deleting Temporary Screenshot

While temporary screenshot appears, Touch & Hold screenshot ( ☐ appears) → Drag screenshot to ☐

#### Setting Clip Now Operation

1

In app sheet, ♦ (Settings) → Useful → Clip Now



- Clip Now window opens.
- 2

#### Slide operation settings



- Slide operation settings appear.
- 3

From upper left / From upper right 🗦 Tap option

Setting is complete.

# Phone

Calling 6	0
Optional Services6	54
Making Call Settings6	9
Address Book 7	1
Hiding Contacts (Secrecy Settings)	4

#### Calling

How to dial directly to make a call and answer a call, as well as options when a call is arriving/during a call are described. (Handset does not support Video Call.)

#### Support for VoLTE and HD Voice

Handset supports VoLTE and HD Voice for high-quality call sound. See "Using VoLTE" for details.

#### Call Caution

Handset is equipped with a "Direct Wave Receiver" which transmits sound by vibrating Display. Do not place a sticker, shield, etc. on Display; other party's voice may become hard to hear. See "Call Window Layout/In-Call Operation" for details.

#### Placing Calls

In Feel Home, 📞 (Phone) 🔵 Dial







#### Dialpad window opens.

· When missed call window appears, Tap <a> </a> . If Feel Home returns, perform 1 again.

#### 2

Use onscreen dialpad to enter number



- $\cdot$  Include area code for landline numbers.
- · To correct number, Tap 🚺 to delete digit(s), then enter correct number.



[CALL]



- Handset dials the number.
- · Call begins when other party answers.
- · For in-call operations and cautions, see "Call Window Layout/In-Call Operation."



To end call, Drag End call down



- Call ends.
- · If "Screen locked" is not shown on Display, Tap End call .
- · After calls to/from numbers not saved in Address Book, a window to add an unsaved number to Address Book appears. Follow onscreen prompts.

#### Troubleshooting

- Q. Call does not connect
- Did you dial all digits for the number? Dial all digits for numbers starting with a "O" area code, etc.
- A. Is the signal weak? Change locations and call again.

#### **Answering Calls**

When a call arrives, Incoming call window opens.



As call is arriving, Drag Answer down







- · When screen is unlocked, Tap Answer .
- · For in-call operations and cautions, see "Call Window Layout/In-Call Operation."







#### Call ends.


- · If "Screen locked" is not shown on Display, Tap End call .
- · After calls to/from numbers not saved in Address Book, a window to add an unsaved number to Address Book appears. Follow onscreen prompts.

#### Missed Calls

For unanswered calls, notification appears in Welcome sheet (lock screen).



- · Tap notification twice to open Call History. Check missed call records and call back as needed.
- · When screen is unlocked, 🔀 appears on Status Bar. Drag Status Bar down for Notifications Window, then Tap notification.



#### · Once playback ends, Display returns to message list.

### Rejecting Arriving Calls

' To stop playback, Tap Stop .

As call is arriving, Drag 

■ down 

Reject

Reject .

#### Forwarding Arriving Calls

As call is arriving, Drag 🔳 down 🗦 Forwarding


- · When screen is unlocked, Tap Incoming call 🗦 🔳 🤿 Forwarding).
- $\cdot$  Set a phone number to forward calls to beforehand. See "Call Forwarding" for details.

## Showing Caller's Name and Photo for Incoming

As call is arriving, Drag 🔳 down 🗦 Display Addressbook Info

- · When screen is unlocked, Tap Incoming call 🗦 🔳 🤿 Display Addressbook Info .
- · Available when "Simple secrecy for incoming calls" is enabled. See "Call Settings" for details.

#### Call Window Layout/In-Call Operation



- 1 Other party name/number
- 2 Other party photo
- 3 Call time
- 4 Mute own voice.
- 5 Adjust volume/quality.
- 6 Record call.
- 7 End call.
- 8 HD Voice call in progress<sup>1</sup>
- 9 Show dialpad.
- 10 Open menu.
- 11 Use Speakerphone.
- 1 Also appears as call is arriving or on hold, and also in Call History.

After a period of inactivity during a call, misoperationpreventing lock screen appears and touch operation is disabled.



- 1 Drag down to unlock misoperation-preventing lock.
- 2 Drag down to end call.

#### Receiver Area (Direct Wave Receiver)

Receiver area (Direct Wave Receiver) is located at the top of Display.

During a call, adjust the position of handset up, down, left, or right for better hearing.

- · Hold handset so that Receiver area covers your ear as much as possible and blocks out surrounding noise for clearer sound.
- · How well sound can be heard differs with each individual and depends on the surrounding environment.
- · When earphones are connected to handset, Direct Wave Receiver is disabled; sound is heard from the earphones.

# In-Call/Voice Memo Operations Adjusting Call Volume During call, Volume Up/Down Key Enabling/Disabling Noise Suppression During call, Volume 🗦 🔤 (to enable)/ 🧧 (to disable) in Noise suppression · Enable Noise suppression for clearer other-party voice. Enabling/Disabling Slow Talk

During call, Volume  $\Rightarrow$  or (to enable)/ (to disable) in Slow talk

 $\cdot$  Enable Slow talk for slower other-party voice.

#### Recording Call (Voice Memo)

During call, Voice Memo

' To end recording, Tap Stop .

#### Playing Back Voice Memos



' To stop playback, Tap Stop .

#### Placing Call on Hold

During call, Menu 🕣 Hold · To resume call, Tap Unhold .

#### Connecting/Disconnecting Bluetooth® Device (Headset, Etc.) for Handsfree Conversation

During call, Menu 

Bluetooth ON / Bluetooth OFF

· Available when handset is paired with a Bluetooth® device with handsfree functionality (e.g., headset).

#### Opening Address Book

During call, Menu 

Address Book

#### Opening Call History

During call, Menu 

Quote to Call log

#### Opening Profile

During call, Menu  $\Rightarrow$  Quote from profile

#### Placing Current Call on Hold & Calling Another Number

During call, Menu 

Add Call

#### Troubleshooting

- Q. Difficulty with call
- A. It may be difficult to make a call in a location with noise.
- A. Check the call volume when using Speakerphone. It may be difficult to make a call with a raised call volume.
- Q. The other party cannot hear me
- A. Are you covering Mic/Recorder Mic on the bottom surface of handset with your finger, etc.? Make sure not to cover Mic/Recorder Mic.
- Q. Sound experiences popping during a call
- A. Are you moving location during a call? Popping may occur when switching areas for a better signal. This is not a malfunction.

#### Using VoLTE

VoLTE (Voice over LTE) is a system enabling voice calls over LTE networks. Compared to voice calls over conventional 3G connections, high-sound quality calls and reduced time until ring tones sound are possible (requires separate subscription).

- · Available when the counterpart model is a VoLTE-compatible model from SoftBank. In addition, it is necessary for both handset and the counterpart model to be within the SoftBank 4G LTE (FDD LTE) service area, with "VoLTE voice call" and "Use 4G" enabled.
- · VoLTE is unavailable during international roaming.
- · During calls over VoLTE, 🛍 appears on Display.




#### HD Voice

HD Voice supports a wide range of audio tones for clearer, more natural-quality voice calls.

- Available when the counterpart model is an HD Voicecompatible model from SoftBank.
- HD Voice is compatible with VoLTE and 3G network.
   Use HD Voice with VoLTE for voice calls of even higher quality.

#### Disabling VoLTE



#### ■ VoLTE Caution

VoLTE uses 4G network service, and is unavailable when 4G network service is disabled on handset. If VoLTE is unavailable, follow the steps below to check whether 4G network service is enabled ( ).



#### **Emergency Location Report**

Making emergency calls (110, 119 or 118) automatically reports handset location to corresponding agency (police, etc.). This system is referred to as Emergency Location Report, and notifies location based on positioning from base stations.

- · Location Report does not incur registration/transmission fees.
- $\cdot$  Location/signal conditions affect positioning accuracy. Always provide location and call purpose.
- · Hiding Caller ID (using 184, etc.) cancels Location Report. However, corresponding agency may obtain location information in life threatening situations.
- $\cdot$  Location Report is not sent for calls made while outside Japan.

#### Emergency Call Cautions

Emergency calls can only be made within the SoftBank service area.

 $\cdot$  Emergency calls cannot be placed when Airplane mode is active. Cancel it first.

#### **Optional Services**

Use these SoftBank Optional Services:

#### Optional Services

The following optional services are available.

Service	Description
Call Forwarding	Divert all/unanswered calls to a preset number.
Voicemail	Divert all/unanswered calls to Voicemail Center; access messages via handset/ touchtone phones.
Call Waiting <sup>1</sup>	Answer calls during a call.
Group Calling <sup>1</sup>	Merge multiple calls.
Notify Caller ID	Send or hide your number when placing calls.
Call Barring	Restrict incoming/outgoing calls by conditions.

1 Requires separate subscription





- Call Settings appear.
- 2

#### [Voicemail/divert]



- Voicemail/divert menu opens.
- 3

#### [Settings/stop]



- Divert menu opens.
- 4






· For No answer , Tap WAIT TIME and select ring time as needed.

OK
Call Forwarding is set.

Canceling Call Forwarding

In Divert menu, Stop call forward 🔵 YES



In Divert menu, Stop call forward 🗦 YES

# Setting Missed Calls Handset notifies you of incoming calls when handset is powered off or out of service area. Initiate Voicemail then follow these steps: In Call Settings, Missed calls Settings CALL Follow audio guidance Setting Operation of Missed Calls In Call Settings, Missed calls Sounds & alerts Tap item Follow onscreen prompts Set Missed calls sound, Vibration pattern, Incoming calls

lamp, and Ring duration.

#### Call Waiting

Requires separate subscription.

1

In app sheet, 🌼 (Settings) 🗦 Call



Call Settings appear.

2

#### Other service settings



Other service settings appear.

3

Call waiting ( 🗸 )



Call waiting is set.

When Call Arrives during Another Call

A tone sounds; Drag 🕓 right to answer.

Canceling Call Waiting

#### Group Calling

Requires separate subscription.

1

During a call, Menu 

Add Call



2

Enter number 🔵 CALL

3

When call connects, Menu → Merge calls

Group Calling starts.

#### Notify Caller ID

1

In app sheet, 🌼 (Settings) 🗦 📵



Call Settings appear.

2

#### Other service settings

Other service settings appear.

3

Notify caller ID 🗦 [Hide number] or [Show number]



Caller ID is set.

#### Call Barring

Restrict outgoing/incoming calls and SMS messages.

· When attempting to place/send a call/SMS while calling is restricted, a message appears. Message may take time to appear in some areas.

Restriction	Description
All outgoing calls	Restrict all outgoing calls.
Bar int'l call	Restrict international calls; while outside Japan, calls within current country are allowed.
Local & home only	Restrict international calls; while outside Japan, calls within current country and to Japan are allowed.
Restrict all incomings	Reject all calls.
Bar if abroad	Reject calls while outside Japan.



In app sheet, 🌼 (Settings) 🗦 Call



Call Settings appear.

2

Call barring




🔀 Call barring menu opens.

3







Rejecting Calls from Numbers Not Saved in Address Book



Rejecting Calls with No/Undisplayable Caller ID or from Payphones



#### ? Troubleshooting

- Q. Calling is not barred
- A. Are you using Call Forwarding or Voicemail? Calling may not be barred even if All outgoing calls and Restrict all incomings are set.

#### Making Call Settings

#### Call Settings

Check call information and make settings. Settable items are the following.

Item	Description
Any-key answer	Set Volume Up Key function for incoming calls.
Quick silent	Set whether turning over handset stops ringtone and handset vibration as a call is arriving.
Adding new contacts to the address book	Set whether a window appears after a call to add an unsaved number to Address Book.
Auto answer	Set auto answering and ring time until handset automatically answers when earphones are connected.
Simple secrecy for incoming calls	Set whether to keep a caller's name and photo from appearing until handset is picked up.
Operation when putting down	Set what action occurs when handset is set down during a call.
Calling display settings	Set screen background, etc. shown during a call.
Quick responses	Edit an SMS message to send to a caller when unable to answer.
Answer phone	Play back Answer Phone and Voice Memos and set operation of Answer Phone.
Voicemail/ divert <sup>1</sup>	Enable and set operation of Voicemail and Call Forwarding.
Missed calls <sup>1</sup>	Set notification of missed calls and Voicemail messages.
Int'l call settings <sup>2</sup>	Set a country code list for international calls and Abroad Assistant.
Call barring <sup>1</sup>	Set call restrictions, rejection, etc.
Power key ends call	Enable (也) to end a call.
Other service settings <sup>1</sup>	Set notification of caller ID and Call Waiting.
Internet call	Set calling method for Internet calls when connected by Wi-Fi.

- 1 See "Optional Services" for details.
- 2 See "Calling from Outside Japan" for details.



In Feel Home, (Phone)



2





Call Settings appear.



Set each item

Setting is complete.

#### Call Setting Operations

Setting Volume Up Key Function for Incoming Calls

In Call Settings, Any-key answer → Answer / Quick silent

Setting Whether Turning Over Handset Stops Ringtone/Vibration for Arriving Call

In Call Settings, Quick silent

· Tap Quick silent to toggle on ( )/off ( ).

Setting Whether Window Appears after Call for Adding Unsaved Number

In Call Settings, Adding new contacts to the address book

· Tap Adding new contacts to the address book to toggle on ( )/off ( ).

Setting Whether Handset Answers Call when

In Call Settings, (Auto answer) → (Auto answer)

'Tap (Auto answer) to toggle on ( ) )/off ( ).

Earphones Connected


Setting Ring Time until Handset Answers with Auto Answer In Call Settings, Auto answer 
Call Time
Select number of seconds 

SET · Available when Auto answer is enabled. Setting Whether to Keep Caller's Name and Photo from Appearing until Handset is Picked Up In Call Settings, Simple secrecy for incoming calls · If confirmation appears, follow onscreen prompts. · Tap Simple secrecy for incoming calls to toggle on ( ✓ )/off ( ☐ ). · When "Simple secrecy for incoming calls" is enabled, function is available if Grip Magic is enabled. Setting what Action Occurs when Handset is Set Down during Call In Call Settings, Operation when putting down Hold / Mute / Speakerphone / OFF  $\cdot$  If confirmation appears, follow onscreen prompts. · When Hold, Mute or Speakerphone is set, function is available if Grip Magic is enabled. Setting Screen Background, Etc. Shown during Calls In Call Settings, Calling display settings 🗦 Follow onscreen prompts Editing SMS Message to Send to Caller when Unable to Answer In Call Settings, Quick responses 
Tap message to edit 🗦 Enter message 🗦 OK Setting/Canceling Answer Phone In Call Settings, Answer phone 

Answer phone Mannermode / ON / OFF Setting Answering Message for Answer Phone In Call Settings, Answer phone 

Answering message setting 🔵 Tap message option Setting Answering Time for Answer Phone In Call Settings, Answer phone 

Answer time setting 🗦 Select time 🗦 SET



#### Address Book

Save contacts with phone numbers and email addresses to Address Book.

In addition, save birthdays, nicknames and other information, and set ringtones for incoming calls/messages for each contact as needed.

#### Address Book Caution

Contacts may be altered/lost if handset is left uncharged or due to accidents, malfunctions, repairs, handset upgrade/replacement, mishandling, etc. Back up important contacts and other data regularly. SoftBank Corp. is not liable for any damages resulting from loss/alteration of contacts.

#### Adding New Contacts

1

In app sheet, 🔣 (Basic) 🤝 🔼 (Address Book)



Contact list (Address Book) appears.

2

Add new entry



- Window for saving new contact opens.
- $\boldsymbol{\cdot}$  If confirmation appears, follow onscreen prompts.

3

Tap item 🔵 Complete entry











Contact is saved.

#### Operations when Saving Contacts

#### Saving Photo

In window for saving new contact, Tap top of image frame (face image, body image)  $\bigcirc$  Tap save method  $\bigcirc$  Save operation

#### Setting Operation for Arriving Voice Call

In window for saving new contact, Ring Set 🗦 Tap item 🗦 Follow onscreen prompts

· Set operation such as type of ringtone, vibration, etc.

#### Adding Groups

In contact list (Address Book), 

Add/edit group 🗦 🗚 🖒 Tap Group name entry field 🗦 Enter group name 
Save

· If confirmation appears, follow onscreen prompts.

#### **Setting Groups**

In window for saving new contact, Group setting 🗦 Tap group ( ✓ ) → Decision

· If no groups are saved, confirmation for adding group appears. Tap YES for window for saving new group. Enter group name and Tap Save .

#### Showing Other Savable Items

In window for saving new contact, Other

· Save chat, nickname, GPS information, organization, etc.

#### Saving Type of Phone Number, Etc.

In window for saving new contact, Tap type ( 👊 , etc.)

Tap type to save

· For Custom , enter type name.

#### Saving Several Different Phone Numbers, Etc. to Contact

to 

Enter number, etc.

#### Deleting Entered Phone Number, Etc.

In window for saving new contact, X for item to delete

#### Saving Contact from Dialpad Window

Save a number entered in dialpad window directly to Address Book.

In Feel Home, (Phone) Dial Tap dialpad keys to enter number to save 🗦 🗦 Add to Address Book 🔵 Follow onscreen prompts

#### Syncing with Contacts on Server

Sync handset Address Book with Google contacts on server. Also sign in to a Google Account before syncing with a non-Google Account.

In app sheet, 🌼 (Settings) 🗦 Accounts 🗦 Tap account type 🔵 Tap account 🥥 Tap application or data to sync ( 🔽 )

#### Dialing from Address Book

1

In Feel Home, (Phone) (Phone) AddressBook



Contact list (Address Book) appears.

2

Tap tab



- $\cdot$  Drag tab left/right for hidden tabs.
- · Tap selected tab again to show sub-tabs (e.g., D, G, J, M, P, T, and W for A). Tap sub-tab for hidden contacts whose last names' readings start with the sub-tab.

3

Tap contact



Contact opens.

4

at right of number



Handset dials number. Call begins when other party answers.

5

To end call, Drag End call down



· If "Screen locked" is not shown on Display, Tap End call .

## Hiding Contacts (Secrecy Settings)

Specify contacts as secret entries requiring Operation Password for viewing.

## Specifying Contacts as Secret Entries

Contacts specified as secret are not shown in contact list (Address Book), recipient selection window, etc.

 $\boldsymbol{\cdot}$  Phone number is shown for arriving call.



In app sheet, (Settings) (Other settings)



#### Secrecy settings



Enter Operation Password 
OK



- Secrecy settings appear.
- · If confirmation appears, follow onscreen prompts.



#### Set contact secrecy



Set contact secrecy window opens.



Tap contact to set as secret ( <a> )</a>

· Several contacts are selectable.

6

[Confirm]



- Secrecy setting for contact is made.
- $\cdot$  Secret mode is set once Display turns off.
- Viewing Guide for Secrecy Setting



# Using Contacts Specified as Secret Entries

Cancel Secret mode temporarily to view/use contacts.

 $\cdot$  Secrecy settings for contacts can be made while Secret mode is temporarily canceled.



Drag Status Bar down



Notifications Window opens.

2


Touch & Hold




Entry window for Operation Password opens.



Enter Operation Password 
OK



Changing Operation Password for Temporarily Canceling Secrecy Settings



 $\cdot$  The setting made here is reflected in Operation password setting in Lock & Security.

# Messaging & Internet

Messaging	/8
S! Mail Initial Setup	78
Sending S! Mail/SMS	79
Opening & Replying to S! Mail/SMS	81
Using Gmail	83
Using Email	86
Using the Internet (Chrome)	88

## Messaging

#### S! Mail

Exchange messages with S! Mail-compatible SoftBank handsets and email compatible devices (other mobiles, PCs, etc.) beyond SMS character entry limit; attach media files.

#### SMS

Exchange short messages (up to 160 single-byte characters) using handset numbers as addresses.

#### Gmail

 $\mbox{\sc Gmail}$  is  $\mbox{\sc Google's webmail}$  service. Handset automatically syncs with  $\mbox{\sc Gmail}.$ 

#### Email

Use email (POP3/IMAP4) on handset.

- · Set up an email account beforehand.
- Sending/receiving email on handset syncs handset and mail server; sent/received messages (in the POP protocol, received messages only) are also accessible from PCs.

## S! Mail Initial Setup

#### Setting Up S! Mail Initially

When activating (Mail) for the first time, complete setup to send/receive S! Mail using Wi-Fi.



In Feel Home, (Mail)



- Setup to Wi-Fi connection window opens.
- · If confirmation appears, follow onscreen prompts.



Set Now



- Wi-Fi connection setup is complete and thread list opens.
- · If confirmation appears, follow onscreen prompts.
- To skip setup, Tap Set Later . Complete setup later as needed from Wi-Fi Connection in "Send/Receive Settings."
- Cautions for Sending/Receiving S! Mail Using Wi-Fi

#### International S! Mail Transmission Fees

Transmission fees apply when sending international S! Mail messages even if Wi-Fi is in use.

# S! Mail Reception while Display is Turned Off (Screen Lock Active)

To receive S! Mail messages using Wi-Fi even when Display is turned off (Screen lock active), disable Wi-Fi sleep policy ( Never ) in Wi-Fi settings.

## Sending S! Mail/SMS

#### Sending S! Mail/SMS

The following explains how to send S! Mail/SMS to a recipient saved in Address Book.

1

In Feel Home, (Mail)



Thread list opens.

2





Message composition window opens.

3

1



Recipient selection window opens.

 $\cdot$  To enter phone number/email address directly, Tap Recipient field.

4

Phonebook



Contact list (Address Book) appears.

5

Tap tab → Tap recipient → OK



A recipient is specified, and message composition window returns.

- $\cdot$  Specify multiple recipients as needed.
- · In message composition window, Tap i •••• in Recipient field to check recipient's phone number/email address.

6

Tap Subject field Enter subject Tap Text entry field

Enter text



- · Tap 🖉 to attach a file.
- $\cdot$  If a subject is entered or a file is attached, the message is sent as S! Mail.

7

Send



S! Mail/SMS is sent.

#### Sending S! Mail/SMS

#### S! Mail and SMS Switching

S! Mail and SMS may automatically switch at sending, depending on whether a subject is entered, text length, whether a file is attached, etc.

 When creating a message, check which it will be sent as at top of Display.



• Disable automatic switching between S! Mail and SMS as needed (thereafter, specify either when creating a message). See "Common Settings" for details.

#### In Case of S! Mail/SMS Send Failure

Failed S! Mail/SMS messages are saved as drafts.

## • Operations when Creating S! Mail/SMS

Specifying Recipients from Outgoing/Incoming History

In recipient selection window, Outgoing History /
Incoming History 
Tap recipient(s) OK

#### Specifying Multiple Recipients from Mail Group

In recipient selection window, Mail Group → Tap mail group → OK

 Set a mail group beforehand. See "Mail Group Settings" for details.

#### Changing Recipient Type (To/Cc/Bcc)

In message composition window, after specifying recipient (s), •••• in Recipient field (c) Change to To /

Change to Cc / Change to Bcc

#### Deleting Recipients

In message composition window, after specifying recipient (s), •••• in Recipient field 
Delete recipient

#### Saving Current Message as Draft

In message composition window, after specifying recipient

· Drafts are indicated by 🔌 in thread list.

#### Using Drafts

In thread list, Tap draft → Edit/send

## Opening & Replying to S! Mail/SMS

Handset receives S! Mail/SMS messages automatically by default. Optionally, retrieve messages manually, and also retrieve all messages saved on the server.

#### Opening New S! Mail/SMS

When message arrives, new message notification appears in Welcome sheet (lock screen).



- · When Display is turned off, Notification Lamp flashes.
- · In screens other than Welcome sheet (lock screen), new message notification appears around Status Bar. It disappears after a while, then Notification Indicator ( ) appears on Status Bar.



In Welcome sheet (lock screen), Tap new message notification twice



- Thread details open.
- $\cdot$  For two or more new messages, thread list opens. Tap thread to open.



Tap message



S! Mail/SMS message window opens.

## About Checking S! Mail/SMS

#### Mail Widgets

Add Mail widgets (easy mode and detail mode) to desktop sheet to check information of new/unread messages. See "Adding Widgets" for details.

#### Spam Mail

Set spam filtering to save messages from senders not in Address Book to Spam mail. New message notification does not appear for those messages. See "Opening S! Mail/SMS" for how to check messages saved in Spam mail.

 Opening New Messages from Screens other than Welcome Sheet (Lock Screen)

Drag Status Bar down for Notifications Window 

Tap new message notification 🔵 Tap message

· Alternatively, when new message notification appears around Status Bar, Tap the new message notification.

#### Opening S! Mail/SMS



In Feel Home, (Mail)



Thread list opens.



#### Tap thread



Thread details open.

Tap a thread indicated by 
 to open thread details including draft/unsent messages.



#### Tap message



S! Mail/SMS message window opens.

#### Message Operations

#### Protecting Messages

In thread details, Touch & Hold message to protect 🗦 🔒

- · Selected message is protected, and appears beside sent/received date and time.
- · To select multiple messages, Touch & Hold one, then Tap other messages.
- $\boldsymbol{\cdot}$  To cancel protection, refer to the steps for protecting messages.

## Saving Attachments In S! Mail/SMS message window, <a> ∅</a> <a> ∂</a> Tap <a> for </a> attachment to save ( 🗹 ) 🔵 Save **Deleting Threads** In thread list, Touch & Hold thread to delete 🔷 📋 😜 $\cdot$ To select multiple threads, Touch & Hold one, then Tap other threads. Deleting Messages In thread details, Touch & Hold message to delete 🗦 📺 Delete · To select multiple messages, Touch & Hold one, then Tap other messages. Reporting Spam In thread details, Touch & Hold message to report as spam 🔷 🛇 🔷 Yes · Only one message can be selected. · In S! Mail/SMS message window, Tap 🚦 🗦 Declare Spam $\Rightarrow$ Yes. Checking Spam

 $\cdot$  If confirmation appears, follow onscreen prompts.

#### Listing Addresses of Sender/Recipients

In thread details, 🚦 🗦 List Address

' In S! Mail/SMS message window, Tap 🔼 .

#### Replying to S! Mail/SMS

1

In S! Mail/SMS message window, 👆 / 🐇



2


Enter text 
Send



Message is sent.

Replying to Threads Easily

In thread details, Tap Text entry field at Display bottom



· Tap 𝒞 to attach a file (e.g., an image).

## **Using Gmail**

Use Gmail (Google's webmail service) as well as your work/personal email.

#### Setting an Account

Set up a Google Account or an email account to use Gmail.

When activating (Gmail) for the first time, account setup menu appears; complete setup.

- $\cdot$  Account setup menu does not appear if you are already signed in to a Google Account.
- To use your existing account, information such as username (ID), password, and server name is required.



In app sheet, 📱 (Google) 🗦 🚩 (Gmail)



- Account setup menu opens.
- $\cdot$  If confirmation appears, follow onscreen prompts.


2

Add an email address



3





4

Follow onscreen prompts

Account setup is complete.

## Creating/Sending Gmail

1

In app sheet, 
☐ (Google) → [M] (Gmail)



- Message list opens.
- · If confirmation appears, follow onscreen prompts.







Message composition window opens.




Enter recipient, subject and text  $\Rightarrow$ 



Message is sent.

#### Message Composition Operations

# Adding Cc/Bcc Recipients In message composition window, in Recipient field Enter recipient Attaching Files In message composition window, Select application Select file



#### Opening New Gmail

When message arrives, new message notification appears in Welcome sheet (lock screen).

- · When Display is turned off, Notification Lamp flashes.
- $\cdot$  In screens other than Welcome sheet (lock screen), Notification Indicator (  $\fbox{M}$  ) appears on Status Bar.



In Welcome sheet (lock screen), Tap new message notification twice



- Message window opens.
- $\cdot$  For two or more new messages, message list opens; Tap message to open.
- Opening New Messages from Screens other than Welcome Sheet (Lock Screen)

Drag Status Bar down for Notifications Window 🗦 Tap new message notification

## Opening Gmail

1

In app sheet, 📔 (Google) 🔿 M (Gmail)



Message list opens.


2

Tap message



Message window opens.

• Operations when Opening Messages



#### Syncing Accounts Manually

In message list, Drag down

 $\cdot$  Sync sent and received messages manually at any time regardless of the automatic sync settings.

## Using Email

Send/receive email using (Email), an email-only application.

#### Setting an Account

Set up an email account to use email.

When activating (Email) for the first time, account setup menu appears; complete setup.

· Information such as username (ID), password, and server name is required.



In app sheet, [See [Email]]



🔀 Account setup menu appears at first activation.



Follow onscreen prompts to set up account

Account setup is complete.

#### Creating/Sending Email



In app sheet, 🙋 (Email)



Message list opens.







Message composition window opens.




Enter recipient, subject and text 🔵  $\geq$ 



Message is sent.

## Message Composition Operations



#### Discarding Current Message

While creating message, 

☐ → Discard → DISCARD









#### Opening New Email

When message arrives, new message notification appears in Welcome sheet (lock screen).

- $\cdot$  When Display is turned off, Notification Lamp flashes.
- · In screens other than Welcome sheet (lock screen), Notification Indicator (  ${f igsim}$  ) appears on Status Bar.



In Welcome sheet (lock screen), Tap new message notification twice



- Message window opens.
- · For two or more new messages, message list opens; Tap message to open.
- Opening New Messages from Screens other than Welcome Sheet (Lock Screen)

Drag Status Bar down for Notifications Window 🔵 Tap new message notification

#### Opening Email



In app sheet, [See [Email]]



Message list opens.




Tap message



Message window opens.

#### Operations when Opening Messages



In message window,  $\spadesuit$   $\ominus$  Create message  $\ominus$   $\ge$ · To reply to all, Tap 🕻 🗦 Reply all .

#### Forwarding Messages

**(2)** 







#### Resetting Messages as Unread

In message window,

· In message list, Tap icon for message to reset as unread ( $\bigcirc$  appears), then Tap  $\cong$   $\bigcirc$   $\leftarrow$  .

## **Deleting Messages**

In message window, 📋 🕣 OK



· In message list, Tap icon for message to delete ( 📀 appears), then Tap 📋 🔵 🛛 .

#### Syncing Accounts Manually

In message list, Drag down

· Sync sent and received messages manually at any time regardless of the automatic sync settings.

## Using the Internet (Chrome)

Enter search terms or URLs for easy Internet access.

#### SSL & TLS

Secure Sockets Layer (SSL) and Transport Layer Security (TLS) are encryption protocols that secure Internet transmissions of important/sensitive information such as credit card numbers and corporate secrets, providing protection against online threats (eavesdropping, falsification, impersonation, etc.).

#### SSL/TLS Caution

When opening a secured page, users must decide as their responsibility whether or not to open the page with use of SSL/TLS. SoftBank Corp. and the Certification Authorities Symantec Website Security G.K. and Cybertrust make no guarantees whatsoever to users regarding security of SSL/TLS.

#### **Using Chrome**



In Feel Home, (Chrome)



- Chrome activates.
- · If confirmation appears, follow onscreen prompts.

#### 2

Tap Text entry field at top of Display 

Enter search term or URL 

Output

Display 

Enter search term or URL 

Output

Display 

Outpu



Search results or webpage opens.

#### Chrome Operations

#### Signing in to My SoftBank

Access My SoftBank to check service charges or reward points, change contract details (subscribed price plan, optional services, etc.), check handset email address, use anti-spam settings, etc.

In Chrome, ┆ ᢒ Bookmarks ᢒ My SoftBank ᢒ
Follow onscreen prompts

#### Searching within Current Webpage

In Chrome, 😜 Find in page 🗦 Enter search text

Search results are highlighted.

#### Saving (Downloading) Images

In Chrome, Touch & Hold image 🔵 Save image

- appears on Status Bar when image is saved. To open the image, Tap download complete notification in Notifications Window.
- · Alternatively, open the image from (2) (Downloads) or (Album).

#### Opening Saved (Downloaded) Image, Etc.

#### Adding Bookmarks

1

In Feel Home, (Chrome)



Chrome activates.

2

Open target webpage ♦ 🕻 ♦ 🌣



Add bookmark window opens.

3

Check/edit Name, URL, etc. 
Save



Current webpage is saved as a bookmark.

#### Bookmark Operations



#### Opening Bookmarks

1

In Feel Home, (Chrome)



Chrome activates.



**Bookmarks Bookmarks Bookmarks Bookmarks** 



Bookmark window opens.



Tap bookmark

Corresponding webpage opens.

## Checking Browsing History

1

In Feel Home, (Chrome)



Chrome activates.

2

: 
History



History window opens.

3

Tap record



Webpage opens.

#### Opening New Tabs

Open multiple webpages in different tabs to switch between them easily.

1

In Feel Home, 🧿 (Chrome)



Chrome activates.

2

New tab



3

Tap Text entry field at top of Display → Enter search term or URL → Go

🏁 Another tab opens.

Tab Operations



Make Chrome settings. Settable items are the following.

Item	Description
Sign in to Chrome	Sign in to your Google Account and make settings for tabs, bookmarks, history, etc. View account information.
Search engine	Select a search engine.
Merge tabs and apps	Set whether to show tab browsing history in application usage history.
Autofill forms	Enable or disable automatic form entry, or edit address and credit card information.
Save passwords	Enable or disable the saving of user names and passwords by webpages, confirm/delete webpages that have saved passwords, etc.
Home page	Set a homepage.
Privacy	Set whether to show a hint for an access error, whether usage and error reports are sent, etc.
Accessibility	Set text size, etc.
Site settings	Set whether to allow cookies, enable JavaScript, etc.
Data Saver	Set whether to economize data usage by compressing webpages before reading them.
About Chrome	View version information, etc. about Chrome.



In Feel Home, (Chrome)



Chrome activates.







Settings are made.

 $\boldsymbol{\cdot}$  For some items, additional settings may appear when Tapping the item.

## Camera

Capturing	Photos	94
Recording	Videos	95

## Capturing Photos

Capture JPEG images.

Camera Usage Note

Mind etiquette when using Camera.

#### Capturing Photos

In Feel Home, 🀞 (SH Camera)



Viewfinder opens.

Aim External Camera at subject



- · For people, focus automatically locks on detected face.
- · Spread or Pinch to zoom in or out on subject.
- · Drag up/down to adjust brightness.

0




Shutter sound plays; photo is captured.

#### Viewfinder Layout

Layout and functions of main indicators are as follows.

· Depending on Camera settings and shooting mode, other indicators may appear, or appearance of indicators may differ.



- 1 Toggle External/Internal Camera.
- 2 Capture photo.
- 3 Record video.
- 4 Change shooting mode.
- 5 Access Camera settings.
- 6 Change Mobile Light setting.
- Open last captured photo/video. (Preview thumbnail)

#### Photo Viewfinder Operations

#### Using Mobile Light

In Viewfinder, 

→ ON / Auto / LOW / OFF













#### Locking Focus on Specific Subject

In Viewfinder, Tap subject for focus lock ( [ ] )

- To cancel focus lock, Tap area outside 📋.
- · External Camera uses color to track subjects; may not correctly track faintly colored subjects or ones similar to background color.

#### Capturing Self with Internal Camera (on Display Side)

In Viewfinder,

- · Tap 🚇 to toggle External/Internal Camera.
- $\cdot$  If confirmation appears, follow onscreen prompts.
- $\cdot$  When using Internal Camera, 2-second delay is set for Self-timer.
- · Some functions/settings are not available for Internal Camera.

#### Capturing Photos Continuously

In Viewfinder, Touch & Hold

· Camera continues to capture photos until  $\widehat{\circ}$  is released.

#### Opening Photo Immediately After Capture

In Viewfinder, Tap preview thumbnail

· For subsequent operations, see "Viewing & Managing Photos/Videos (Album)."

#### ? Troubleshooting

- Q. Cannot open Camera/Camera exits suddenly
- A. Camera does not open if battery level is low. Charge
- A. Camera exits automatically after a period of inactivity.
- Q. Images are dark/grainy
- A. Is there a strong light near the subject, or a strong light source in the screen? Avoid letting a strong light source (the sun, light, etc.) in the screen. Leaving handset in a warm place for a long time or where Camera is in direct sunlight for a long time may affect image quality.
- Q. Cannot focus
- Fingerprints, etc. on lens cover prevent Camera from focusing. Wipe clean with a dry, soft cloth.

#### Photo Capture Cautions

#### If Lens Becomes Dirty

Fingerprints/smudges may hinder handset imaging. Clean Lens with a soft cloth beforehand.

#### Avoid Direct Sunlight Exposure

Do not expose Lens area to direct sunlight for extended periods; may damage color filter, altering images.

#### Nobile Light Warning

Do not turn on Mobile Light close to eyes, look directly at Mobile Light when on, or shine Mobile Light in eyes; may affect eyesight or cause other problems.

## Recording Videos

Record H.264/AAC videos.

Camera Usage Note

Mind etiquette when using Camera.

## Recording Videos

In Feel Home, 🐞 (SH Camera)





Viewfinder opens.

Aim External Camera at subject



- · Spread or Pinch to zoom in or zoom out on subject; also available while recording videos.
- · Drag up/down to adjust brightness; also available while recording videos.

3





Tone sounds and recording starts.








Tone sounds and recording stops; video is saved.

## Viewfinder Layout

Layout and functions of main indicators are as follows.

· Depending on Camera settings and shooting mode, other indicators may appear, or appearance of indicators may differ.



- 1 Toggle External/Internal Camera.
- 2 Capture photo.
- 3 Record video.1
- 4 Change shooting mode.
- 5 Access Camera settings.
- 6 Change Mobile Light setting.<sup>2</sup>
- Open last captured video/photo. (Preview thumbnail)
- 1 (stop recording) appears while recording videos.
- 2 \(\frac{1}{3}\) / \(\frac{1}{3}\) appears while recording videos.

#### Video Viewfinder Operations

## Using Mobile Light

In Viewfinder, 

→ ON / Auto / LOW / OFF











#### Locking Focus on Specific Subject

In Viewfinder, Tap subject for focus lock ( [ ] )

- To cancel focus lock, Tap area outside [ ].
- · External Camera uses color to track subjects; may not correctly track faintly colored subjects or ones similar to background color.

#### Recording Self with Internal Camera (on Display Side)

In Viewfinder, 🚇

- · Tap 🚇 to toggle External/Internal Camera.
- · If confirmation appears, follow onscreen prompts.
- · Some functions/settings are not available for Internal Camera.

#### Opening Video Immediately After Recording

In Viewfinder, Tap preview thumbnail 🗦 🕞



· For subsequent operations, see "Viewing & Managing Photos/Videos (Album)."

#### ? Troubleshooting

- Q. Cannot open Camera/Camera exits suddenly
- Camera does not open if battery level is low. Charge handset.
- A. Camera exits automatically after a period of inactivity.
- Q. Images are dark/grainy
- A. Is there a strong light near the subject, or a strong light source in the screen? Avoid letting a strong light source (the sun, light, etc.) in the screen. Leaving handset in a warm place for a long time or where Camera is in direct sunlight for a long time may affect image quality.
- Q. Cannot focus
- A. Fingerprints, etc. on lens cover prevent Camera from focusing. Wipe clean with a dry, soft cloth.

#### Camera Cautions

#### If Lens Becomes Dirty

Fingerprints/smudges may hinder handset imaging. Clean Lens with a soft cloth beforehand.

#### Avoid Direct Sunlight Exposure

Do not expose Lens area to direct sunlight for extended periods; may damage color filter, altering images.

#### Continuous Recording Time

Recording capacity is 2 GB per file (recording stops when exceeded). To continue recording, start another session.

## Mobile Light Warning

Do not turn on Mobile Light close to eyes, look directly at Mobile Light when on, or shine Mobile Light in eyes; may affect eyesight or cause other problems.

# Music & Images

Music Files (Music)	100
Viewing & Managing Photos/Videos (Album)	101

## Music Files (Music)

Play music files. Create playlists of your favorite songs as needed.

## Playing Music Files

The following file formats are supported.

· 3GPP, MP4, MP3, AMR, WMA (WMDRM not supported), ASF (WMDRM not supported), Ogg Vorbis, WAVE, MIDI, XMF, RTTTL/RTX, OTA, iMelody, ADTS raw AAC, FLAC



In app sheet, 📳 (Entertainment) 🗦 🎵 (Music)



Music activates.

 Last-opened category appears if Music was previously activated.



Artists / (Albums / (Songs)



3

Tap item 🔵 Tap song



Song plays.

- · For Songs (in 2), Tap song directly.
- · Depending on category, after Tapping an item, Tap another item (e.g., album name).

Music Operations

Changing Playback Volume

While song plays, Volume Up/Down Key

Playing All Songs Randomly

In Music, Artists / Albums / Songs 
Shuffle all

Alternatively, for Artists / Albums, Tap an item (e.g., album name)


Shuffle all to play all songs randomly.

Playing All Songs in Current Location from the Top

In Music, Artists / Albums / Songs 
Play from head

· For Artists / Albums , Tap an item (e.g., album name).

## Music Player Layout



- 1 Return to the previous screen.
- 2 Song image appears here.
- 3 Song title, artist, album
- 4 Drag slider to adjust playback position.
- 5 Play previous song or current song from beginning.
- 6 Open menu.
- 7 Toggle repeat all songs, repeat current song, repeat off.
- 8 Toggle shuffle playback on/off.
- 9 Play next song.
- 10 Pause/play

## Viewing & Managing Photos/ Videos (Album)

Photos/videos captured on handset and downloaded images are sorted into Event and Map categories.

#### Viewing Photos/Videos

View captured/downloaded photos and videos.

Image	File format
Photo	JPEG, PNG, GIF, BMP, WebP
Video	3GPP, MP4, WMV (WMDRM not supported), ASF (WMDRM not supported), WebM, Matroska



In app sheet, Album



- File list opens.
- · Flick up/down for hidden files.
- · If confirmation appears, follow onscreen prompts.



Tap photo/video




- Photo/video opens (file view window).
- · For video playback, Tap ( ), then follow onscreen prompts.
- 🗇 appears for photos captured with continuous shooting. appears for photos captured in Photo Sphere mode.

#### Categories

Category name (e.g., All) appears at upper left of file list. Sort images into other categories (Folder, Event and Map) as needed.

· All images appear in All category.

## Photo/Video Viewing Operations



#### Setting Whether to Show Images More Clearly when Display is Bright

In file list, folder list, or file view window, Settings > Sharpness · Tap Sharpness to toggle on ( ✓ )/off ( □ ).

#### Selecting a Range of Images from Continuous Shooting


In continuous shooting photo index window, 🚦 🗦 Clip range  $\bigcirc$  Drag  $\bigcirc$  /  $\bigcirc$  right and left to select the desired range of images 🗦 🗸 🗦 [YES]  $\cdot$  Photos that have not been selected are deleted.

## Selecting Desired Images from Continuous

Shooting

Tap desired images in continuous shooting photo index window to set as favorites  $\Rightarrow$   $\bigstar$  (  $\star$  )

· In continuous shooting photo index window, 🚦 🔵 Tap Display only marked images to show only photos set as favorites.



## ? Troubleshooting

- Q. Cannot open photos or videos
- A. The database may be disabled. Connect handset to a PC using Micro USB Cable, and delete the DATABASE folder in ¥PRIVATE¥SHARP¥PM on handset memory before opening photos or videos.

# Connectivity

Wi-Fi	104
Using Tethering Functions	107
Bluetooth®	108

#### Wi-Fi

Handset supports Wi-Fi (wireless LAN). Access the Internet via household Wi-Fi networks.

#### About Wi-Fi

Available in the following environments.

Environment	Description
At home	Connect handset to your Wi-Fi home network. If you have a broadband connection at home but do not have a Wi-Fi router, consider using a Wi-Fi router by FON offered by SoftBank Corp. If you are using a Wi-Fi router by FON, refer to the "Fonルーターかんた人設定ガイド (http://mb.softbank.jp/mb/special/network/pdf/wifi_howto_01.pdf) (Fon Router Easy Settings Guide)" (Japanese).
On the go	SoftBank Wi-Fi spots offered by SoftBank are available.

## Automatic Updates for Optimizing Wi-Fi Connection

While using Wi-Fi, updates for optimizing connection may be received or applied automatically.

#### Enabling Wi-Fi

1





Wi-Fi settings appear.


2

Off



- Wi-Fi is enabled ( On ).
- $\cdot$  Access point search starts; available access points appear upon completion.
- · To disable Wi-Fi, Tap On (Off appears).

#### ■ Wi-Fi Operations





#### Connecting Selected Access Points

Enable handset Wi-Fi first.

1

In app sheet, 🌼 (Settings) 🗦 Wi-Fi settings



Wi-Fi settings appear.

2

Tap access point



3

Enter password → CONNECT



- Handset connects to the access point.
- Password (indicated by WEP, WPA, KEY, etc.) may be found on a label on your Wi-Fi router. For details, contact the vendor of the router. For public wireless LAN services, check the password with your ISP.
- Depending on access point, password entry may not be required.

## ■ Wi-Fi Connection Operations

## 

- $\cdot$  Available when Wi-Fi is enabled.
- $\cdot$  Depending on security protocol, other fields may also need to be completed.



#### Troubleshooting

- Q. Cannot detect access points
- A. There may be multiple access points using neighboring channels. In this instance, handset may not detect access points correctly.

#### Disconnecting Wi-Fi

1

In app sheet, 🤹 (Settings) 🗦 Wi-Fi settings



Wi-Fi settings appear.

2

Tap connected access point 

DISCONNECT



Wi-Fi is disconnected.

 $\boldsymbol{\cdot}$  Password entry may be required to reconnect to access point.

#### Using Wi-Fi Direct

Use Wi-Fi Direct to establish a Wi-Fi connection with other Wi-Fi Direct compatible devices with no need for an access point or Internet connection.

· Enable handset Wi-Fi first.













Wi-Fi settings appear.











- Found Wi-Fi Direct compatible devices appear in Peer devices field.
- · If target device does not appear, Tap SEARCH FOR DEVICES to try searching again.



Tap target device > Follow onscreen prompts for authentication



- · A connection request will be canceled if not accepted within a certain period of time.
- · To disconnect devices, Tap one then Tap OK .

#### Using Tethering Functions

#### **Tethering Functions**

Tethering functions make handset act as an external modem (like a Wi-Fi router).

Use tethering functions to connect a PC or game device to the Internet through handset.

- $\cdot$  Requires separate subscription.
- $\cdot$  Use after confirming that handset is updated to the latest software.

#### **Setting Tethering Functions**

When using tethering functions, several methods are available for connecting handset with other devices.

Make settings according to connection method and status of target device beforehand.

Settable items are the following.

Item	Description
USB tethering	Set whether to enable tethering via Micro USB Cable.
Wi-Fi tethering	Set whether to enable tethering via Wi-Fi.
Set up Wi-Fi	Set information such as network name and
hotspot	security for Wi-Fi tethering.
Wi-Fi	
Wi-Fi tethering	Use WPS to connect handset to other
	Use WPS to connect handset to other devices via Wi-Fi easily.
tethering	
tethering Easy	













- Tethering function window opens.
- · If confirmation appears, follow onscreen prompts.



Set each item

#### Bluetooth®

Connect handset to other Bluetooth® devices (e.g., headset) for handsfree conversations, or connect to other Bluetooth®-capable mobile phones, etc. to exchange files.

#### Bluetooth® Functions

The Bluetooth® function is a technology that enables wireless connection with PCs, Bluetooth® devices with handsfree functionality, etc. such as the following.

Function	Description
Sound output	Listen to music, audio, etc. wirelessly.
Handsfree conversation	Use Bluetooth® devices (e.g., headsets) for handsfree conversations.
File transfer	Transfer files between handset and Bluetooth® devices.

#### Bluetooth® Usage Cautions

#### Connection

Bluetooth® connection may not be possible with some Bluetooth® devices. In addition, noise may interfere with wireless or handsfree conversations.

#### File Transfer

Files may not appear correctly on recipient devices.

#### Enabling Bluetooth®

1

In app sheet, 🌼 (Settings) 🗦 Bluetooth



- Bluetooth® menu opens.
- 2

Off



- Bluetooth® is enabled ( On ).
- · To disable Bluetooth®, Tap On (Off appears).

#### ■ Bluetooth® Connection Operations

Renaming Handset Name that Appears on Other Devices

Enter name 🔵 RENAME

- $\cdot$  Available when Bluetooth  $^{\rm \tiny B}$  is enabled.
- · Renaming may not be possible if a pictogram is used.

Setting Whether to Give Priority to aptX®

In Bluetooth® menu, ▮ ♦ aptX ♦ ✓ (to disable)/ ☐ (to enable) at the right end of aptX line ♦ OK

- · Available when Bluetooth® is enabled.
- Changes are applied to devices connected after setting changes are made. Disconnect and reconnect handset to devices to apply changes.

#### Pair nearby Bluetooth® devices with handset to transfer files, for handsfree conversations, or to listen to music.

Pairing with Other Bluetooth® Devices

 $\cdot$  Enable Bluetooth® on handset and set target devices to be

discoverable first.

Setting Whether to Always Use Handsfree

· Tap Handsfree setting to toggle on ( ✓ )/off ( □ ). · When Handsfree setting is enabled, notification of incoming calls appears on both handset and handsfree device; use handsfree device for conversations even if

calls answered on handset. When the setting is disabled, talk on whichever device used for answering the call.

A. Airplane mode may be active. Activating Airplane mode disables Bluetooth  ${}^{\circledR}$  . (Bluetooth  ${}^{\circledR}$  can be enabled again

· Available when Bluetooth® is enabled.

Troubleshooting

Q. Cannot use Bluetooth®

while Airplane mode is active.)

Device for Calls

In app sheet, 🌼 (Settings) 🗦 Bluetooth



Bluetooth® menu appears; found Bluetooth® devices appear in Available devices field.

· If target device does not appear, Tap 🚦 🗦 Refresh to try searching again.

#### 2

Tap target device  $\bigcirc$  Follow onscreen prompts for authentication

Pairing completes; handset connects to some devices (e.g., handsfree devices) automatically.

- · Authentication procedure varies by device. Passkey entry may be required.
- · Passkey is a 1 to 16-digit alphanumeric code required for authentication between handset and other devices.
- · Paired devices appear in Paired devices field.

#### Pairing Operations

# Renaming Paired Devices name Enter name OK · Available when Bluetooth® is enabled. · Renaming may not be possible if a pictogram is used. **Unpairing Devices** · Available when Bluetooth® is enabled. Connecting to Bluetooth® Devices by Service In Bluetooth® menu, 🏚 for target device 🗦 Tap item · Available when Bluetooth® is enabled.

· Available when handset is paired with compatible devices.

#### Connecting Paired Bluetooth® Devices



In app sheet, 🌼 (Settings) 🗦 Bluetooth



- Bluetooth® menu opens.
- · Paired Bluetooth® devices appear in Paired devices field.

2

Tap target device

- Handset connects to the device.
- Accepting Connection Requests

Handset automatically accepts connection requests from paired devices. For unpaired devices, set handset to be discoverable first; when connection request arrives, follow onscreen prompts.

- · If confirmation appears, follow onscreen prompts.
- Disconnecting Devices (e.g., Handsfree Devices)

In Bluetooth® menu, Tap connected device ⇒ OK





#### Sending Files (e.g., Address Book)



In app sheet, 🔣 (Basic) 🗦 🔼 (Address Book)



- Contact list (Address Book) appears.
- 2

Tap tab 🔵 Tap contact



- Contact opens.
- **⋮** → Send → Send by Bluetooth



4

SEND (NO IMG) or SEND (IMAGE) ( YES when face image/photo is not saved)



Tap target device

File is sent.

#### Receiving Files (e.g., Address Book)

When file reception request arrives, appears on Status Bar. To receive files:



Drag Status Bar down



Notifications Window opens.

2

Tap Bluetooth® share notification → ACCEPT



3

After file reception, Drag Status Bar down for Notifications  $\mbox{\it Window}$ 







- File content is saved.
- $\cdot$  If confirmation appears, follow onscreen prompts.
- To always use selected option, Tap ALWAYS .
- Opening Files Received by Bluetooth® Transfer





# Global Services

Global	Roami	ng		11	4
Calling	from	Outside	Japan	11	5

#### Global Roaming

Handset is Global Roaming Service eligible. Use the same handset number outside Japan.

#### Setting a Cellular Provider

Handset connects to an appropriate cellular provider automatically by default. To set a cellular provider manually:



In app sheet, 🌼 (Settings)



2





3

Cellular networks



🔀 Cellular network settings appear.



Network operators





Tap provider

- Cellular provider is set.
- To set an appropriate cellular provider automatically, Tap Choose automatically .
- To search for all available cellular providers, Tap Search networks .

#### Changing Data Roaming Setting

Change setting for data communication outside Japan.

1

In app sheet, 🏩 (Settings)



2





3

#### Cellular networks



🔀 Cellular network settings appear.

4

#### Data roaming



Data roaming is disabled.

#### Enabling Data Roaming

In Cellular network settings, Data roaming 
OK

#### Calling from Outside Japan

Abroad Assistant is installed on handset. While outside Japan, follow onscreen prompts to place calls easily according to the country the other party is in.

To learn about roaming areas/rates, etc., see SoftBank Website:

#### http://mb.softbank.jp/en/global\_services/

Print out roaming area/rate information to carry while traveling abroad as needed.

#### Calling Japan



In Feel Home, 📞 (Phone) 🔵 Dial



- Dialpad window opens.
- · When missed call window appears, Tap . If Feel Home returns, perform 1 again.



Use onscreen dialpad to enter number 

CALL

- Roaming assistant appears.
- · Do not add + before the number.



#### [Japan number]



🏁 Handset dials the number.

#### Calling Landlines & Mobiles within Current Country



In Feel Home, (Phone) Dial







Dialpad window opens.

· When missed call window appears, Tap <a> . If Feel Home</a> returns, perform 1 again.

2

Use onscreen dialpad to enter number 🗦 CALL



Roaming assistant appears.

 $\cdot$  Do not add + before the number.

3

#### Stay country number



Handset dials the number.

#### Calling Countries aside from Japan

In Feel Home, (Phone) (Phone)









Dialpad window opens.

· When missed call window appears, Tap <a> </a> . If Feel Home returns, perform 1 again.

Use onscreen dialpad to enter number 

CALL





Roaming assistant appears.

· Do not add + before the number.

#### Other country number



Country code list opens.

Tap country code



Handset dials the number.

· When calling SoftBank handsets, always Tap 日本(JPN).



# Handset Settings

About Settings	120
Sound/Notification Settings	121
Wallpaper & Display Settings	124
Energy Saving Settings	126
Home Applications Setting	130
Useful Settings	130
About phone	134
Accounts Settings	135
Call Settings	135
Mail Settings	136
Guide Setting	139
Data Usage Settings	140
Storage Settings	142
Application Settings	143
Data Transfer	143
Other Sattings	1/6

# **About Settings**

# About Settings

In app sheet, Tap 🌼 (Settings) to customize operation of handset functions. Handset settings include the following items.

Item	Description
Profile	Check handset number, email address, etc.
Sound/ notification	Set Manner mode, ringtone, confirmation tones, etc.
Wallpaper & display	Set Wallpaper, Display brightness, etc.
Energy saving	Adjust corresponding settings together at once to save battery power, or check battery status.
Home applications	Switch Home application.
Useful	Set useful functions such as emopa, Clip Now, and Grip Magic.
About phone	Check handset status.
Accounts	Create/add accounts; sync them as needed.
Wi-Fi settings	Enable Wi-Fi connection. See "Enabling Wi-Fi" for details.
Wi-Fi spot settings	Make SoftBank Wi-Fi spot settings.
Bluetooth	Enable Bluetooth®. See "Enabling Bluetooth®" for details.
Call	Set call options.
Mail settings	Set Mail options.
Guide	Show/hide Guide indicator.
Data usage	Check data usage and set limit.
Storage	Check handset/SD Card memory status, mount SD Card and erase SD Card files.
Application	Check installed applications and running applications.
Data transfer	Import files from other mobiles using SD Card or Bluetooth®, or save handset files to SD Card.
Other settings	Set operation of other functions.



In app sheet, 🏩 (Settings)



Settings appear.

2

Set each item

#### Sound/Notification Settings

#### Sound/Notification Settings

Set Manner mode as well as make settings for ringtone, operation tones, etc. Settable items are the following.

Item	Description
Mode settings	Set Manner mode.
Media volume	Set volume for music, videos, etc.
Alarm volume	Set volume for Alarm.
Ring volume	Set volume for ringtones for incoming calls, etc.
エモパー volume	Set volume for emopa.
For Incoming call	Set ringtone and other options for incoming calls.
Interruptions	Control interruption of incoming calls and notifications.
For new	Set ringtone and other options for
message	incoming messages.
For notification	Set sound and other options for notifications.
When device is locked	Set whether to show all notifications when Display is turned off (Screen lock active).
App notifications	Block notifications from applications or set priority for notifications.
Notification	Control access of applications to
access	notifications.
Other sounds	Set whether to play sound when Tapping menu items, etc. or to vibrate handset when Tapping dialpad, etc.



In app sheet, 🏩 (Settings)



2

#### Sound/notification



Sound/notification menu opens.



Set each item

Setting is complete.

#### Sound/Notification Operations

#### Setting Manner Mode

In Sound/notification menu, Mode settings 
Standard manner mode / Silent manner mode

- · To cancel Manner mode, Tap OFF .
- · Camera shutter sound, video recording tones, music, video/game sounds, etc. still play even in Manner mode.

#### Setting Volume for Music, Videos, Etc.

In Sound/notification menu, Drag Media volume slider to adjust volume

· Sound plays at set volume when releasing finger from slider.

#### Setting Volume for Alarm

In Sound/notification menu, Drag Alarm volume slider to adjust volume

 Sound plays at set volume when releasing finger from slider.

# Setting Volume for Ringtones for Incoming Calls, Etc.


In Sound/notification menu, Drag Ring volume slider to adjust volume  $\,$ 

· Sound plays at set volume when releasing finger from slider.

#### Setting Volume for emopa

In Sound/notification menu, Drag  $\mathbb{I} \mp l \ ^{\circ} -$  volume slider to adjust volume

 $\boldsymbol{\cdot}$  emopa speaks at set volume when releasing finger from slider.




Setting Days and Times for which to Receive Calls and Notifications Set as Priority Interruption In Sound/notification menu, Interruptions 


Days → Tap day ( ✓ ) → DONE → Start time / End time 🔵 Follow onscreen prompts · Effective when "When calls and notifications arrive" is set to "Always interrupt." Setting Ringtone for Incoming Messages In Sound/notification menu, For new message > Select ringtone 🗦 Tap option ( Sound/Ringtone , Media Storage , etc.) 🔷 JUST ONCE / ALWAYS 🔷 Tap tone/file 
OK  $\cdot$  Sound plays when Tapping a tone/file. To stop playback, Tap Play/stop. 'To always use selected option, Tap ALWAYS . Setting Vibration Pattern for Incoming Messages In Sound/notification menu, For new message > Select vibration 🗦 Tap pattern 🗦 OK  $\cdot$  Handset vibrates when Tapping a pattern. Setting Notification Lamp Illumination Color for Incoming Messages In Sound/notification menu, For new message 

Select lamp color 🗦 Tap item 🗦 OK · If set color is not supported by handset, Notification Lamp does not illuminate in that color. Setting Ringtone, Vibration Pattern or Notification Lamp Illumination Color for Incoming Messages by Contact In Sound/notification menu, For new message 🗦 Individual ringtone setting 

Select contact 

Select ringtone] / [Select vibration] / [Select lamp color] 🔷 Follow onscreen prompts Canceling Ringtone, Vibration Pattern and Notification Lamp Illumination Color for Incoming Messages by Contact In Sound/notification menu, For new message 🗦 Individual ringtone setting > Select contact > Cancel Individual Ringtone 🔵 OK





#### Wallpaper & Display Settings

#### Wallpaper & Display Settings

Set Wallpaper, Display brightness, etc. Settable items are the following.

Item	Description
Wallpaper	Set Wallpaper for Home Screen.
Welcome Sheet	Set Wallpaper and other options for Welcome sheet (lock screen).
Screen edge effect	Set operation when Display turns on, etc.
Brightness level	Set Display brightness.
Screen timeout	Set a period of inactivity after which Display turns off automatically.
Quality mode	Select image quality according to purpose, or set handset to adjust image quality automatically.
When device is rotated	Set whether to rotate Display with handset orientation automatically.
Screen lock during call	Set whether to lock screen during calls to prevent Touchscreen misoperation.
Font Settings	Set font size and font type.
Daydream	Set screensaver to activate when Display turns off while charging.
Display left percents of Battery	Set whether to show battery strength in percent beside battery indicator on Status Bar.

1

In app sheet, 🏩 (Settings)



2

#### [Wallpaper & display]



🔀 Wallpaper & display menu opens.

3


Set each item

Setting is complete.

■ Wallpaper & Display Operations



setting





#### **Energy Saving Settings**

#### Using Energy Saving Settings

Use handset in an energy-saving mode by changing settings of Display, etc. at once.



In app sheet, 🌼 (Settings)



2





🔀 Energy saving settings appear.



Energy save



- Setting is complete.
- $\cdot$  Energy save symbol appears green when Energy saving settings are enabled.
- Energy Saving Setting Operations

#### Disabling Energy Saving Settings

In Energy saving settings (Energy save symbol appears green), Energy save (Energy save symbol appears gray)

#### Changing Energy Saving Settings Individually

In Energy saving settings, Edit 
Tap setting Follow onscreen prompts







#### Changing Energy Saving Settings According to Battery Level

Set Energy saving settings to be enabled when battery level falls below a certain level.



In app sheet, 🏩 (Settings)



2







Energy saving settings appear.

for Switch by batt. ( <a> )</a>



4

Tap bar to set battery level at which to enable Energy save



# Changing Energy Saving Settings by Time of Day

Set handset to enable/disable Energy saving settings automatically at a preset time of day.



In app sheet, 🏩 (Settings)



2





Energy saving settings appear.








Set timer window opens.



Tap switch time ( Switch time 1 , etc.)





6



7



#### Using Energy Save Standby

Restrict the operation of background applications while Display is turned off (Screen lock active).



In app sheet, 🏩 (Settings)



2

Energy saving 🗦 Energy save standby



Energy save standby window opens.

3

ECO STANDBY



- Setting is complete.
- ECO STANDBY symbol appears green when ECO STANDBY is enabled.
- Energy Save Standby Operations

#### Disabling Energy Save Standby Settings

In Energy save standby window (ECO STANDBY symbol appears green), ECO STANDBY (ECO STANDBY symbol appears gray)

# Setting Applications with Restricted Operation in Energy Save Standby

In Energy save standby window, EDIT 
RUN for applications to set (BLOCK appears) 
YES

• To cancel restricted operation, Tap BLOCK for set application (RUN appears).

#### Energy Save Standby Cautions

#### Applications with Periodic Data Communication

Depending on the application, data communication may not be carried out correctly after ECO STANDBY is switched from enabled to disabled. Power handset off then back on. May not work properly while charging handset even if BLOCK is set in EDIT.

#### **ECO STANDBY**

ECO STANDBY restricts the operation of background applications while Display is turned off (Screen lock active). Some functions may not operate correctly.

#### **Battery Settings**

Check Battery usage.

1

In app sheet, 🌼 (Settings)



2

Energy saving) 🔵 [Battery]



Battery window opens.

3

Tap item

Details of Battery usage appear.

# Home Applications Setting

#### Home Applications Setting

Set Home application.

1

In app sheet, 🏩 (Settings)



2

Home applications



Mome applications window opens.

3

Tap Home application

Setting is complete.

#### ■ Delete Home Applications

In Home applications window, 

Follow onscreen prompts

 $\cdot$  Preinstalled Home applications cannot be deleted.

#### **Useful Settings**

#### Useful Settings

Set useful functions such as emopa, Clip Now, and Grip Magic. Settable items are the following.

Item	Description
エモパー (Japanese only)	Set what information to receive and how to receive it from emopa. For details on emopa, see "エモパーを利用する (http://help.mb.softbank.jp/aquoscrystal2/pc/09-10.html)" (Japanese).
Clip Now	Set what action occurs when sliding your finger along the edge of Display.
Grip magic	Set actions that occur when handset is picked up or set down.
On/off with motion	Set how operation of handset turns Display on or off.
Recent apps key	Set actions that occur when Recent apps key is Tapped.
Self check	Diagnose handset or restart in Safe mode.

1

In app sheet, 🏩 (Settings)



2

Useful



Useful window opens.

3

Set each item

# Handset Settings

#### On/Off with Motion Settings

Set how operation of handset turns Display on or off. Settable items are the following.

Item	Description
Bright Keep	Set whether to keep Display from turning off while handset is held.
Turn off by putting flatly	Set whether Display turns off when handset is placed flat.
Sweep ON	Set whether Display turns on when Display is Flicked while it is turned off (Screen lock active).
Let's Try!	View tutorial on Sweep ON.



In app sheet, 🏩 (Settings)





#### [Useful]



Useful window opens.

#### 3

#### On/off with motion



On/off with motion window opens.

#### 4

Set each item

Setting is complete.

#### On/Off with Motion Operations


#### Setting Whether to Keep Display On while Holding Handset

In On/off with motion window, Bright Keep → ON (Notify) / ON (Not notify) / OFF

- · For ON (Notify), 🔊 appears on Status Bar.
- · Hand-held state is determined from handset angle and Proximity/Light Sensor; usage status may affect determination of hand-held state.

#### Setting Whether to Turn Off Display when Handset is Placed Flat

In On/off with motion window, Turn off by putting



- · Tap Turn off by putting flatly to toggle on ( ✓ )/off ( 🗌 ).
- · Available when Bright Keep is enabled.
- · May not work properly depending on application in use.

#### Setting Whether to Turn On Display by Flicking when Display Off (Screen Lock Active)

In On/off with motion window, Sweep ON → ON / Enable while holding(When grip sensor is enabled) / OFF

- $\cdot$  For "Enable while holding(When grip sensor is enabled)," function is available when Grip Magic is enabled.
- · If confirmation appears, follow onscreen prompts.

#### Viewing Tutorial on Sweep ON

In On/off with motion window, Let's Try! 

Follow onscreen prompts

#### Recent Apps Key Setting

1

In app sheet, 🌼 (Settings)



2

#### [Useful]



Useful window opens.

3

#### Recent apps key



4

#### Quick Launcher / Recent applications



Setting is complete.

#### Self Check Settings

Diagnose handset by selecting items to diagnose from functions/components.



In app sheet, 🌼 (Settings)



2

#### [Useful]



Useful window opens.

3

#### Self check



Self check window opens.

4

#### START CHECKING



Select checking method window opens.

#### SELECT FROM PHONE FUNCTIONS



6

Tap item(s) to diagnose ( ✓ ) → Next



7

Next



8

#### Start diagnosis




9

Follow onscreen prompts

Diagnosis results appear.

· Tap diagnosis result for detailed result screen.





Viewing Self Check Diagnostic History

In Self check window, Tap the diagnostic history to view 
Self check window, Tap the diagnostic history to view

#### About phone

#### About phone

Check handset status or calibrate sensors.



In app sheet, 🌼 (Settings)




2

About phone



About phone menu opens.

- · For details on Software Update, see "Updating Software."
- About Phone Operations



# Setting a Cellular Provider In About phone menu, Carrier Setting YES Follow onscreen prompts Checking Legal Information, Authentication Information, or Technical Regulations Conformity Certification and FCC ID Handset conforms to technical regulations pursuant to the Radio Law and the Telecommunications Business Law. In About phone menu, Legal information / Authentication / Technical Regulations Conformity

 $\dot{}$  For  $\ensuremath{\mathsf{Legal}}$  information , follow onscreen prompts.

Certification/FCC ID

#### **Accounts Settings**

#### Accounts Settings

Create/add accounts; sync them as needed.

1

In app sheet, 🏩 (Settings)



2


Accounts



3

Add account  $\bigcirc$  Tap account type  $\bigcirc$  Follow onscreen prompts

- An account is added.
- Select Applications to Sync by Account



# Call Settings

Call Settings



In app sheet, 🏩 (Settings)



2





3

Set each item

- Setting is complete.
- · For details on call settings, see "Call Settings."

# Mail Settings

Make settings for S! Mail/SMS.

#### Common Settings

Settable items are the following.

Item	Description
Message Notice	Set items that appear in notification for new messages.
Sound/ Vibration	Set ringtone, vibration, lamp, etc. for new messages.
Thread Mode	Enable/disable conversation thread view for messages.
Color Style Setting	Change the screen design.
Font Size options	Set the font size.
SMS/S!Mail Automatic Switching	Enable/disable automatic switching between S! Mail and SMS at sending.
Show Subject Field	Set whether to enable Subject field to be shown in thread details.
Double enlarge image	Show small images at double-size.
My Pictogram Setting	Change the display order of or delete My pictograms.
Decore Picture Setting	Change the display order of or delete decore mail pictures.
Mail Save&Load	Back up/restore message data or export/ import message data in vMessage format.
Spam mail folder	Enable/disable sorting of messages from senders not in Address Book to Spam Box.
Initialization	Return message settings to defaults.
Advanced Settings	Set whether to enable old messages to be automatically deleted, and set number of messages that can be saved. Check used space on SD Card and handset.


1

In app sheet, 🌼 (Settings)



2

#### [Mail settings]



- Mail settings appear.
- · Alternatively, in Feel Home, 📄 (Mail) 🔷 🌣 .
- 3

#### Common Settings



- Common Settings appear.
- 4

Set each item

#### Send/Receive Settings

Settable items are the following.

Item	Description
Receive Settings	Set what portions of message to first retrieve (e.g., notification only) and whether to automatically check new messages when activating Mail.
Send Settings	Set whether to quote a message when replying to S! Mail, set a size limit on images to send, set whether to request delivery reports for sent messages, set whether to show confirmations, and set character encoding.
Wi-Fi Connection	Make S! Mail settings for Wi-Fi connections.
SMS Send/ Receive Settings	Set the application used for sending/receiving SMS.
Display Progress	Set whether to send and receive messages in the background.



In app sheet, 🏩 (Settings)



#### Mail settings



Mail settings appear.

· Alternatively, in Feel Home, 📄 (Mail) 🗦 🌣 .

#### Send/Receive Settings



Send/Receive Settings appear.



Set each item

#### Mail Group Settings




In app sheet, 🌼 (Settings)



2

[Mail settings]



Mail settings appear.

· Alternatively, in Feel Home, 📄 (Mail) 🗦 🌣 .





[Mail Group Settings]



Mail Group Setting appears.

#### Mail Group Setting Operations





#### Number/Address Settings

Settable and viewable items are the following.

Item	Description
Phone Number	View phone number.
Mail Address	View mail address.
Change Mail Address	Navigate to My SoftBank to change mail address, etc.



In app sheet, 🏩 (Settings)



#### 2

#### [Mail settings]



- Mail settings appear.
- · Alternatively, in Feel Home, 📄 (Mail) 🗦 🗘 .

#### 3

#### Number/Address Settings



- Number/Address Settings appear.
- 4

Set each item

Setting is complete.

# **Guide Setting**

#### **Guide Setting**

Set whether Guide indicator always appears on Status Bar.



In app sheet, 🏩 (Settings)



2

#### Guide



- Guide Indicator Setting appears.
- 3

Drag switch to OFF or ON 

Done



#### Data Usage Settings

Check your amount of cellular data usage (per month) and restrict usage.

Data usage is only as tracked by handset, and may differ from actual data usage statement.

#### Checking Data Usage

Check data usage.



In app sheet, 🏩 (Settings)



2

Data usage



Data usage window opens.



Set each item


Setting is complete.

#### Data Usage Window Layout



- 1 Show cycle for checking data usage/set cycle reset date<sup>1</sup>.
- 2 Data communication limit line
- 3 Data communication alert line
- 4 Services used during period
- 5 Open menu.
- 6 Enable/disable cellular data communication.
- 7 Limit cellular data communication.
- 8 Data usage
- 1 Data usage cycle is reset on the same day of every month (at time of purchase, day before first handset activation) (Reset date settable).

#### Data Usage Operations



#### Limiting/Alerting Data Usage

Set an upper limit and alert position on data usage beforehand to receive alerts and notifications of limited usage when the upper limit is approached.



In app sheet, 🏩 (Settings)



2

[Data usage]



Data usage window opens.

3

Set cellular data limit) ⇒ OK







Amount is shown on data communication limit line (red).



Drag data communication limit line (red) up/down to set upper limit





Drag data communication alert line (black) up/down to set alert amount



- Upper limit and alert amount on data usage are set.
- $^{\cdot}$  When data usage reaches the alert amount,  ${\color{red}\underline{\Lambda}}$  appears at top of Display, and when it reaches the upper limit, notification indicating that cellular data communication is disabled appears. Follow onscreen prompts.

#### Storage Settings

#### Storage Settings

Check handset and SD Card memory space, mount or unmount SD Card, and erase SD Card files. Settable items are the following.

· Available items vary depending on status of SD Card, etc.

Item	Description
Total space	Check total handset memory/SD Card space.
Available	Check free handset memory/SD Card space.
Mount	Mount SD Card for use on handset.
microSD	See "Unmounting SD Card" for details.
Unmount	Unmount SD Card to remove it safely.
microSD	See "Unmounting SD Card" for details.
Erase microSD	Format SD Card. See "Formatting SD Card" for details.
Encrypt microSD	Encrypt SD Card.
Release microSD encryption	Decrypt SD Card.
Export to microSD	Copy files in handset memory to SD Card.
Import to phone	Copy files in SD Card to handset memory.

#### 1

In app sheet, 🛊 (Settings)



2

[Storage]




🟁 Storage menu opens.



Set each item

Setting is complete.

#### Storage Operations



#### Cautions for SD Card Encryption/ Decryption

Observe the following when encrypting/decrypting SD Card files.

- · Charge handset adequately beforehand, and keep handset charged during the process.
- $\cdot$  Set Lock No. passcode/password for unlocking screen beforehand.
- Encryption/decryption is not available if there is not enough free space on SD Card.
- $\cdot$  Encrypted SD Card cannot be used on any device other than the one used for encrypting the SD Card.
- $\cdot$  To use encrypted SD Card normally, decrypt the SD Card.
- If you perform Reset all with SD Card encrypted, files on the SD Card will be unusable. Disable encryption before performing Reset all.
- $\cdot$  SD Card becomes read-only when installed in a device that has been used for encrypting another SD Card.
- · To write to read-only SD Card, encrypt it.
- SD Card encryption/decryption may take some time. Do not stop charging or remove SD Card during the process. If the process is interrupted, SD Card files may be lost.

### **Application Settings**

### **Application Settings**

Check information on installed applications and running applications.



In app sheet, 🌼 (Settings)



2

### Application



- Application menu opens.
- $\cdot$  Flick application list left/right to show applications by category (DOWNLOADED, RUNNING, or ALL).



Tap application



4

Set each item

Setting is complete.

### Data Transfer

Import files from other mobiles using SD Card or Bluetooth®, or save handset files to SD Card.

### !

### **Data Transfer Cautions**

### Caution for Importing

Import is not available if there is only a little free space on handset memory. Process stops if Battery runs low. Operate with adequate battery charge whenever possible.

### Caution for Saving

Saving files requires at least 11 MB of free space in handset memory. Process stops if Battery runs low. Operate with adequate battery charge whenever possible.

### Importing Files from SD Card

Import files (contacts, messages, bookmarks, Calendar, Notepad, User/Learning dictionary, emopa) saved to SD Card on other mobiles or handset to handset.

- · Insert SD Card containing a backup file beforehand.
- $\cdot$  Contacts may not be imported correctly depending on the device used for saving them.



In app sheet, 🏩 (Settings)



2

### Data transfer



- Data transfer window opens.
- · In Data transfer window, Tap Function information to view a video tutorial (Japanese) on the Sharp Website.







• If SD Card is not inserted or there is no backup file on inserted SD Card, Select device to import from window appears. Follow onscreen prompts.



Tap type of data to import 
Tap file to import 
Add registration

Tap type of data to import 
Add



· When Mail is selected, Mail application activates. Follow onscreen prompts.



### YES

- Import starts.
- · If confirmation appears, follow onscreen prompts.



### Complete

- Import is complete.
- Personal Dictionary/Learning Dictionary Import Caution

When importing User/Learning dictionary (S-Shoin), existing User/Learning dictionary (S-Shoin) files on handset memory will be deleted.

### Importing Contacts via Bluetooth®

Import contacts from other mobiles using Bluetooth®.

· Enable Bluetooth® beforehand.



In app sheet, 🌼 (Settings)



2

### Data transfer



- Data transfer window opens.
- In Data transfer window, Tap Function information to view a video tutorial (Japanese) on the Sharp Website.



Data import 🔶 [Import phonebook data from smartphone.]



· If SD Card is not inserted or there is no backup file on inserted SD Card, Select device to import from window appears. Follow onscreen prompts.



Follow onscreen prompts



Import of contacts is complete.

### Saving Files to SD Card

Save files (contacts, messages, bookmarks, Calendar, Notepad, User/Learning dictionary, emopa) on handset to SD Card.

- · Insert SD Card beforehand.
- $\cdot$  Depending on target device, files saved on handset may not be imported correctly.



In app sheet, 🏩 (Settings)



2

[Data transfer]



Data transfer window opens.

3

Save data to microSD



· Tap Function information to view a video tutorial (Japanese) on the Sharp Website.

4

Enter Operation Password 
OK



Tap item(s) to save

 $\boldsymbol{\cdot}$  When saving contacts, confirmation for saving face image appears. Follow onscreen prompts.

6







- Save starts.
- · When saving Mail messages, Tapping Save activates あんしんバックアップ (Anshin Backup). Follow onscreen prompts. See "あんしんバックアップを利用する (http:// help.mb.softbank.jp/aquos-crystal2/pc/09-02.html)"(Japanese) for details.



Complete

Save is complete.

## Other Settings

### Other Settings

Make settings for other functions. Settable items are the following.

Item	Description
Location	Enable location information.
Network settings	Set Airplane mode or make network settings such as Cellular networks.
Lock & Security	Set Screen lock, Operation Password, etc.
Secrecy settings	Specify settings for hiding contacts.  See "Hiding Contacts (Secrecy Settings)" for details.
Contacts data access monitor	Control access of applications to Address Book.
Language & input	Set functions for language and text entry.
Date & time	Set functions for date and time.
Accessibility	Set functions for text-to-speech, etc.
Printing	Set up cloud printing.
Backup & reset	Back up application data and handset settings including Wi-Fi password to Google server, or delete all handset memory files.



In app sheet, 🏩 (Settings)



2

Other settings



Other settings appear.



Set each item

Setting is complete.

### Location Information Settings

Enable location information. Settable items are the following.

Item	Description
Mode	Set whether wireless networks and GPS are used for obtaining current location.  Obtained location information is used by applications.
Recent location requests	View applications that have recently used location information.
Location services	Make settings for applications that use location information.



In app sheet, 🌼 (Settings)



2

### Other settings



Other settings appear.



### Location



Location window opens.







5

### DISAGREE / (AGREE)



- Setting is complete.
- To disable use of location information, Tap On ( Off appears).
- Changing Accuracy of Location Information

In Location window, Mode 

Tap location mode

- $\cdot$  Available when Location is enabled.
- $\cdot$  If confirmation appears, follow onscreen prompts.

### Network Settings

Set Airplane mode and make network settings. Settable items are the following.

Item	Description
Airplane mode	Leaving power on, suspend signal-transmitting functions.
Default SMS app	Set application for sending/receiving SMS.
NFC/Osaifu- Keitai settings	Set behavior of NFC and Osaifu-Keitai®.
Wireless output	Set wireless output.
VPN settings	Set VPN destinations.
Cellular networks	Set Network options. For details on cellular providers and data roaming, see "Global Roaming."
Proxy settings	Make proxy settings.
VoLTE voice call <sup>1</sup>	Set whether to use LTE for voice calling.

1 Requires separate subscription



In app sheet, 🏩 (Settings)



2

Other settings



Other settings appear.

3

Network settings



Network settings appear.

4

Set each item

Setting is complete.

Network Settings Operations



In Network settings, Airplane mode

Tap Airplane mode to toggle on ( )/off ( ).

### Setting Application for Sending/Receiving SMS

In Network settings, Default SMS app 
Tap application

### Adding VPN Destinations

SAVE

 Available when Screen lock option is set to Pattern, Lock No., or Password.

• Tap an added VPN to connect/disconnect it. Touch & Hold to edit/delete it.

### Enabling/Disabling Data Roaming

In Network settings, Cellular networks → Data roaming

- · Tap Data roaming to toggle on ( )/off ( ).
- · If confirmation appears, follow onscreen prompts.

# Selecting Whether to Use 4G LTE & 4G Networks

In Network settings, Cellular networks → Use 4G

· Tap Use 4G to toggle on ( ✓ )/off ( □ ).

### Adding Access Points

In Network settings, Cellular networks 🗦 (Access Point





### Lock & Security Settings

Make security settings including Screen lock and security codes. Settable items are the following.

 $\cdot$  Available items vary depending on handset settings.

Available recilis	vary depending on handset settings.
Item	Description
Operation password setting	Set Operation Password to use or change some functions. See "Setting Operation Password" for details.
Screen lock	Set Screen lock option.
Make pattern visible	Set whether to show a pattern drawn when unlocking screen.
Automatically lock	Set an amount of time before screen is locked after Display turns off automatically.
Power key to lock instantly	Set whether to lock screen immediately after Pressing ①.
Owner info	Show owner information in Welcome sheet (lock screen).
Smart Lock	Set whether to unlock screen automatically by identifying a trusted device, place, face, or voice.
Set up USIM card lock	Set whether to require PIN entry when powering on. See "USIM PIN" for details.
Encrypt phone	Encrypt handset.
Visible passwords	Show/hide passwords as you type.
Device administrator	Enable/disable device management options.
Unknown sources	Enable/disable installation of non-Google Play applications.
Storage type	Check storage type.
Use secure credentials	Control access of applications to secure certificates and other authentication information.
Install certificates	Install encrypted authentication information.
Clear credentials	Delete all authentication information and reset password for authentication information storage.
Trust agents	Show/hide trusted agents.
Screen pinning	Make only specified application accessible on handset.
Apps with usage access	Control access of applications to application usage history.



In app sheet, 🏩 (Settings)





### Other settings



Other settings appear.



### Lock & Security



Lock & Security menu opens.



Set each item

Setting is complete.

### Lock & Security Operations

# Disabling Screen Lock In Lock & Security menu, Screen lock → None · When Screen lock option other than None or Swipe is set, after Tapping Screen lock , unlock screen to proceed.

### Requiring Dragging for Unlocking Screen

In Lock & Security menu, Screen lock > Swipe

· When Screen lock option other than None or Swipe is set, after Tapping Screen lock , unlock screen to proceed.

### Requiring Pattern Drawing for Unlocking Screen

In Lock & Security menu, Screen lock Pattern Draw pattern CONTINUE Draw pattern again CONFIRM Select how you want to handle notifications when Screen lock is active DONE

- When Screen lock option other than None or Swipe is set, after Tapping Screen lock , unlock screen to proceed.
- When drawing a pattern to unlock screen, input will be disabled for 30 seconds after five consecutive failures.

### Requiring Passcode Entry for Unlocking Screen

In Lock & Security menu, Screen lock → Lock No. →
Enter passcode → CONTINUE → Re-enter passcode
→ OK → Select how you want to handle notifications
when Screen lock is active → DONE

 $\cdot$  When Screen lock option other than None or Swipe is set, after Tapping  $\mbox{ Screen lock }$  , unlock screen to proceed.

### Requiring Password Entry for Unlocking Screen

In Lock & Security menu, Screen lock Password

Enter password CONTINUE Re-enter

password Select how you want to handle

notifications when Screen lock is active DONE

• When Screen lock option other than None or Swipe is set, after Tapping Screen lock , unlock screen to proceed.

# Setting Whether to Show a Pattern Drawn when Unlocking Screen

In Lock & Security menu, Make pattern visible

- · Tap Make pattern visible to toggle on ( )/off ( ).
- · Available when Screen lock option is set to Pattern.

### Setting an Amount of Time before Screen is Locked after Display Turns Off Automatically

In Lock & Security menu, Automatically lock 
→ Tap time

 Available when Screen lock option is set to Pattern, Lock No., or Password.

# Setting Whether to Lock Screen Immediately after Pressing (\*\odots)

In Lock & Security menu, Power key to lock instantly

- Available when Screen lock option is set to Pattern, Lock No., or Password.
- Tap Power key to lock instantly to toggle on ( )/ off ( ).

### Setting Whether to Show Owner Information in Welcome Sheet (Lock Screen)

In Lock & Security menu, Owner info 
Show owner

### info on lock screen

- · Tap Show owner info on lock screen to toggle on ( ✓ )/off ( ☐ ).
- · After enabling "Show owner info on lock screen," enter owner information.
- · To show owner information, Tap 📵 in Welcome sheet (lock screen). (Tap 🔞 to hide it.)

### Unlocking Screen Automatically when Tapping IC Card (NFC) or Connecting Bluetooth® Device

In Lock & Security menu, Smart Lock 

Enter pattern/ Lock No. passcode/password (a) Trusted devices (b) ADD TRUSTED DEVICE 

Bluetooth / NFC 

Follow onscreen prompts

- · Available when Screen lock option is set to Pattern, Lock No., or Password.
- · If a Bluetooth® device is set as a trusted device, screen is unlocked while handset is connected to the Bluetooth® device. If an IC card (NFC) is set as a trusted device. unlock screen by placing the IC card (NFC) on the back of handset while Display is turned on.
- · When selecting Bluetooth, enable Bluetooth® and pair handset with a Bluetooth® device beforehand.

### Deleting IC Cards (NFC)/Bluetooth® Devices Saved as Trusted Devices

In Lock & Security menu, Smart Lock 🗦 Enter pattern/ Lock No. passcode/password > Trusted devices > Tap IC card/Bluetooth® device OK / REMOVE TRUSTED DEVICE)

· Available when Screen lock option is set to Pattern, Lock No., or Password.

### Unlocking Screen Automatically in Specified Locations

In Lock & Security menu, Smart Lock → Enter pattern/ Lock No. passcode/password  $\Rightarrow$  Trusted places  $\Rightarrow$ Home / Add trusted place 🗦 Follow onscreen prompts

· Available when Screen lock option is set to Pattern, Lock No., or Password.

### Deleting Locations Saved as Trusted Places

In Lock & Security menu, Smart Lock 

Enter pattern/ Lock No. passcode/password 
Trusted places 
Tap location 

Delete

· Available when Screen lock option is set to Pattern, Lock No., or Password.

### Unlocking Screen Automatically Using Face Recognition

In Lock & Security menu, Smart Lock 

Enter pattern/ Lock No. passcode/password 
Trusted face 
SET UP > NEXT > Align face with guide > "Got it" appears NEXT NEXT

- · Face recognition starts automatically when Display turns on, then screen will be unlocked.
- · Available when Screen lock option is set to Pattern, Lock No., or Password.
- · To improve face recognition accuracy, Tap Improve face matching . Follow onscreen prompts.

### Deleting Face Recognition Setting

In Lock & Security menu, Smart Lock → Enter pattern/ Lock No. passcode/password 
Trusted face Remove trusted face 🔵 REMOVE

· Available when Screen lock option is set to Pattern, Lock No., or Password.

### Unlocking Screen Automatically when Saying "OK Google" to Handset

In Lock & Security menu, Smart Lock 

Enter pattern/ Lock No. passcode/password 
Trusted voice Follow onscreen prompts

- · Available when Screen lock option is set to Pattern, Lock No., or Password.
- · May be unavailable depending on handset interface language.

### Setting Whether to Keep Screen Unlocked while Handset is Held or on Your Body

In Lock & Security menu, Smart Lock → Enter pattern/ Lock No. passcode/password 
On-body detection Off / On


- · Available when Screen lock option is set to Pattern, Lock No., or Password.
- · If confirmation appears, follow onscreen prompts.
- · Tap Off / On to enable/disable the setting.

### **Encrypting Handset Files**

In Lock & Security menu, Encrypt phone 

ENCRYPT PHONE ( ENCRYPT PHONE )

- · If confirmation appears, follow onscreen prompts.
- · Charge handset adequately beforehand, and keep handset charged during the process.
- · If encryption is interrupted, all handset files will be deleted.



onscreen prompts

- · Available when Screen lock option is set to Pattern, Lock No., or Password.
- · Authentication information may be required when setting a Wi-Fi network. How to obtain authentication information depends on issuer.

### Deleting All Credentials and Resetting Credentials Storage Password

In Lock & Security menu, Clear credentials 🔷 OK

· By erasing credentials storage, all VPN settings are also

### Showing/Hiding Trusted Agents

In Lock & Security menu, Trust agents 🗦 Tap agent

- · Available when Screen lock option is set to Pattern, Lock No., or Password.
- · Tap agent name to toggle on ( )/off ( ).

### Making Only Specified Application Accessible In Lock & Security menu, Screen pinning Off (

) 🗦 🔘 🔵 Activate target application 🗦 🔲 History 🔷 🕕 🗘 START

- · When Screen lock option is set to Pattern, Lock No., or Password, set handset to require screen unlocking to cancel Screen pinning as needed. Follow onscreen prompts.
- To cancel Screen pinning, Touch & Hold and at the same time.

### Controlling Access of Applications to Application Usage History

In Lock & Security menu, Apps with usage access 🗦 Follow onscreen prompts

### Lock & Security Cautions

### Screen Lock Caution

Do not forget pattern, Lock No. passcode or password set for unlocking screen (write it down if necessary). If you forget it, visit the nearest SoftBank Shop for recovery procedure. Note that your files and settings will be lost during the recovery process.

### Cautions for Handset Encryption

Observe the following when encrypting handset.

- · To decrypt handset, perform Reset all. See "Backup & Reset" for details.
- · When Screen lock option other than None or Swipe is set, storage decryption password entry window appears before handset starts up. Unlock screen using option set in Screen lock.
- · If incorrect pattern, Lock No. passcode or password is entered 10 times and 20 times consecutively in storage decryption password entry window, input will be disabled for 30 seconds. Note that handset will be initialized after 30 consecutive failures.
- · When changing Screen lock option to Pattern, Lock No., or Password while handset is encrypted, set whether to show storage decryption password entry window before handset starts up.

### Contacts Data Access Monitor Setting

Control access of applications to Address Book.

1

In app sheet, 🏩 (Settings)



2

### Other settings



Other settings appear.

3

### Contacts data access monitor



Contacts data access monitor window opens.

4

Tap application (a) Permit access or Prohibit access





Setting is complete.

 $\cdot$  Select "Notify statusbar." checkbox to show a notification when an application accesses Address Book.

### Language & Input Settings

Make settings for display language and text entry. Settable items are the following.

Item	Description
Current selected keyboard	Set default input method.
Google Keyboard	Set functioning of Google Keyboard.
S-Shoin	Set functioning of S-Shoin.
Google voice typing	Set voice input options.
Select language	Select handset interface language.
Voice input	Set voice input services.
Text-to- speech output	Set text-to-speech options.
Spell checker	Enable/disable spelling correction.
Personal dictionary	Save words to user dictionary.
Pointer speed	Set pointer speed for mouse/trackpad use.
Character code setting	Set character code for sending data.

1

In app sheet, 🏩 (Settings)



2

### Other settings



Other settings appear.







🔀 Language & input menu opens.

4

Set each item

Setting is complete.

### Language & Input Operations

# Setting Default Input Method In Language & input menu, Current selected keyboard Tap input method • To add/remove input method, Tap CHOOSE KEYBOARDS , then follow onscreen prompts. Setting Functioning of Google Keyboard

In Language & input menu, Google Keyboard 🗦 Tap item 

Follow onscreen prompts

### Setting Language for Voice Input

In Language & input menu, Google voice typing 🔷 Languages 
Tap language 
SAVE

· Touch & Hold language to set it as the primary language.

Setting Whether to Start Voice Search when Saying "OK Google" to Handset with 8 (Google) Active

In Language & input menu, Google voice typing 🔵 "Ok Google" detection) 🔵 [From the Google app]

· Tap From the Google app to toggle on ( )/off ( ).


# Setting Whether to Start Voice Search when Saying "OK Google" to Handset with Display On In Language & input menu, Google voice typing (Coogle voice typing) Google" detection 🔵 From any screen · Sign in to a Google Account beforehand. $\cdot$ Available when "From the Google app" is enabled. · Tap From any screen to toggle on ( )/off ( ). · An initial setting screen appears the first time the setting is enabled ( ). Follow onscreen prompts. · To perform initial setting again, Tap Retrain voice model]. · To delete saved initial setting information, Tap Delete voice model , then follow onscreen prompts. This disables "From any screen" ( ). Setting Speech Output for Voice Input In Language & input menu, Google voice typing Speech output $\Rightarrow$ Tap item · If Hands-free only is selected, speech output is available when a headset is connected. Checking Details on Installed Languages In Language & input menu, Google voice typing Offline speech recognition 🗦 Tap language Downloading Languages In Language & input menu, Google voice typing 🗦 Offline speech recognition ( ) (ALL ( ) Tap language → DOWNLOAD Setting Update Method for Languages In Language & input menu, Google voice typing 🔷 Offline speech recognition (a) (AUTO-UPDATE (b) Tap option Enabling/Disabling Blocking of Offensive Words In Language & input menu, Google voice typing Block offensive words · Tap Block offensive words to toggle on ( )/off ( ).

### Enabling/Disabling Audio Recording with a Bluetooth® Headset

In Language & input menu, Google voice typing 🔷 Bluetooth headset · Tap Bluetooth headset to toggle on ( )/off

( ).





Setting Speed of Pointer for Mouse/Trackpad In Language & input menu, Pointer speed 🗦 Drag slider to adjust speed  $\Rightarrow$  OK  $\cdot$  Pointer is faster the longer the bar is. Setting Character Code for Sending Data In Language & input menu, Character code setting Unicode / Shift\_JIS

### Date & Time Settings

Make settings for date and time. Settable items are the following.

Item	Description
Automatic date & time	Set date and time automatically.
Auto timezone	Enable/disable automatic time zone adjustment.
Set date	Set date manually.
Set time	Set time manually.
Select time zone	Set time zone manually.
Use 24-hour format	Enable/disable 24-hour format.
Choose date format	Set date format.

1

In app sheet, 🏩 (Settings)



2

Other settings



Modern Settings appear.

3

Date & time




Date & time menu opens.

4

Set each item

Setting is complete.

■ Date & Time Operations



### Accessibility Settings

Make settings for user accessibility, such as Captions and Magnification gestures.

Item	Description
Captions	Set options for captions.
Magnification gestures	Set whether to magnify screen content by Triple-Tapping Display.
Large text	Enlarge text on Display.
High contrast text	Make text easier to read by outlining, etc.
Power button ends call	Set whether to end calls when Pressing $\ensuremath{\sigma}$ .
Auto-rotate screen	Enable/disable automatic screen rotation.
Speak passwords	Set whether to announce password characters audibly.
Accessibility shortcut	Set whether to enable accessibility settings easily.
Text-to- speech output	Set text-to-speech options. See "Language & Input Settings" for details.
Touch & hold delay	Set the amount time required for Touch & Hold.
Color inversion	Invert colors of screen content.
Color correction	Correct colors of screen content.

In app sheet, 🏩 (Settings)



2

Other settings



Other settings appear.

(Accessibility



🔀 Accessibility menu opens.


Set each item

Setting is complete.

Accessibility Operations



Setting Whether to Magnify Screen Content by Triple-Tapping Display



Setting Whether to Enlarge Text on Display

· Tap Large text to toggle on ( ✓ )/off ( □ ).

Setting Whether to Make Text Easier to Read by Outlining, Etc.

In Accessibility menu, High contrast text · Tap (High contrast text) to toggle on ( ✓ )/off ( 🗌 ).

Setting Whether to End Calls when Pressing

In Accessibility menu, Power button ends call

· Tap Power button ends call to toggle on ( ✓ )/off ( 🔲 ).



### Printing Settings

Make settings for cloud printing.

1

In app sheet, 🏩 (Settings)



2

Other settings



Other settings appear.

3

Printing



Printing window opens.

· Follow onscreen prompts.

### Backup & Reset

Back up application data and handset settings including Wi-Fi password to Google server, or delete all handset memory files.

- $\cdot$  Reset all deletes all handset memory files irreversibly. Back up important data before performing Reset all.
- · Deleted content cannot be restored. Reset with caution.



In app sheet, 🌼 (Settings)



2

Other settings



Other settings appear.

3

Backup & reset




Backup & reset menu opens.

4

Set each item

Setting is complete.

Backup & Reset Operations



# For Assistance

File Storage	162
Backup & Restore	162
Troubleshooting	163
Specifications	165
Warranty & After-Sales Service	166
Customer Service	166

### File Storage

### File Save Location

Use handset memory and SD Cards to save files.
Files are saved to handset memory by default. Save locations of created files may be changed depending on application.
See below for main file types and save locations.

File Type	Description
Contacts, Bookmark, Calendar, Mail, Notepad, TV programs	Created files are saved to handset memory. Save locations are fixed.
Still images (photos), videos	Created files are saved to handset memory.

 $<sup>\</sup>cdot$  For details on SD Card insertion/removal, etc., see "Handset Memory & SD Card."

### Backup & Restore

### Backup/Restore Options

Backup and restore options are the following.

Option	Description
あんしんバック アップ (Anshin Backup)	Use あんしんパックアップ (Anshin Backup) application to back up handset files to a server in the network or to SD Card inserted in handset, and restore to handset as needed. See "あんしんパックアップを利用する (http://help.mb.softbank.jp/aquos-crystal2/pc/09-02.html)" (Japanese) for details.
Corresponding applications	Depending on application, backup/restore settings can be changed.
Data transfer	Use Data transfer in Settings to import files on other mobiles or SD Card files saved on handset, or save (back up) handset files to SD Card. See "Data Transfer" for details.
Transfer to other devices (e.g., PCs)	Connect handset to a PC or other device with Micro USB Cable and exchange files.

### Troubleshooting

### Check Here First

If symptoms continue even after checking, contact a nearby SoftBank Shop or Customer Service.

### Troubleshooting

- Q. Handset does not power on
- A. Are you Long Pressing ①? Press ① until the logo appears.
- A. Is handset recharged? Recharge handset if not charged.
- A. Did you continue to use handset while warm before it powered off? Try powering handset on after it cools down.
- Q. Handset suddenly powers off
- A. If handset continues to be used while warm, a caution appears and handset powers off after approximately 3 minutes
- Q. Handset freezes/operation is unstable
- A. If handset stops operating or no longer accepts input, force-shut down handset.
  - (Long Press for at least 8 seconds)
  - · Release ① once handset vibrates; handset powers off.
- Q. Operation is unstable after a new application was installed
- A. The newly installed application may be the cause.
  Uninstall the application in Safe mode. See
  "Uninstalling Applications." To power on handset in
  Safe mode:
  - Check Display, OK

    · While in Safe mode, "Safe mode" appears at lower

(Long Press) ( Touch & Hold Power off ( )

- While in Safe mode, "Safe mode" appears at lower left.
- After restarting in Safe mode, handset can be powered on as usual.
- By powering on handset in Safe mode, added widgets may be deleted.
- · Before powering on handset in Safe mode, it is recommended that you back up important data.
- Q. Handset initiates operation without Touchscreen being operated / Handset does not respond after Touchscreen being operated
- A. Press 🐧 to turn off screen, Press 🐧 again to turn on screen and then operate handset.

- Q. Cannot use Phone, email, or Internet
- A. Check whether you are where signal is weak or are out of service area.
- A. Power on handset again.
- A. Is Airplane mode set? If appears in Status Bar, to cancel Airplane mode:
  - (Long Press) 🔵 Airplane mode
- A. Is Cellular data disabled? To check whether Cellular data is enabled:
  - In app sheet, (Settings) Data usage
- A. Is a disabled access point set? To return to initial settings:



- Q. Battery level goes down quickly
- A. Are you where signal is weak or have been out of service area for a long period? Calling where signal is weak or being out of service area uses a lot of battery.
- A. The following shorten handset usage time: frequent use of Mobile Light, sound-emitting functions/ operations, frequent communication, etc. with an external device, brightening Display, setting a long Display-on time. Use Energy saving settings to reduce unneeded battery consumption. See "Using Energy Saving Settings" for details.
- Q. Cannot install applications
- A. Is there only a little free space on handset memory? To check free space:
  - In app sheet, 🏩 (Settings) 🗦 Storage
- A. Applications not supported by handset cannot be installed.
- Q. Display suddenly dims
- A. Display dims automatically when handset becomes warm. Display returns to original brightness once handset cools down.
- Q. Cannot unlock screen
- A. If handset stops operating or no longer accepts input, force-shut down handset.
  - (Long Press for at least 8 seconds)
  - $^{\cdot}$  Release  $\boxed{\textbf{0}}$  once handset vibrates; handset powers off.

- Q. Cannot charge / Charging takes time
- A. Is Micro USB plug on AC Charger firmly inserted in handset? Remove and then reinsert firmly.
- A. Is AC Charger firmly plugged into a household AC outlet? Unplug and plug in again firmly.
- A. Are you using a non-specified AC Charger? Always use a specified product. Using an unspecified product not only prevents charging, but may also affect Internal Battery.
- A. Is Notification Lamp blinking? In this case, handset is not being charged. Use a specified charger and charge handset.
  - If charging is still not possible, contact Customer Service or a SoftBank Shop.
- A. Is Micro USB plug on AC Charger soiled? Clean terminals with a clean, dry cotton swab, etc. before charging.
- A. Are you recharging by USB? Recharging by USB takes longer than with AC Charger. You may also not be able to recharge depending on the connection environment.
- Q. Recharging stops / Recharging does not start
- A. Recharging stops automatically if handset becomes warm. Recharging starts again once handset cools down
- Q. USIM Card is not recognized
- A. Is USIM Card installed properly? Is it installed in the right location and orientation? Turn off handset, check whether USIM Card is installed properly, and then turn handset on again. If this does not remedy the problem, USIM Card may be damaged.
- A. Are there any fingerprints, etc. or other soiling on the (gold) IC chip on USIM Card? Remove USIM Card, wipe with a clean, dry cloth, and install it again properly.
- A. Is wrong USIM Card installed? An unusable USIM Card may be installed. Make sure that the right USIM Card is installed.
- Q. Cannot recharge by USB
- A. Is the computer turned on? You cannot recharge if the computer is not turned on.
- A. Are you using a USB hub? You may not be able to recharge if using a USB hub. Connect the optional Micro USB Cable to the computer.
- Q. Cannot make a call / Calls do not connect
- A. Is Airplane mode set? If appears in Status Bar, to cancel Airplane mode:
  - **(** (Long Press) **→** (Airplane mode)
- A. Did you dial all digits for the number? Dial all digits for numbers starting with a "O" area code, etc.
- A. Are you where handset receives a signal? Check signal, change locations and call again.

- Q. Cannot hear the other party
- A. Is the call volume low? To turn the call volume up, Press Volume Up Key during a call.
- A. Is handset set to always use a handsfree device for calls? To check whether Handsfree setting is disabled:

- · Can be checked when Bluetooth® is enabled.
- Q. Touch operation does not work as expected

A. Calibrate Touchscreen as follows.

- In app sheet, (Settings) (About phone (Settings) (Adjust touch panel (Settings) (Tap center of six circles)
  - · Hold handset normally during calibration.

### Specifications

### Handset

Handset specifications are as follows.

- $\cdot$  Times in the table vary with location, status, settings, etc.
- Display employs precision technology; however, some pixels may remain on/off.

Item	Description
Weight	Approx. 153 g
Internal Battery Capacity	2,030 mAh
Continuous Talk Time¹	3G: Approx. 810 minutes GSM: Approx. 510 minutes VoLTE: Approx. 760 minutes
Continuous Standby Time <sup>2</sup>	3G: Approx. 570 hours GSM: Approx. 530 hours 4G (AXGP Network): Approx. 460 hours 4G (FDD-LTE Network): Approx. 480 hours
One Seg Continuous Viewing Time <sup>3</sup>	Approx. 9 hours
Charging Time <sup>4</sup>	AC Charger (SHCEJ1): Approx. 150 minutes AC Charger (ZTDAC1; Micro USB, 1.0 A): Approx. 150 minutes
Dimensions (W x H x D)	Approx. 71 mm x 136 mm x 11 mm (without protruding parts)
Maximum Output	3G: 0.25 W GSM (900 MHz): 2 W GSM (1800 MHz, 1900 MHz): 1 W 4G: 0.2 W
Maximum Transmission Speed <sup>5</sup>	SoftBank 4G: 110 Mbps in downlink, 10 Mbps in uplink SoftBank 4G LTE: 112.5 Mbps <sup>6</sup> in downlink, 37.5 Mbps in uplink

- 1 Average measured with handset fully charged, in strong signal conditions at rest.
- 2 Average measured with handset fully charged, without calls or operations, in strong signal conditions at rest, and with data communication and Urgent News disabled. May vary with battery strength, ambient temperature, settings, etc.
- 3 Calculated with the default settings except Automatic brightness checkbox in Brightness level unchecked, in fullscreen landscape mode, with Earphones with Mic (optional accessory), and volume at maximum, starting from handset fully-charged and continuing until 10% remaining battery charge. Usable time may vary with radio signal conditions and the content played.
- 4 Measured with power off using AC Charger.
- 5 Provided on a best-effort basis; transmission speed may decrease or transmission may become unavailable due to traffic conditions, network environment, etc. In addition, transmission speed varies by area.

6 Depending on area, maximum downlink speed is set to 75 Mbps or 37.5 Mbps.

For applicable areas, see SoftBank Website.

### TV Antenna Cable

Item	Description
Cable Length	Approx. 136 mm
Weight	Approx. 5 g
4-Pole Mini- Plug	Round type, diameter 3.5 mm, 4-pole
Materials Used/Surface Finish	Styrene-based elastomer resin + PBT resin + PA resin + Ni base + phosphor bronze + olefin-based elastomer resin + POM resin + brass + PP resin/gold plating

### Materials

Parts	Materials Used/Surface Finish			
Cabinet (Display-side)	PA resin + GF/evaporated, UV coating, printing			
Back Surface (Turquoise, Black, Pink)	PC resin + ABS resin/coating, tactile coating, printing			
Back Surface (White)	PC resin + ABS resin/coating, UV coating, printing			
Card Slot Cover	PC resin + elastomer resin + silicone rubber/evaporated, UV coating			
Power Key	PC resin/evaporated, UV coating			
Volume Up/ Down Key	PC resin/evaporated, UV coating			
Display	PC resin/UV hard coating			
Camera Window	Acrylic resin/anti-soiling surface treatment, backside printing			
Mobile Light Window	PC resin			
Speaker Screen	Nylon resin			
External Device Port	Stainless/tin plating			
USIM Tray	POM resin			

### Warranty & After-Sales Service

### Warranty

Handset purchase includes warranty.

- · Check shop name and purchase date.
- · Read warranty and keep in a safe place.
- · Warranty period is given in warranty.

### Cautions

### Damages

SoftBank Corp. is not responsible for any damages for user or third party resulting from lost opportunities to make a call, etc. due to breakage, malfunction, or trouble of product.

### Malfunction/Repairs

Information/settings on handset may be lost/changed due to malfunction or repairs. It is recommended that you keep a copy of Address Book contacts and other important information. SoftBank Corp. is not responsible for loss/change of data (contacts, images, sound, etc.) or settings due to malfunction, repairs, change of model, or any other handling.

### Disassembly/Modification

Disassembly/modification of handset is prohibited under the Radio Law. Note that handset cannot be accepted for repairs if modified.

Adhering stickers, etc. on Display or Keys or adhering decorations with glue, etc. may be deemed to be modifications, and prevent acceptance of handset for repairs.

### After-Sales Service

To request repairs, contact Customer Service or a nearby SoftBank Shop. Have details of symptoms ready.

- During the warranty period, repairs are made under the terms and conditions of the warranty.
- · After the warranty period, if handset can be repaired, repairs will be made at cost.

### Further inquiries

For more information on after-sales service, contact a nearby SoftBank Shop or Customer Service.

### Customer Service

For SoftBank handset or service information, call General Information. For repairs, call Customer Assistance.

### SoftBank Customer Support

### General Information

From a SoftBank handset, dial toll free at 157
From a landline/IP phone, dial toll free at 0800-919-0157

# Customer Assistance (Repairs/Lost Handsets)

From a SoftBank handset, dial toll free at 113
From a landline/IP phone, dial toll free at 0800-919-0113
If you cannot reach a toll free number, use the number
(charges apply) below for your service area:
Hokkaido Area, Tohoku Area, Hokuriku Area, Kanto &

Koshinetsu Area: 022-380-4380 Tokai Area: 052-388-2002 Kansai Area: 06-7669-0180

Chugoku Area, Shikoku Area, Kyushu & Okinawa Area:

092-687-0010

### Smartphone Technical Support Center

From a SoftBank handset, dial toll free at 151 From a landline/IP phone, dial toll free at 0800-1700-151

### SoftBank Global Call Center

From outside Japan, dial +81-92-687-0025 (toll free from SoftBank handsets)

If handset is lost/stolen, call this number immediately (international charges apply)

# Safety Precautions

Safety Precautions168
Important Product Information176
Handset & Hardware Care177
General Notes179
Radio Wave Exposure and Specific Absorption Rate (SAR)
Information 181
Water Resistance 182

### Safety Precautions

Read Safety Precautions before using handset.

Observe precautions to avoid injury to self or others, or damage to property.

SoftBank Corp. is not liable for any damages resulting from use of this product.

### Safety Precautions

These labels show degree of risk from improper use; learn them before reading on:

Label	Description			
<b>⚠</b> DANGER	Great risk of death or serious injury			
<b>⚠</b> WARNING	Risk of death or serious injury			
<b>⚠</b> CAUTION	Risk of minor injury or damage to property			

These symbols signify prohibited/compulsory actions; learn them before reading on:

Symbol	Description				
Prohibited	Prohibited actions				
Do Not Disassemble	Disassembly prohibited				
Avoid Liquids Or Moisture	Exposure to liquids prohibited				
Do Not Use Wet Hands	Use with wet hands prohibited				
Compulsory	Compulsory actions				
Disconnect Power Source	Unplug from outlet				

Handset, USIM Card, TV Antenna Cable, Charger (Optional Accessory), Micro USB Cable (Optional Accessory), SD Card (Optional Accessory) (Common)

### **⚠** DANGER



Use specified Charger and Micro USB Cable only.

Non-specified equipment use may cause Internal Battery to leak, overheat, burst or ignite, and may cause Charger to overheat, ignite, malfunction, etc.



Do not disassemble, modify or solder handset or related hardware.

May cause fire, injury, electric shock or malfunction. Internal Battery may leak, overheat, burst, ignite, etc. Modifying handsets is prohibited by the Radio Law and subject to penalty.



Do not wet internal handset parts or Charger.

If liquid (water, pet urine, etc.) enters handset, leaving wet or charging while wet may cause overheating, electric shock, fire, injury, malfunction, etc.

Use only as directed.



Do not charge, use, or leave handset or related hardware in extreme heat (fire, heat sources, direct sunlight, inside vehicles in the hot sun, etc.).

Do not charge, leave, use, or be carrying handset or related hardware in a warm place or where heat collects, such as under a kotatsu (blanketed warming table) or electric blanket, next to a kairo (worn warming patch), etc.

May cause warping/malfunction; Internal Battery may leak, overheat, ignite or burst. Handset or related hardware may become hot to the touch, leading to burns or other problems.



Do not force Charger into handset. Check Micro USB plug orientation; retry.

Internal Battery may leak, overheat, burst, ignite, etc. May damage or burn out External Device Port.



When handset is connected to Charger, do not apply excessive force by stomping or in any other way.

When Port or connector is damaged, charging may cause malfunction or fire. Charge as directed.

### ♠ WARNING



Do not place handset or Charger in/on ovens, microwave ovens, pressure cookers, induction stoves or other cooking appliances.

Internal Battery may leak, overheat, burst or ignite. Handset/Charger may overheat, emit smoke, ignite, malfunction, etc.



Keep handset off and Charger disconnected near gas stations or places with fire/explosion

May ignite gas. Turn off any NFC (including Osaifu-Keitai®) compatible mobile phone when using gas station facilities (If NFC (including Osaifu-Keitai®) is locked, unlock before turning mobile phone off).



Do not drop/throw or subject to strong impact.

Internal Battery may leak, overheat, burst or ignite, resulting in fire, electric shock, malfunction, etc.



If you notice unusual sound/odor, smoke or any other abnormality, follow these steps.

- 1. Grasp plug and disconnect Charger. Handset or related hardware may be hot to the touch; remove handset from Charger, being careful not to burn yourself.
- 2. Power off, being careful not to burn or injure yourself. Use in an abnormal condition may cause fire, electric shock,



Keep External Device Port or Earphones-Microphone Port away from liquids (tap water, beverage, sea water, pet urine, etc.) and conductive materials (pencil lead, metal strip/ jewelry, hairpin, etc.).

Also, do not let liquids or conductive materials enter External Device Port or Earphones-Microphone Port.

May cause fire, burns, malfunction, etc. due to shortcircuiting.

IPX is a standard for water protection; however, compliance with this standard does not mean that shortcircuiting due to adhesion of liquid can be prevented. Handset water resistance does not provide protection from sea water, pool water, hot water, etc. When liquid adheres, remove it thoroughly before charging.



Never connect Micro USB plug while handset or Charger is wet.

Handset is water resistant; however, if Micro USB plug is inserted while it is wet, liquid (tap water, beverage, sea water, pet urine, etc.) or a foreign object adhered to handset or Micro USB plug may cause overheating, burnout, fire, malfunction, burns, etc. due to electric shock, short-circuiting, etc.



Do not expose handset or related hardware to hot air from dryers or other sources to dry them or for other purposes. Avoid saunas or hot water.

Internal Battery may leak, overheat, burst or ignite. Handset/Charger may overheat, emit smoke, ignite, malfunction, etc.

### **⚠** CAUTION



Do not place handset or related hardware on unstable surfaces; take added care when vibration is set or while charging.

Handset or related hardware may fall, resulting in injury, malfunction, etc. A fall while charging may cause damage to connector.



When removing Charger from handset, hold by Micro USB plug and do not pull cord/cable.

Pulling plug by cord/cable may damage cord/cable or connector and cause fire, electric shock, etc.



For any skin irritation associated with use, discontinue use and consult a doctor.

Metal and other materials may cause skin irritation, rashes, or itchiness depending on your physical condition.



Do not touch handset or Charger for long periods during charging.

May cause low-temperature burns.



Keep handset and related hardware away from infants and pets.

Infants and pets may choke from swallowing handset or related hardware or be injured, etc.



For use of handset/related hardware by child, explain instructions and supervise use.

Misuse may cause injury or other problems.

### Internal Battery

### **⚠** DANGER

Confirm battery type; use/dispose of Internal Battery accordingly.

Symbol on Label

Battery Type

Li-ion00

Lithium-ion



Do not dispose of handset in fire.

Internal Battery may leak, burst, ignite, etc.



Do not damage (nail, hammer, stomp, etc.) handset or subject it to strong impact.

Internal Battery may leak, overheat, burst, ignite, etc.



If battery fluid gets in eyes, do not rub; rinse with clean water and consult a doctor immediately.

Eyes may be severely damaged.

### ♠ WARNING



If battery fluid contacts skin or clothes, discontinue handset use and rinse with clean water immediately.

May cause skin damage.



If charging continues even after specified Charging Time, stop charging.

Internal Battery may leak, overheat, burst, ignite, etc.



For abnormal odor, excessive heat, discoloration or distortion, move handset away from sources of flame, being careful not to burn or injure yourself.

Continued use may cause Internal Battery to leak, overheat, burst, ignite, etc.



Do not let your pet bite handset; if this occurs, do not use that handset.

Pet bites may cause Internal Battery to leak, overheat, burst or ignite. May cause handset/related hardware to malfunction, or fire may result.

### **⚠** CAUTION



Do not dispose of handset with ordinary

Battery is built into handset; take handset to a SoftBank Shop for appropriate disposal.

### Handset

### **⚠ WARNING**



Handset Display uses transparent resin. Do not subject to shock (dropping, etc.) or excessive force

May cause Display to break and scatter pieces. If Display breaks, be careful not to directly touch shards or broken parts. May cause injury.



Do not use handset while driving or cycling.

Accidents may result.

Phone use while driving or cycling is prohibited by law and subject to penalty; park legally beforehand.



Power off near electronic devices that employ high precision control systems or weak signals.

May cause electronic malfunctions or other problems. Take added care near these devices: Hearing aids, implanted pacemakers/defibrillators and other electronic medical equipment; fire alarms, automatic doors and other automatic control devices.



Inside aircraft, follow airline instructions regarding handset use.

Radio waves from handset may interfere with flight safety.



Users with a heart condition should adjust ringtone vibration and volume as needed.

May cause heart damage.



If thunder is audible while outdoors, power off; find cover.

There is a risk of lightning strike or electric shock.



Do not shine Mobile Light in eyes.

May temporarily affect eyesight or startle, leading to accidents.



Do not cover/wrap handset with a cloth or blanket while charging. In addition, do not leave handset covered with a cloth or blanket when going to bed.

Heat may collect, resulting in fire, burns, malfunction, etc.

### **⚠** CAUTION



Do not use handset when it may affect a vehicle's electronic equipment.

Handset use inside vehicles may cause electronic equipment to malfunction, resulting in accidents.



Keep handset away from magnetic items (e.g., magnetic cards).

Data on bank cards, credit cards, telephone cards, floppy disks, etc. may be lost.



Handset may become hot during prolonged use in extreme heat (fire, heat sources, direct sunlight, inside vehicles, etc.), or in a warm place or where heat collects, such as under a kotatsu (blanketed warming table) or electric blanket, next to a kairo (worn warming patch), etc.

Prolonged contact with skin may cause low-temperature burns.



When using handset for an extended period (e.g., to play game applications) while charging, handset and Charger may become hot; avoid prolonged contact with hot parts.

May cause low-temperature burns or other problems.



Always maintain some distance from Speaker while ringtones, music or other handset sounds play.

Excessive volume may damage ears or hearing.



View One Seg in a sufficiently bright location, at a reasonable distance from Display.

May deteriorate vision.



Moderate handset volume when using earphones.

Excessive volume may damage ears or hearing.

### Charger (Optional Accessory)

### **M** WARNING



Do not cover/wrap Charger with a cloth or blanket while charging. In addition, do not leave Charger covered with a cloth or blanket when going to bed.

Heat may collect, resulting in fire, burns, malfunction, etc.



Use only the specified voltage.

Non-specified voltages may cause fire, malfunction, etc.

- · AC Charger: AC 100 V 240 V Input
- $\cdot$  In-Car Charger (use in negative earth vehicles only): DC 12 V/24 V Input

Do not use power adapters designed for overseas travel. Transformer use may cause fire, electric shock or malfunction.



Unplug Charger when not in use; grasp plug and disconnect it.

If a foreign object/liquid adheres to blades, or if blades get stomped while Charger is plugged in, electric shock, fire or malfunction may result.



If liquid (water, pet urine, etc.) gets inside, grasp plug and disconnect Charger immediately.

May cause electric shock, smoke or fire.



To remove debris, grasp plug and disconnect Charger, then clean with a dry cloth.

Fire may result.



Plug Charger firmly into the outlet, keeping the plug and connector away from conductive material (pencil lead, metal strip/jewelry, etc.).

May cause fire, burns, malfunction, etc. due to electric shock or short-circuiting.



Do not touch Charger plug or connector with wet hands.

May cause electric shock, malfunction, etc.



Do not touch Charger if thunder is audible.

May cause electric shock or other problems.



Do not use Charger in high humidity or near water (in bathrooms, shower rooms, etc.).

May cause fire, electric shock or malfunction.



Do not use In-Car Charger in positive earth vehicles.

May cause fire or other problems. Use in negative earth vehicles only.



Use only the specified fuse for In-Car Charger.

Non-specified fuse may cause fire or malfunction. See In-Car Charger manual for details.

### **A** CAUTION



Before cleaning, grasp plug and disconnect Charger.

May cause electric shock or other problems.



Always grasp plug (not cord/cable) to disconnect Charger.

Pulling plug by cord/cable may damage cord/cable and cause electric shock, fire, etc.



When Charger is connected to a power strip, do not apply excessive force by stomping or in any other way.

May cause fire or malfunction.



Do not subject Charger to strong impact while it is plugged in.

May cause malfunction or injury.



Keep hands and other body parts away from blades.

May cause burns, electric shock, injury or malfunction.

### TV Antenna Cable

### **№ WARNING**



If cord is damaged, do not use TV Antenna Cable.

May cause fire, electric shock, or burn injuries.



Do not place heavy objects on top of TV Antenna Cable.

May cause fire, electric shock, or burn injuries.



Do not touch TV Antenna Cable with wet hands.

May cause fire, electric shock, or burn injuries.



Clean off dust adhering to plug of TV Antenna

May cause fire, electric shock, or burn injuries.



When disconnecting TV Antenna Cable from handset, grasp plug and pull, without forcefully pulling cord.

May cause fire, electric shock, or burn injuries.

### **↑** CAUTION



Do not store in a location that is subject to excessive dust, high humidity, or high temperatures.

May cause fire, electric shock, or burn injuries.



Do not swing handset grasping TV Antenna Cable.

May result in hitting yourself or other persons, causing injury or other accident.

### Handset Use & Electronic Medical Equipment

This section is based on "Guidelines for Use of Mobile Phones and Other Devices in Hospitals" (Electromagnetic Compatibility Conference, August 2014) and "Guidelines to safeguard implanted medical devices against radio emissions from the use of radio equipment" (Ministry of Internal Affairs and Communications).

### ♠ WARNING



Persons with implanted pacemaker/defibrillator should keep handset more than 15 cm away.

Radio waves may interfere with implanted pacemakers or defibrillators.



Before using electronic medical equipment other than implanted pacemaker/defibrillator outside medical facilities, consult the vendor on radio wave effects.

Radio waves may interfere with electronic medical equipment.



If it may not be possible to keep handset 15 cm away from other persons (e.g., in a crowded situation where you cannot move freely), suspend signal-transmitting functions (e.g., by activating Airplane mode) or power off beforehand. If an application that automatically powers handset on is installed, disable that feature before powering off. Persons with implanted pacemaker/defibrillator may be near.

Radio waves may interfere with implanted pacemakers or defibrillators causing such devices to malfunction.



Observe these rules inside medical facilities to avoid effects of radio waves on electronic medical equipment:

- · Follow instructions regarding mobile phone use within medical facilities.
- · Always turn off handset within operating rooms, intensive care units (ICU), etc.
- $\cdot$  Even in patient rooms, lobbies, or other locations where mobile phone use is permitted, keep handset at a reasonable distance away from electronic medical equipment.

### Important Product Information

### General Use

- · If your USIM Card or handset (with USIM Card inserted) is lost or stolen, suspend your service immediately. For details, contact SoftBank Customer Support, General Information.
- · Handset transmissions may be disrupted inside buildings, tunnels or underground, or when moving into/out of such places; may affect calls.
- · Use handset without disturbing others.
- Handsets are radios as stipulated by the Radio Law. Under the Radio Law, handsets must be submitted for inspection upon request.
- Charging by USB takes longer than by household AC outlet.
   Charging may not be possible/take a long time depending on connection and computer conditions.
- Handset use near landlines, TVs or radios may cause interference.
- Beware of eavesdropping.
   Because this service is completely digital, the possibility of signal interception is greatly reduced. However, some transmissions may be overheard.
- Eavesdropping

  Deliberate/accidental interception of communications
  constitutes eavesdropping.
- · Beware of harmful/malicious websites. Take added care when posting personal information.
- Display uses liquid crystal.
   When wearing polarized sunglasses and depending on the angle, the screen may appear dark or distorted.
- · An export license may be required to carry handset into other countries if it is to be used by or transferred to another person. However, no such license is required when taking handset abroad for personal use on a vacation or business trip and then bringing it back.
- Export control regulations in the United States provide that an export license granted by the US government is required to carry handset into Cuba, Iran, North Korea, Sudan or Syria.

### Heat from Handset Use

- · Handset internal temperature may increase depending on usage or environment, causing housing to heat up. (Handset may stop charging or Display brightness may be adjusted for safety.)
- After a period of handset use under such conditions, warning appears and handset shuts down after approximately 3 minutes. To lower handset internal temperature and prevent automatic shutdown, exit all applications and turn off Display.
- · After a period of Camera use at high internal temperature, warning appears and handset automatically shuts down. (Shot image is saved.)

### Camera

- · Mind etiquette when using Camera.
- · Test Camera before shooting special moments.
- $\cdot$  Do not use Camera in places where shooting is prohibited.
- Shot images may not be used/transferred without copyright holder (photographer) permission, except for personal use.

### One Seg

- · Handset transmissions may be disrupted inside buildings, tunnels or underground, or when moving into/out of such places; may affect One Seg viewing.
- As handset transmissions differ according to where used,
   One Seg viewing may not be possible in some areas. View in a location with good handset transmission.

### In-Call/Transmission Cautions

- During calls/transmissions, calling/transmission charges/ fees apply even if other functions or operations are simultaneously in use.
- · Transmissions involving JavaScript may incur high charges.

### Urgent News (Application)

- Handset receives alerts by default (Receive settings are enabled).
- · Alert tones sound even in Manner mode.
- Alerts are not received during calls/transmissions or in poor signal conditions.
- $\cdot$  Depending on usage/situation, handset may receive alerts for other areas or no alerts.
- · Standby Time may decrease when Receive settings are
- SoftBank Corp. cannot be held liable for any damages associated with this service, including accidents resulting from received information, reception timing or reception failure.

# Technical Regulations Conformity Certification

Handset conforms to technical regulations pursuant to the Radio Law and the Telecommunications Business Law. To check technical regulations conformity certification information (e.g.,  $\textcircled{\Xi}$ ):

In app sheet, ♠ (Settings) → About phone → Technical Regulations Conformity Certification/FCC ID

### Handset & Hardware Care

### Handset & Hardware Care

- · Use handset within 5°C 35°C and 35% 90% humidity.
- · Avoid extreme temperature or direct sunlight.
- $\cdot$  Handset/Internal Battery may become warm during operation or while charging. This is normal.
- · Warranty does not cover malfunctions resulting from misuse.
- · Clean handset with a soft dry cloth. Alcohol/solvent use may fade color/print.
- · Avoid scratching Display.
- · Avoid heavy objects or excessive pressure. May cause malfunction or injury.
  - · Do not sit on handset in back pants pocket.
- · Do not place heavy objects on handset inside handbags, packs, etc.
- · Handset back cover is not removable. Do not try to remove it; may cause damage or malfunction, or affect water resistance.
- · Connect only specified products to Port. Other devices may malfunction or cause damage.
- · Do not power off while using SD Card; may result in data loss or malfunction.
- · When walking outside, moderate handset volume to avoid accidents.
- · When holding handset, do not block Mic/Recorder Mic, Speaker, Mic, or Mic (Recorder Mic).
- · Do not cover Light Sensor or place a sticker/label over it; may hinder ambient light detection, resulting in malfunction of Light Sensor.

### USIM/SD Card Insertion/Removal




Open Card Slot Cover





Insert/remove USIM/SD Card



- · SD Card Slot is located above USIM Card Slot. Insert each card into correct opening in correct orientation.
- · USIM Card Insertion/Removal
- · Insert/remove USIM Tray by pulling out USIM Tray. Always power off handset beforehand.
- · When pulling out USIM Tray, gently pull it out horizontally from the edge. Do not pull USIM Tray forcefully or at an angle; damage may result.
- · When inserting USIM Tray into handset, check orientation, then gently insert it all the way horizontally.
- · When inserting empty USIM Tray, do not insert it at an angle; damage may result. Check orientation of USIM Tray, then gently insert it all the way horizontally.
- · SD Card Insertion/Removal
- $\cdot$  When inserting SD Card, gently insert it all the way horizontally with terminals facing up.
- · When removing SD Card, unmount SD Card beforehand.
- · When removing SD Card, lightly push it in and release finger (SD Card pops out slightly); gently pull it out horizontally.



Close Card Slot Cover by pressing 1 then





 $\cdot$  Press  $\bigcirc$  areas firmly so that there is no gap between handset and Card Slot Cover. Debris trapped between gasket and Card Slot may allow ingress of liquid.

### Display (Touchscreen)

Handset Display is Touchscreen.


If Display is wet, wipe it with a soft cloth.

- · Touchscreen may not respond in these situations:
  - · Use with gloves/long fingernails
  - · Use of pens, pencils or sharp objects
  - · Use with objects on/against Display
- $\cdot$  To prevent malfunctions, do not:
  - · Touch Display with wet fingers
  - · Use if Display is wet
  - · Subject Display to force/pressure
- · Place a sticker or shield (commercially-available protective film, privacy protector shield, etc.) on Display
- · To improve response, calibrate Touchscreen as follows. In app sheet, 🌼 (Settings) 🔵 About phone 🗦 Adjust touch panel 🔵 Follow onscreen prompts
- · In the following cases, Press 😈 to turn off Display, Press (b) again to turn on Display and then operate handset.
  - · Handset operates automatically without touch input
  - · Handset does not respond to touch input

### TV Antenna Cable

To view or record One Seg, connect TV Antenna Cable to Earphones-Microphone Port.

· Earphones-microphone can be connected to use with TV Antenna Cable.



- · Insert plug firmly. If plug is not inserted all the way, broadcasts may not be received or audio may not be heard.
- · As connection may be poor if Port is dirty, clean with a dry cotton swab, etc. Avoid damaging Port when cleaning.
- · Do not deform TV Antenna Cable plug or Earphones-Microphone Port. Deforming may cause malfunction.
- · Bringing earphone cord, etc. close to handset may result in noise.

### Earphones-Microphone Port

Earphones with Mic (SHLDL1) are available for separate purchase. Other earphones-microphone may not function properly on handset.

· Do not subject Earphones-Microphone Port to strong impact while using earphones-microphone; water resistance may be affected.

### Self Check

If handset is unstable, diagnose the cause as follows.

In app sheet, 🌼 (Settings) 🗦 Useful 🗦 Self check





### Forcing Power Off

If handset has stopped processing or won't respond to operation, power off forcibly as follows.

· **(**Long Press for at least 8 seconds) Release finger after vibration; handset powers off.

### Bluetooth® Function

SoftBank Corp. is not liable for any damages resulting from data/information leakage due to use of handset Bluetooth® function.

### ■Precautions

The frequency band utilized by handset Bluetooth® function is shared with industrial, scientific or medical equipment, including household microwave ovens, and used by radio stations, amateur radio stations, etc. (hereafter "other radio stations").

- 1. Before using Bluetooth®, visually check that no other radio stations sharing the same frequency band are in use nearby.
- 2. Should interference occur between handset and other radio stations, move it to a different location or cancel Bluetooth® function immediately.
- 3. For additional information and support, contact SoftBank Customer Support, General Information: From a SoftBank handset, call toll free at 157. To call toll free from a landline/IP phone, see "Customer Service."
- · Frequency Band

This radio station utilizes 2.4 GHz band.

FH1 indicates FHSS modulation with maximum transmission radius of 10 meters.

XX4 indicates a different modulation scheme with maximum transmission radius of 40 meters.

It is not possible for the radio station to avoid using the frequency band of a mobile unit identification apparatus.



### Wi-Fi (Wireless LAN)

Wireless LAN (hereafter "Wi-Fi") uses radio waves to enable communication between compatible devices within range. However, it is advisable for the user to configure security settings to avoid risk of data interception.

- · Do not use Wi-Fi near electrical appliances, audiovisual equipment or office automation equipment; may affect Wi-Fi transmission speed, availability, clarity, etc. (Especially when a microwave oven is in use.)
- · If there are multiple access points nearby, handset may not detect access points correctly.

### ■Precautions

The frequency band utilized by handset Wi-Fi is shared with industrial, scientific or medical equipment, including household microwave ovens, and used by radio stations, amateur radio stations, etc. (hereafter "other radio stations").

- 1. Before using Wi-Fi, visually check that no other radio stations sharing the same frequency band are in use nearby.
- 2. Should interference occur between handset and other radio stations, move it to a different location or disable Wi-Fi immediately.
- 3. For additional information and support, contact SoftBank Customer Support, General Information: From a SoftBank handset, call toll free at 157. To call toll free from a landline/IP phone, see "Customer Service."

### · Frequency Band

This radio station utilizes 2.4 GHz band with DSSS-OFDM modulation. Maximum transmission radius is 40 meters.

### 2.4DS/OF4

### ■Simultaneous Use with Bluetooth®

Wi-Fi (IEEE 802.11b/g/n) and Bluetooth® transmit on the 2.4 GHz band. Enabling handset Bluetooth® or using Bluetooth® devices near handset may affect Wi-Fi transmission speed, availability and clarity. Should interference occur, cancel handset Bluetooth® or discontinue Bluetooth® device use.

- · Handset supports Wi-Fi channels 1 13. Handset does not connect to access points set to other channels.
- · Available channels vary by country.
- · For use of Wi-Fi aboard aircraft, check with airline
- · In some countries/regions, there are restrictions on the use of Wi-Fi. Check the local laws and regulations before using Wi-Fi on handset abroad.

### General Notes

403SH here refers to this mobile phone "AQUOS CRYSTAL 2."

### Portrait Rights

Portrait rights protect individuals' right to refuse to be photographed or to refuse unauthorized publication/use of their photographs. Portrait rights consist of the right to privacy, which is applicable to all persons, and the right to publicity, which protects the interests of celebrities. Therefore, photographing others including celebrities and publicizing/distributing their photographs without permission is illegal; use Camera responsively.

### Copyrights

Copyright laws protect sounds, images, computer programs, databases, other materials and copyright holders. Duplicated material is limited to private use only. Use of materials beyond this limit or without copyright holder permission may constitute copyright infringement, and be subject to criminal punishment. Comply with copyright laws when using images shot with Camera.

The software contained in handset is copyrighted material; copyright, moral right and other related rights are protected by copyright laws. Do not copy, modify, alter, disassemble, decompile or reverse-engineer the software; do not separate it from hardware in whole or part.

### Open Source Software

· Handset contains software based on GNU General Public License (GPL), GNU Lesser General Public License (LGPL), and other licenses.

To check details of relevant software licenses:

In app sheet, 🌼 (Settings) 🗦 About phone 🗦 Legal information Open source licenses

· The source code of software based on GPL, LGPL, and Mozilla Public License (MPL) is provided on the following website free of charge.

https://sh-dev.sharp.co.jp/android/modules/oss/ (Japanese)

### CE Declaration of Conformity

Hereby, Sharp Telecommunications of Europe Ltd, declares that 403SH is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. A copy of the original declaration of conformity for each model can be found at the following Internet address: http:// www.sharp.co.jp/k-tai/

C € 0168

### **Battery Cautions**

Use specified Charger only.

Non-specified equipment use may cause Internal Battery to leak, overheat, burst or ignite, and may cause Charger to overheat, ignite, malfunction, etc.

Battery is built into handset. Do not dispose of handset with ordinary refuse; take it to a SoftBank Shop for appropriate disposal.

Charge handset in ambient temperature 5°C - 35°C; Internal Battery may leak/overheat and performance may deteriorate outside this range.

### Volume Level Caution

To prevent possible hearing damage, do not listen at high volume levels for long periods.



### ■Headphone Signal Level

The maximum output voltage for Music Player function, measured in accordance with EN 50332-2, is 116 mV.

### Stand-by Mark

**(**): This symbol means the stand-by on/off.

### FCC Notice

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

#### ■FCC Information to User

This equipment has been tested and found to comply with the limits of a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation; if this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- 1. Reorient/relocate the receiving antenna.
- 2. Increase the separation between the equipment and receiver.
- 3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- 4. Consult the dealer or an experienced radio/TV technician for help.

### Radio Wave Exposure and Specific Absorption Rate (SAR) Information

[403SH] here refers to this mobile phone [AQUOS CRYSTAL 2].

### Specific Absorption Rate (SAR) for This Product (for Japan)

This mobile phone 【403SH】 meets the Japanese technical regulations\* and international guidelines for exposure to radio waves

The Japanese technical regulations for exposure to radio frequency energy established permitted levels of radio frequency energy, based on standards developed by independent scientific organizations through periodic and thorough evaluation of scientific studies.

The regulation employs a unit of measurement known as the Specific Absorption Rate, or SAR.

The SAR limit is 2 watts/kilogram (W/kg) averaged over ten grams of tissue.

The limit includes a substantial safety margin designed to assure the safety of all persons, regardless of age and health. The value of the limit is equal to the value given in international guidelines recommended by ICNIRP\*\*, which is in collaboration with the World Health Organization (WHO). The highest SAR value for this mobile phone is 0.532 W/kg when tested for use at the ear, and 0.486 W/kg\*\*\* when worn on the body in the below manner\*\*\*.

While there may be differences between the SAR levels of various phones and at various positions, all phones meet the Japanese technical regulations.

Although the SAR is determined at the highest certified power level, the actual SAR of the phone during operation can be well below the maximum value.

Use at positions other than at the ear\*\*\*\*

This mobile phone may be used at positions other than at the ear. By using an accessory such as a belt clip holster that maintains a 1.5 cm separation with no metal (parts) between the body and the mobile phone, this mobile phone will comply with international guidelines for radio wave protection.

- \* The technical regulation is provided in Article 14-2 of the Ministry Ordinance Regulating Radio Equipment.
- \*\* International Commission on Non-Ionizing Radiation
- \*\*\* The value is under simultaneous transmission use conditions.

The World Health Organization has announced that "A large number of studies have been performed over the last two decades to assess whether mobile phones pose a potential health risk. To date, no adverse health effects have been established as being caused by mobile phone use."

For more information about SAR, see the following websites: Ministry of Internal Affairs and Communications (MIC) http://www.tele.soumu.go.jp/e/sys/ele/body/index.htm Association of Radio Industries and Businesses (ARIB) http://www.arib-emf.org/index02.html (Japanese)

### European RF Exposure Information/FCC RF Exposure Information

This mobile phone [403SH] is confirmed to comply with guidelines relating to effects of radio wave exposure as set forth by the Council of Europe (CE) and the Federal Communications Commission (FCC). Refer to the following.

### ■European RF Exposure Information

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves recommended by international guidelines. These guidelines were developed by the independent scientific organization ICNIRP and include safety margins designed to assure the protection of all persons, regardless of age and health. The guidelines use a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit for mobile devices is 2.0 W/kg and the highest SAR value for this device when tested at the ear is 0.403 W/kg\*.

As mobile devices offer a range of functions, they can be used in other positions, such as on the body as described in this User Guide. In this case, the highest tested SAR value is 0.500 W/ka\*.

\* The tests are carried out in accordance with international auidelines for testina.

### ■FCC RF Exposure Information

Your handset is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government. The guidelines are based on standards that were developed by independent scientific organization through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health. The exposure standard for wireless handsets employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg. The tests are performed in positions and locations (e.g. at the ear and worn on the body) as required by the FCC for each model. The highest SAR value for this model handset as reported to the FCC when tested for use at the ear is 0.39 W/kg, and when worn on the body in a holder or carry case, is 0.45 W/kg. Body-worn Operation; This device was tested for typical body-worn operations with the handset kept 1.0 cm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 1.0 cm separation distance between the user's body and the handset. The use of beltclips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided. The FCC has granted an Equipment Authorization for this model handset with all reported SAR levels evaluated as in compliance with the FCC RF emission

guidelines. SAR information on this model handset is on

ID APYHRO00221.

file with the FCC and can be found under the Display Grant

section of http://www.fcc.gov/oet/ea/ after searching on FCC

Additional information on Specific Absorption Rates (SAR) can be found on the FCC website at http://transition.fcc.gov/oet/rfsafety/.

### FCC ID Location

The device is electronically labeled and the FCC ID can be displayed via the About phone & Technical Regulations Conformity Certification under the Setting menu.

The World Health Organization has stated that present scientific information does not indicate the need for any special precautions for the use of mobile devices. They note that if you want to reduce your exposure then you can do so by limiting the length of calls or using a hands-free device to keep the mobile phone away from the head and body.

### World Health Organization

http://www.who.int/emf

List of Specific Absorption Rates (SAR) for radio waves by smartphone/3G model

http://www.softbank.jp/mobile/support/sar/ (Japanese)

### Water Resistance

### Handset Water Resistance

Handset complies with IPX5 (former JIS protection level 5)<sup>1</sup> and IPX7 (former JIS protection level 7)<sup>2</sup> water protection standards, with Card Slot Cover closed firmly. (Handset is not dust proof.)

<sup>1</sup>IPX5 compliant means that a handset continues to function as a phone after being subjected to a water jet (approximately 12.5 liters/min.) discharged from a nozzle (inner diameter: 6.3 mm), from all directions (approximately 3 m from handset) for at least 3 minutes.

<sup>2</sup>IPX7 compliant means that a handset continues to function as a phone after being gently submerged to the depth of 1 m in still tap water at room temperature, left there for approximately 30 minutes, then removed from it.

- Water resistance may be affected under some circumstances.
   Warranty does not cover malfunctions resulting from misuse.
- Handset is compliant with IPX5 and IPX7 water protection standards. However, ingress of beverage, sea water, etc. may cause malfunction.

### ■Handset Care

- · Close Card Slot Cover firmly. Debris (hair, sand, fibers, etc.) trapped between gasket and Card Slot may allow ingress of liquid.
- If handset is exposed to liquids with Card Slot Cover open, they may enter handset and cause electric shock or malfunction. Discontinue use and power off.
- · If handset is wet, wipe it with a dry cloth.
- · Never open/close Card Slot Cover with wet hands or while handset is wet.
- Do not use Earphones-Microphone Port or External Device Port while it is wet or obstructed by sand/dirt; water resistance may be affected, or malfunction, burns or fire may result due to electric shock, short-circuiting, etc.
- Handset is only water resistant against fresh/tap water between 5°C - 35°C.

### Precautions

- · Do not subject handset to soap, detergent, bath powder/oil, sea/pool/spa water, hot water, etc.
- · Rinse off sea/pool water, beverage, dirt, sand, mud, etc. immediately with fresh/tap water between 5°C - 35°C; residue may cause malfunction if allowed to dry.
- · Do not soak handset in bath or pool; never use it in water (including key operation).
- · Handset is not resistant to water pressure. Avoid highpressure water/shower (over 6 liters/min.) and water immersion.
- · Do not expose handset to high humidity for long periods; avoid prolonged use in bath/shower rooms.
- · Volume may be low when an opening such as Mic/Recorder Mic or Speaker is wet; dry handset before use (see "Drying Handset").
- · Charger and other optional accessories are not waterproof. Do not use in high humidity or near water (outdoors, in bathrooms, shower rooms, etc.); may cause fire, electric shock or malfunction.
- · Do not subject handset to strong impact (e.g., from a fall); do not poke Mic/Recorder Mic, Speaker, Mic, Recorder Mic, etc. with a sharp object.
- · Avoid placing handset directly on sand. Sand may penetrate Speaker, Mic, Recorder Mic, etc., resulting in low volume.
- · To prevent condensation, warm handset to room temperature before bringing it from a cold place into a warm place such as a bathroom. If condensation occurs, leave handset at room temperature until it is dry.
- · Handset does not float on water.
- · Keep handset out of heavy rain.

### **Charging Cautions**

- · Never connect Micro USB plug while handset or Charger is
- Handset is water resistant; however, if Micro USB plug is inserted while it is wet, liquid (tap water, beverage, sea water, pet urine, etc.) or a foreign object adhered to handset or Micro USB plug may cause overheating, burnout, fire, malfunction, burns, etc. due to electric shock, shortcircuiting, etc.
- Do not use Charger where water is regularly in use (kitchens, bathrooms, shower rooms, etc.); may cause fire or electric shock.

### Care & Maintenance

- · Proper care of Card Slot Cover gasket is crucial for continued handset water resistance. Observe the following:
  - · Do not remove or damage gasket. Keep it clean.
- · If Card Slot Cover is damaged or deformed, contact a SoftBank Shop.
- · Do not insert a sharp object into Card Slot Cover gap, Earphones-Microphone Port or External Device Port.
- · To maintain water resistance, it is recommended to replace Card Slot Cover every 2 years regardless of its condition. Customer-requested Card Slot Cover replacement incurs fees and requires handset submission. For details, contact a SoftBank Shop or SoftBank Customer Support, General Information.

### Washing Handset

Wipe off dirt, sand, beverage, etc., gently with a cloth. Then hold handset approximately 10 cm below faucet or shower head and wash with low-pressure tap water (6 liters/min. or lower) at room temperature (5°C - 35°C). Wash with your hands, taking care not to open Card Slot Cover; do not use a brush or sponge. Dry handset before use; after drying it well, power on.

- · Before washing handset, make sure that Card Slot Cover is closed firmly.
- · Do not use a washing machine or ultrasonic cleaner.
- · Earphones-Microphone Port and External Device Port tend to accumulate dust, sand, etc.; rinse and dry them completely before use. Any residue may cause malfunction, burns or fire.
- · Do not put a cotton swab, cloth, etc. into Earphones-Microphone Port or External Device Port; water resistance may be affected causing malfunction.

### Drying Handset


After exposing handset to water, be sure to dry Mic/Recorder Mic, Mic, Recorder Mic, Speaker, Earphones-Microphone Port and External Device Port.



Wipe handset surface with dry cloth



Holding handset firmly by its sides, shake it about 20 times



· When shaking handset, hold it firmly so as not to drop it.



Pat against dry cloth to remove moisture from openings and grooves



 $\cdot$  Water may be trapped in openings; pat against a dry cloth to remove it.



Leave handset on dry cloth for approximately 2 -  $\mathbf 3$  hours at room temperature

### Cautions

### When Removing Moisture

Do not put a cotton swab, cloth, etc. into openings; water resistance may be affected.

### After Drying Procedure

Do not use handset in wet conditions.

- $\cdot$  Calls may fail, or moisture may transfer to clothes, bag,  $_{\mbox{\scriptsize otc}}$
- Moisture may short-circuit Earphones-Microphone Port, External Device Port or other parts.
- $\boldsymbol{\cdot}$  Exposure to cold may freeze moisture and cause malfunction.

# AQUOS CRYSTAL 2 User Guide Index



About phone
B
Backup & Restore
C
Calling
D
Data Transfer
<b>B</b>
Energy Saving Settings126
File Storage162
G
General Notes

<b>H</b>
Handset & Hardware Care177
Handset Initial Settings16
Handset Memory & SD Card9
Handset Phone Number
Hiding Contacts (Secrecy Settings)74
Home Applications Setting130
Home Screen (Feel Home) Basics43
Icons at Display Top (Status Bar)44
Important Product Information176
M
Mail Settings136
Making Call Settings69
Messaging 78
Music Files (Music)100
0
Opening & Replying to S! Mail/SMS81
Operating by Gripping Handset (Grip Magic)38
Optional Services64
Other Settings146
P
Package Contents
Parts & Functions
14 Tower Oil/OIT14
R
Radio Wave Exposure and Specific Absorption Rate (SAR)
Information
Recording Videos
,
5
Safety Precautions168
Security Codes
Sending S! Mail/SMS79
S! Mail Initial Setup78
Sound/Notification Settings121
Specifications165
Storage Settings142
Text Entry
Touchscreen Operations
Troubleshooting163

# AQUOS CRYSTAL 2 User Guide

October 2015, First Edition SoftBank Corp.

Visit SoftBank Shop for assistance

Model : AQUOS CRYSTAL 2 Manufacturer : SHARP CORPORATION