






Libero 2

QUICK START

Parts & Functions



- | | |
|---|--|
| ① Earphone Port | ⑩  : Back to previous screen. |
| ② Front Camera Flash | ⑪ External Device Port |
| ③ Earpiece | ⑫ Mic |
| ④ Proximity/Light Sensor | ⑬ Volume Up/Down Key |
| ⑤ Front Camera | ⑭ Power Key: Power On/Off (Long Press) |
| ⑥ Notification Lamp | ⑮ Camera |
| ⑦ Display | ⑯ Camera Flash |
| ⑧  : Show recently-used applications. | ⑰ Battery Cover |
| ⑨  : Show Home Screen. | ⑱ Speaker |

Touchscreen Operations

Tap

Contact Display lightly and briefly.




Touch & Hold

Contact Display lightly; release finger when screen changes.




Drag

Touch icon or other item lightly, move it where desired, and release finger.




Swipe/Flick

Contact Display lightly, then brush screen up/down or left/right.



Pinch/Spread


Contact Display lightly, then close/widen fingers.




Getting Started

Powering On/Initial Settings


The first time powering on, initial settings appear. Follow onscreen instructions.




- 1** In initial setting, Tap "日本語(日本)" to change language to "English" ► "LET'S GO"




- 2** Select setup option




- 3** Set up Wi-Fi
• For details, see "Setting Up Wi-Fi."




- 4** Set up Google™ account




- 5** Set phone protection



- 6** Set Google services



- 7** Set up more ► "ALL SET"



* Setting steps may differ depending on handset condition.

Text Entry

Use onscreen keyboard for text entry.

Keyboard Layout (10-Key Keyboard)

Default input mode is Kana (Japanese); Tap  to toggle input mode to Alphabet.



Tap key to enter assigned character

記号

Switch to Emoji/Symbol/Emoticon list

文字
あA1

Toggle input mode


- Toggles to Kana→Alphabet→Number in order.



Delete character before cursor

Changing Keyboard

1 While entering text,  ► Choose keyboard




Home Screen/Applications List

Home Screen

Home Screen is a starting window for operations. Drag/Flick left or right to toggle the sheets.

Status Bar

Status Indicators appear for notifications or handset status. Drag down to open Notifications Window.








Customize area

Customize Home Screen; Touch & Hold area without shortcuts to change Wallpaper, or Touch & Hold shortcuts to move, remove, etc.


Dock


Shortcuts can be moved, removed or changed.

-  Place calls.
-  Use S! Mail and SMS.
-  Customize handset settings.
-  Access Internet.
-  Capture photos or videos.



Applications List


In Home Screen, Tap  to open applications list. Tap an icon to activate the application.



Messaging


Use S! Mail/SMS for messaging.

Creating/Sending S! Mail


1 In Home Screen,
(Mail)→ 



2 Enter recipient, subject,
message




3 Tap "Send"



- If sending confirmation appears, follow onscreen instructions.

Checking New Mail

Mail notification appears and sounds when a message arrives. Tap a notification to open the message.

 Mail • now ∨
1 new message: Yamamoto
Subject:Re: Hello !

Other mail applications are pre-installed on handset.

 S! Mail/SMS


 Email

 Gmail

Setting Up Wi-Fi


Handset supports Wi-Fi (wireless LAN). Access the Internet via Wi-Fi.

- 1 In Home Screen,  (Settings) ▶ "Wi-Fi" ▶ Tap 



- Wi-Fi is ON ().

- 2 Choose an access point (Wi-Fi network) ▶ Enter password ▶ "CONNECT"




User Guides

Guide (Application)

Use to learn handset operations or access FAQ Web pages.

1 In Home screen,  (Applications list) ▶  (Guide)

- In Guide, some functions can be activated from the description by Tapping "Access."



User Guide

Available from handset or on a PC.

■ From handset

Activate browser and select "オンラインマニュアル" bookmark.

■ From a PC

<https://www.softbank.jp/mobile/support/product/libero2-prepaid/>

*PDF version is also downloadable.

For Assistance

For SoftBank handset or service information, call General Information. For repairs, call Customer Assistance.

SoftBank Customer Support

■ General Information

From a SoftBank handset, dial toll free at **157**

From a landline/IP phone, dial toll free at

 **0800-919-0157**

■ Customer Assistance (Repairs/Lost Handsets)

From a SoftBank handset, dial toll free at **113**

From a landline/IP phone, dial toll free at

 **0800-919-0113**

Smartphone Technical Support Center

From a SoftBank handset, dial toll free at **151**

From a landline/IP phone, dial toll free at

 **0800-1700-151**

SoftBank Global Call Center

From outside Japan, dial

+81-92-687-0025

(toll free from SoftBank handsets)



ソフトバンクは、
はじめています。
続けていきます。
環境への取り組み。

<https://www.softbank.jp>

2017.7 1st Edition

SoftBank Corp.

For inquiry,

Contact the SoftBank Shop where you purchased
handset

Model: Libero 2

Manufactured by: ZTE Corporation



モバイルリサイクルネットワーク
携帯電話・モバイル端末のリサイクルにご協力。



やめましょう、
歩きスマホ。



キケン！
水ぬれ充電

